



ONVIF Conformance Test

Performed by

Operator - Operator

Organization - Lingodigit Co., Ltd.

Address - Rm.12, 2F.,No.128, Bao'an 5th St., Nantun Dist.,Taichung City 40858, Taiwan

Device Under Test

Product Name - ONVIF-M550S

Brand - Lingodigit Co., Ltd.

Model - ONVIF-M550S

Product Type - Fixed Camera

Serial Number - 0200DA0011AA

Firmware Version - 1.0

Other -

ONVIF Device Test Tool version 19.12 rev. 5581

Test Date and Time - 2020/3/12 @ 05:56:11

ONVIF Test Summary

Tests Executed: 215

Tests Passed: 215

Tests Failed: 0

Features:

Events

Media

IO

Timeouts (ms):

Message Timeout: 30000

Reboot Timeout: 30000

Time between Tests: 0

Time between Requests: 50

Operation Delay: 1000

Real Timeouts (ms):

Maximum Timeout: 422

Median Timeout: 16

Average Timeout: 36

Account: admin

TEST PASSED

Features Definition Log

DEFINE FEATURES

STEP 1 - GetCapabilities (no credentials supplied)

STEP PASSED

STEP 2 - GetServices (no credentials supplied)

STEP PASSED

STEP 3 - Check GetCapabilities and GetServices

STEP PASSED

STEP 4 - Get Service Capabilities (no credentials supplied)

STEP PASSED

STEP 5 - Analyze Device Service capabilities

STEP PASSED

STEP 6 - Define Network features

STEP PASSED

STEP 7 - Define Security capabilities

STEP PASSED

STEP 8 - Define System features

STEP PASSED

STEP 9 - Define Device IO features

STEP PASSED

STEP 10 - Define Misc features

STEP PASSED

STEP 11 - Sending Unicast Probe request

STEP PASSED

STEP 12 - Define Discovery features

STEP PASSED

STEP 13 - Get Event service capabilities

STEP PASSED

STEP 14 - Define Media features

STEP PASSED

STEP 15 - Get Video Encoder Configuration Options

STEP PASSED

STEP 16 - Get Audio Encoder Configuration Options

STEP PASSED

STEP 17 - Define Audio features

STEP PASSED

STEP 18 - Get Media Capabilities

STEP PASSED

STEP 19 - Define Streaming features

STEP PASSED

Define GetSnapshotURI capability

STEP 20 - Get Profiles

STEP PASSED

Find profile with Video Source and Video Encoder for testing Snapshot URI feature

Use profile with token profile1

STEP 21 - Get snapshot URI

STEP PASSED

STEP 22 - Get Audio Outputs

STEP PASSED

STEP 23 - Define Audio Output features

STEP PASSED

STEP 24 - Define Security Configuration support

STEP PASSED

STEP 25 - Get Network Protocols

STEP PASSED

STEP 26 - Define Media2 features

STEP PASSED

STEP 27 - Check IO service

STEP PASSED

STEP 28 - Get IO capabilities

STEP PASSED

STEP 29 - Define RelayOutputs features

STEP PASSED

STEP 30 - Define Relay Output Options features

STEP PASSED

STEP 31 - Define DigitalInputs features

STEP PASSED

STEP 32 - Define DigitalInputOptions features

STEP PASSED

STEP 33 - Define PTZ service

STEP PASSED

STEP 34 - Define Imaging features

STEP PASSED

STEP 35 - Define AnalyticsService features

STEP PASSED

STEP 36 - Define Recording Control service support

STEP PASSED

STEP 37 - Define Search service support

STEP PASSED

STEP 38 - Define Replay service support

STEP PASSED

STEP 39 - Define Receiver service support

STEP PASSED

STEP 40 - Define Access Rules support

STEP PASSED

STEP 41 - Define Credential support

STEP PASSED

STEP 42 - Define Schedule support

STEP PASSED

STEP 43 - Define AccessControl service support

STEP PASSED

STEP 44 - Define DoorControl service support

STEP PASSED

STEP 45 - Define Thermal service support

STEP PASSED

STEP 46 - Get Event Properties

STEP PASSED

STEP 47 - Define supported events

STEP PASSED

Define device scope(s)

STEP 48 - Get device scopes

STEP PASSED

STEP 49 - Check scopes

STEP PASSED

STEP 50 - Get device information

STEP PASSED

STEP 51 - Get Endpoint Address

STEP PASSED

STEP 52 - Check for Undefined features

STEP PASSED

PROCESS COMPLETED

Device Pre-Configuration Log

PRECONFIGURE DEVICE FOR CONFORMANCE

IPv6 is not supported, skipping IPv6 configuration procedure.

PROCESS COMPLETED

The following tests were FAILED:

Tests

MEDIA-1-1-1-v14.12 MEDIA PROFILE CONFIGURATION

MEDIA-1-1-3-v14.12 PROFILES CONSISTENCY

MEDIA-1-1-5-v19.12 DYNAMIC MEDIA PROFILE CONFIGURATION

MEDIA-2-1-2-v14.12 VIDEO ENCODER CONFIGURATION

MEDIA-2-1-6-v14.12 GUARANTEED NUMBER OF VIDEO ENCODER INSTANCES

MEDIA-2-1-7-v14.12 GET GUARANTEED NUMBER OF VIDEO ENCODER INSTANCES AND GET VIDEO ENCODER CONFIGURATION OPTIONS CONSISTENCY

MEDIA-2-1-8-v14.12 VIDEO SOURCE CONFIGURATION

MEDIA-2-1-9-v14.12 JPEG VIDEO ENCODER CONFIGURATION

MEDIA-2-1-11-v14.12 H.264 VIDEO ENCODER CONFIGURATION

MEDIA-2-2-1-v14.12 VIDEO SOURCE CONFIGURATIONS AND PROFILES CONSISTENCY

MEDIA-2-2-2-v14.12 VIDEO SOURCE CONFIGURATIONS AND VIDEO SOURCE CONFIGURATION CONSISTENCY

MEDIA-2-2-3-v14.12 VIDEO SOURCE CONFIGURATIONS AND VIDEO SOURCE CONFIGURATION OPTIONS CONSISTENCY

MEDIA-2-2-4-v14.12 PROFILES AND VIDEO SOURCE CONFIGURATION OPTIONS CONSISTENCY

MEDIA-2-2-5-v14.12 VIDEO SOURCE CONFIGURATIONS AND VIDEO SOURCES CONSISTENCY

MEDIA-2-2-6-v14.12 VIDEO SOURCE CONFIGURATION USE COUNT (CURRENT STATE)

MEDIA-2-2-12-v14.12 VIDEO SOURCE CONFIGURATION USE COUNT (ADD SAME VIDEO SOURCE CONFIGURATION TO PROFILE TWICE)

MEDIA-2-2-13-v14.12 VIDEO SOURCE CONFIGURATION USE COUNT (ADD DIFFERENT VIDEO SOURCE CONFIGURATIONS IN PROFILE)

MEDIA-2-2-14-v14.12 VIDEO SOURCE CONFIGURATION USE COUNT (REMOVE VIDEO SOURCE CONFIGURATION)

MEDIA-2-2-15-v17.06 VIDEO SOURCE CONFIGURATION USE COUNT (DELETION PROFILE WITH VIDEO SOURCE CONFIGURATION)

MEDIA-2-2-16-v14.12 VIDEO SOURCE CONFIGURATION USE COUNT (SET VIDEO SOURCE CONFIGURATION)

MEDIA-2-3-1-v14.12 VIDEO ENCODER CONFIGURATIONS AND PROFILES CONSISTENCY

MEDIA-2-3-2-v14.12 VIDEO ENCODER CONFIGURATIONS AND VIDEO ENCODER CONFIGURATION CONSISTENCY

MEDIA-2-3-3-v14.12 VIDEO ENCODER CONFIGURATIONS AND VIDEO ENCODER

CONFIGURATION OPTIONS CONSISTENCY

MEDIA-2-3-4-v14.12 PROFILES AND VIDEO ENCODER CONFIGURATION OPTIONS
CONSISTENCY

MEDIA-2-3-5-v14.12 VIDEO ENCODER CONFIGURATION USE COUNT (CURRENT STATE)

MEDIA-2-3-12-v14.12 VIDEO ENCODER CONFIGURATIONS – ALL SUPPORTED VIDEO
ENCODINGS

MEDIA-2-3-13-v14.12 VIDEO ENCODER CONFIGURATION USE COUNT (ADD SAME VIDEO
ENCODER CONFIGURATION TO PROFILE TWICE)

MEDIA-2-3-14-v14.12 VIDEO ENCODER CONFIGURATION USE COUNT (ADD DIFFERENT VIDEO
ENCODER CONFIGURATIONS IN PROFILE)

MEDIA-2-3-15-v14.12 VIDEO ENCODER CONFIGURATION USE COUNT (REMOVE VIDEO
ENCODER CONFIGURATION)

MEDIA-2-3-16-v17.06 VIDEO ENCODER CONFIGURATION USE COUNT (PROFILE DELETION
WITH VIDEO ENCODER CONFIGURATION)

MEDIA-2-3-17-v14.12 VIDEO ENCODER CONFIGURATION USE COUNT (SET VIDEO ENCODER
CONFIGURATION)

MEDIA-3-1-7-v19.12 GET AUDIO SOURCE CONFIGURATION OPTIONS

MEDIA-3-1-14-v14.12 G.711 AUDIO ENCODER CONFIGURATION

MEDIA-3-1-16-v14.12 AAC AUDIO ENCODER CONFIGURATION

MEDIA-3-1-17-v14.12 GET AUDIO SOURCE CONFIGURATION – INVALID
CONFIGURATIONTOKEN

MEDIA-3-1-18-v14.12 GET AUDIO SOURCE CONFIGURATION OPTIONS – INVALID
PROFILETOKEN

MEDIA-3-1-19-v14.12 GET AUDIO SOURCE CONFIGURATION OPTIONS – INVALID
CONFIGURATION TOKEN

MEDIA-3-1-20-v14.12 SET AUDIO SOURCE CONFIGURATION – INVALID TOKEN

MEDIA-3-1-21-v14.12 SET AUDIO ENCODER CONFIGURATION

MEDIA-3-1-22-v14.12 AUDIO SOURCE CONFIGURATION

MEDIA-3-1-23-v14.12 AUDIO ENCODER CONFIGURATION

MEDIA-3-2-1-v14.12 AUDIO SOURCE CONFIGURATIONS AND PROFILES CONSISTENCY

MEDIA-3-2-2-v14.12 AUDIO SOURCE CONFIGURATIONS AND AUDIO SOURCE
CONFIGURATION CONSISTENCY

MEDIA-3-2-3-v14.12 AUDIO SOURCE CONFIGURATIONS AND AUDIO SOURCE
CONFIGURATION OPTIONS CONSISTENCY

MEDIA-3-2-4-v14.12 PROFILES AND AUDIO SOURCE CONFIGURATION OPTIONS

CONSISTENCY

MEDIA-3-2-5-v14.12 AUDIO SOURCE CONFIGURATIONS AND AUDIO SOURCES CONSISTENCY

MEDIA-3-2-6-v14.12 AUDIO SOURCE CONFIGURATION USE COUNT (CURRENT STATE)

MEDIA-3-2-12-v14.12 AUDIO SOURCE CONFIGURATION USE COUNT (ADD SAME AUDIO SOURCE CONFIGURATION TO PROFILE TWICE)

MEDIA-3-2-13-v14.12 AUDIO SOURCE CONFIGURATION USE COUNT (ADD DIFFERENT AUDIO SOURCE CONFIGURATIONS IN PROFILE)

MEDIA-3-2-14-v14.12 AUDIO SOURCE CONFIGURATION USE COUNT (REMOVE AUDIO SOURCE CONFIGURATION)

MEDIA-3-2-15-v17.06 AUDIO SOURCE CONFIGURATION USE COUNT (PROFILE DELETION WITH AUDIO SOURCE CONFIGURATION)

MEDIA-3-2-16-v14.12 AUDIO SOURCE CONFIGURATION USE COUNT (SET AUDIO SOURCE CONFIGURATION)

MEDIA-3-3-1-v14.12 AUDIO ENCODER CONFIGURATIONS AND PROFILES CONSISTENCY

MEDIA-3-3-2-v14.12 AUDIO ENCODER CONFIGURATIONS AND AUDIO ENCODER CONFIGURATION CONSISTENCY

MEDIA-3-3-3-v14.12 AUDIO ENCODER CONFIGURATIONS AND AUDIO ENCODER CONFIGURATION OPTIONS CONSISTENCY

MEDIA-3-3-4-v14.12 PROFILES AND AUDIO ENCODER CONFIGURATION OPTIONS CONSISTENCY

MEDIA-3-3-5-v14.12 AUDIO ENCODER CONFIGURATION USE COUNT (CURRENT STATE)

MEDIA-3-3-11-v14.12 AUDIO ENCODER CONFIGURATION OPTIONS AND AUDIO ENCODER CONFIGURATIONS CONSISTENCY (BITRATE AND SAMPLERATE)

MEDIA-3-3-12-v14.12 AUDIO ENCODER CONFIGURATION USE COUNT (ADD SAME AUDIO ENCODER CONFIGURATION TO PROFILE TWICE)

MEDIA-3-3-13-v14.12 AUDIO ENCODER CONFIGURATION USE COUNT (ADD DIFFERENT AUDIO ENCODER CONFIGURATIONS IN PROFILE)

MEDIA-3-3-14-v14.12 AUDIO ENCODER CONFIGURATION USE COUNT (REMOVE AUDIO ENCODER CONFIGURATION)

MEDIA-3-3-15-v17.06 AUDIO ENCODER CONFIGURATION USE COUNT (DELETION PROFILE WITH AUDIO ENCODER CONFIGURATION)

MEDIA-3-3-16-v14.12 AUDIO ENCODER CONFIGURATION USE COUNT (SET AUDIO ENCODER CONFIGURATION)

MEDIA-5-1-3-v14.12 METADATA CONFIGURATION

MEDIA-6-1-1-v19.06 SNAPSHOT URI

MEDIA-7-1-2-v18.06 SOAP FAULT MESSAGE
MEDIA-7-1-4-v14.12 SOAP FAULT MESSAGE
MEDIA-8-1-1-v14.12 MEDIA SERVICE CAPABILITIES
MEDIA-8-1-2-v14.12 GET SERVICES AND GET MEDIA SERVICE CAPABILITIES CONSISTENCY
RTSS-1-1-27-v19.12 MEDIA STREAMING – GUARANTEED NUMBER OF VIDEO ENCODER INSTANCES (RTP-Unicast/UDP)
RTSS-1-1-28-v19.12 MEDIA STREAMING – GUARANTEED NUMBER OF VIDEO ENCODER INSTANCES (RTP-Unicast/RTSP/HTTP/TCP)
RTSS-1-1-29-v19.12 MEDIA STREAMING – GUARANTEED NUMBER OF VIDEO ENCODER INSTANCES (RTP/RTSP/TCP)
RTSS-1-1-30-v19.12 MEDIA STREAMING – GUARANTEED NUMBER OF VIDEO ENCODER INSTANCES (MIX OF TRANSPORT TYPES)
RTSS-1-1-31-v19.12 MEDIA CONTROL – RTSP/TCP
RTSS-1-1-32-v19.12 MEDIA STREAMING – RTSP KEEPALIVE (SET_PARAMETER)
RTSS-1-1-33-v19.12 MEDIA STREAMING - RTSP KEEPALIVE (OPTIONS)
RTSS-1-1-34-v19.12 MEDIA STREAMING – JPEG (RTP-Unicast/UDP)
RTSS-1-1-35-v19.12 MEDIA STREAMING - JPEG (RTP-Unicast/RTSP/HTTP/TCP)
RTSS-1-1-36-v19.12 MEDIA STREAMING - JPEG (RTP/RTSP/TCP)
RTSS-1-1-41-v19.12 MEDIA STREAMING - H.264 (RTP-Unicast/UDP)
RTSS-1-1-42-v19.12 MEDIA STREAMING - H.264 (RTP-Unicast/RTSP/HTTP/TCP)
RTSS-1-1-43-v19.12 MEDIA STREAMING - H.264 (RTP/RTSP/TCP)
RTSS-1-1-44-v19.12 SET SYNCHRONIZATION POINT - H.264
RTSS-1-1-45-v19.12 MEDIA STREAMING – RTP-Unicast/RTSP/HTTP/TCP (LINE BREAKS IN BASE64 ENCODING)
RTSS-1-1-46-v19.12 VIDEO ENCODER CONFIGURATION – JPEG RESOLUTION
RTSS-1-1-48-v19.12 VIDEO ENCODER CONFIGURATION – H.264 RESOLUTION
RTSS-1-1-53-v19.12 MEDIA STREAMING – JPEG (VALIDATING RTP HEADER EXTENSION)
RTSS-2-1-19-v19.12 MEDIA STREAMING – G.711 (RTP-Unicast/UDP)
RTSS-2-1-20-v19.12 MEDIA STREAMING – G.711 (RTP-Unicast/RTSP/HTTP/TCP)
RTSS-2-1-21-v19.12 MEDIA STREAMING – G.711 (RTP/RTSP/TCP)
RTSS-2-1-25-v19.12 MEDIA STREAMING – AAC (RTP-Unicast/UDP)
RTSS-2-1-26-v19.12 MEDIA STREAMING – AAC (RTP-Unicast/RTSP/HTTP/TCP)
RTSS-2-1-27-v19.12 MEDIA STREAMING – AAC (RTP/RTSP/TCP)
RTSS-2-1-28-v19.12 AUDIO STREAMING – G.711 (RTP-Unicast/UDP)
RTSS-2-1-29-v19.12 AUDIO STREAMING – G.711 (RTP-Unicast/RTSP/HTTP/TCP)

RTSS-2-1-30-v19.12 AUDIO STREAMING – G.711 (RTP/RTSP/TCP)
RTSS-2-1-34-v19.12 AUDIO STREAMING – AAC (RTP-Unicast/UDP)
RTSS-2-1-35-v19.12 AUDIO STREAMING – AAC (RTP-Unicast/RTSP/HTTP/TCP)
RTSS-2-1-36-v19.12 AUDIO STREAMING – AAC (RTP/RTSP/TCP)
RTSS-3-1-10-v19.12 MEDIA STREAMING – VIDEO AND G.711 AUDIO (RTP-Unicast/UDP)
RTSS-3-1-11-v19.12 MEDIA STREAMING – VIDEO AND G.711 AUDIO (RTP-
Unicast/RTSP/HTTP/TCP)
RTSS-3-1-12-v19.12 MEDIA STREAMING – VIDEO AND G.711 AUDIO (RTP/RTSP/TCP)
RTSS-3-1-16-v19.12 MEDIA STREAMING – VIDEO AND AAC AUDIO (RTP-Unicast/UDP)
RTSS-3-1-17-v19.12 MEDIA STREAMING – VIDEO AND AAC AUDIO (RTP-
Unicast/RTSP/HTTP/TCP)
RTSS-3-1-18-v19.12 MEDIA STREAMING – VIDEO AND AAC AUDIO (RTP/RTSP/TCP)
RTSS-4-1-3-v19.12 NOTIFICATION STREAMING
IMAGING-4-1-2-v18.06 REALTIME PULLPOINT SUBSCRIPTION – IMAGE TOO DARK
IMAGING-4-1-5-v18.06 REALTIME PULLPOINT SUBSCRIPTION – MOTION ALARM
DEVICEIO-2-1-1-v18.06 REALTIME PULLPOINT SUBSCRIPTION – DIGITAL INPUT EVENT
DEVICEIO-3-1-1-v17.01 GETDIGITALINPUTS
DEVICEIO-3-1-2-v17.01 GETDIGITALINPUTS – VERIFY QUANTITY
DEVICEIO-3-1-3-v17.12 I/O GET DIGITAL INPUT CONFIGURATION OPTIONS
DEVICEIO-3-1-4-v17.12 I/O DIGITAL INPUT CONFIGURATION
DEVICEIO-5-1-1-v17.12 GET VIDEOSOURCES (DeviceIO) AND GET VIDEOSOURCES (Media)
CONSISTENCY
SECURITY-1-1-1-v14.12 USER TOKEN PROFILE
SECURITY-1-1-2-v14.12 DIGEST AUTHENTICATION
IPCONFIG-1-1-3-v16.07 IPV4 DHCP
DISCOVERY-1-1-2-v16.01 HELLO MESSAGE VALIDATION
DISCOVERY-1-1-3-v14.12 SEARCH BASED ON DEVICE SCOPE TYPES
DISCOVERY-1-1-4-v14.12 SEARCH WITH OMITTED DEVICE AND SCOPE TYPES
DISCOVERY-1-1-5-v14.12 RESPONSE TO INVALID SEARCH REQUEST
DISCOVERY-1-1-6-v14.12 SEARCH USING UNICAST PROBE MESSAGE
DISCOVERY-1-1-8-v14.12 BYE MESSAGE
DISCOVERY-1-1-9-v14.12 DISCOVERY MODE CONFIGURATION
DISCOVERY-1-1-11-v14.12 DEVICE SCOPES CONFIGURATION
DISCOVERY-2-1-1-v14.12 DISCOVERY - NAMESPACES (DEFAULT NAMESPACES FOR EACH
TAG)

DISCOVERY-2-1-2-v14.12 DISCOVERY - NAMESPACES (DEFAULT NAMESPACES FOR PARENT TAG)

DISCOVERY-2-1-3-v14.12 DISCOVERY - NAMESPACES (NOT STANDARD PREFIXES)

DISCOVERY-2-1-4-v14.12 DISCOVERY - NAMESPACES (DIFFERENT PREFIXES FOR THE SAME NAMESPACE)

DISCOVERY-2-1-5-v14.12 DISCOVERY - NAMESPACES (THE SAME PREFIX FOR DIFFERENT NAMESPACES)

DEVICE-1-1-1-v14.12 GET WSDL URL

DEVICE-1-1-2-v14.12 ALL CAPABILITIES

DEVICE-1-1-3-v14.12 DEVICE CAPABILITIES

DEVICE-1-1-4-v14.12 MEDIA CAPABILITIES

DEVICE-1-1-5-v14.12 EVENT CAPABILITIES

DEVICE-1-1-6-v14.12 PTZ CAPABILITIES

DEVICE-1-1-9-v14.12 SOAP FAULT MESSAGE

DEVICE-1-1-10-v14.12 IMAGING CAPABILITIES

DEVICE-1-1-11-v14.12 ANALYTICS CAPABILITIES

DEVICE-1-1-13-v14.12 GET SERVICES – DEVICE SERVICE

DEVICE-1-1-14-v14.12 GET SERVICES – MEDIA SERVICE

DEVICE-1-1-16-v14.12 GET SERVICES – EVENT SERVICE

DEVICE-1-1-18-v14.12 DEVICE SERVICE CAPABILITIES

DEVICE-1-1-19-v14.12 GET SERVICES AND GET DEVICE SERVICE CAPABILITIES CONSISTENCY

DEVICE-1-1-30-v17.06 GET SERVICES AND GET CAPABILITIES CONSISTENCY

DEVICE-1-1-31-v18.12 GET SERVICES - XADDR

DEVICE-2-1-1-v14.12 NETWORK COMMAND HOSTNAME CONFIGURATION

DEVICE-2-1-3-v14.12 NETWORK COMMAND SETHOSTNAME TEST ERROR CASE

DEVICE-2-1-4-v14.12 GET DNS CONFIGURATION

DEVICE-2-1-5-v14.12 SET DNS CONFIGURATION - SEARCHDOMAIN

DEVICE-2-1-6-v14.12 SET DNS CONFIGURATION - DNSMANUAL IPV4

DEVICE-2-1-8-v14.12 SET DNS CONFIGURATION - FROMDHCP

DEVICE-2-1-11-v14.12 GET NTP CONFIGURATION

DEVICE-2-1-12-v16.07 SET NTP CONFIGURATION - NTPMANUAL IPV4

DEVICE-2-1-14-v14.12 SET NTP CONFIGURATION - FROMDHCP

DEVICE-2-1-17-v14.12 GET NETWORK INTERFACE CONFIGURATION

DEVICE-2-1-18-v14.12 SET NETWORK INTERFACE CONFIGURATION - IPV4

DEVICE-2-1-25-v14.12 GET NETWORK DEFAULT GATEWAY CONFIGURATION
DEVICE-2-1-30-v14.12 SET NETWORK DEFAULT GATEWAY CONFIGURATION - IPV4
DEVICE-2-1-32-v14.12 NETWORK COMMAND SETHOSTNAME TEST
DEVICE-2-1-33-v14.12 GET NETWORK PROTOCOLS CONFIGURATION
DEVICE-2-1-34-v14.12 SET NETWORK PROTOCOLS CONFIGURATION
DEVICE-2-1-35-v14.12 SET NETWORK PROTOCOLS CONFIGURATION - UNSUPPORTED PROTOCOLS
DEVICE-3-1-1-v14.12 SYSTEM COMMAND GETSYSTEMDATEANDTIME
DEVICE-3-1-4-v19.06 SYSTEM COMMAND SETSYSTEMDATEANDTIME TEST FOR INVALID TIMEZONE
DEVICE-3-1-5-v19.06 SYSTEM COMMAND SETSYSTEMDATEANDTIME TEST FOR INVALID DATE
DEVICE-3-1-7-v14.12 SYSTEM COMMAND FACTORY DEFAULT SOFT
DEVICE-3-1-8-v16.01 SYSTEM COMMAND REBOOT
DEVICE-3-1-9-v14.12 SYSTEM COMMAND DEVICE INFORMATION
DEVICE-3-1-11-v19.06 SYSTEM COMMAND SETSYSTEMDATEANDTIME
DEVICE-3-1-12-v19.06 SYSTEM COMMAND SETSYSTEMDATEANDTIME USING NTP
DEVICE-4-1-1-v14.12 SECURITY COMMAND GETUSERS
DEVICE-4-1-3-v14.12 SECURITY COMMAND CREATEUSERS ERROR CASE
DEVICE-4-1-4-v14.12 SECURITY COMMAND DELETEUSERS
DEVICE-4-1-5-v14.12 SECURITY COMMAND DELETEUSERS ERROR CASE
DEVICE-4-1-7-v14.12 SECURITY COMMAND SETUSER
DEVICE-4-1-8-v14.12 SECURITY COMMAND USER MANAGEMENT ERROR CASE
DEVICE-4-1-9-v14.12 SECURITY COMMAND CREATEUSERS
DEVICE-6-1-1-v14.12 DEVICE MANAGEMENT - NAMESPACES (DEFAULT NAMESPACES FOR EACH TAG)
DEVICE-6-1-2-v14.12 DEVICE MANAGEMENT - NAMESPACES (DEFAULT NAMESPACES FOR PARENT TAG)
DEVICE-6-1-3-v14.12 DEVICE MANAGEMENT - NAMESPACES (NOT STANDARD PREFIXES)
DEVICE-6-1-4-v14.12 DEVICE MANAGEMENT - NAMESPACES (DIFFERENT PREFIXES FOR THE SAME NAMESPACE)
DEVICE-6-1-5-v14.12 DEVICE MANAGEMENT - NAMESPACES (THE SAME PREFIX FOR DIFFERENT NAMESPACES)
DEVICE-8-1-1-v17.01 AUXILIARY COMMANDS
EVENT-1-1-2-v19.06 GET EVENT PROPERTIES

EVENT-2-1-9-v14.12 BASIC NOTIFICATION INTERFACE - SUBSCRIBE
EVENT-2-1-12-v14.12 BASIC NOTIFICATION INTERFACE - RENEW
EVENT-2-1-17-v14.12 BASIC NOTIFICATION INTERFACE - NOTIFY
EVENT-2-1-18-v14.12 BASIC NOTIFICATION INTERFACE - NOTIFY FILTER
EVENT-2-1-24-v17.06 BASIC NOTIFICATION INTERFACE - SET SYNCHRONIZATION POINT
EVENT-2-1-25-v17.06 BASIC NOTIFICATION INTERFACE – CONJUNCTION IN NOTIFY FILTER
(OR OPERATION)
EVENT-2-1-26-v17.06 BASIC NOTIFICATION INTERFACE – TOPIC SUB-TREE IN
PULLMESSAGES FILTER
EVENT-2-1-27-v17.06 BASIC NOTIFICATION INTERFACE – CONJUNCTION IN NOTIFY FILTER
(TOPIC SUB-TREE AND OR OPERATION)
EVENT-2-1-28-v17.12 BASIC NOTIFICATION INTERFACE - UNSUBSCRIBE
EVENT-2-1-29-v18.06 BASIC NOTIFICATION INTERFACE - MESSAGE CONTENT FILTER
EVENT-3-1-9-v14.12 REALTIME PULLPOINT SUBSCRIPTION - CREATE PULL POINT
SUBSCRIPTION
EVENT-3-1-12-v17.12 REALTIME PULLPOINT SUBSCRIPTION - RENEW
EVENT-3-1-15-v14.12 REALTIME PULLPOINT SUBSCRIPTION - PULLMESSAGES
EVENT-3-1-16-v14.12 REALTIME PULLPOINT SUBSCRIPTION - PULLMESSAGES FILTER
EVENT-3-1-24-v14.12 REALTIME PULLPOINT SUBSCRIPTION – PULLMESSAGES AS KEEP-
ALIVE
EVENT-3-1-25-v17.06 REALTIME PULLPOINT SUBSCRIPTION – SET SYNCHRONIZATION POINT
EVENT-3-1-32-v17.06 REALTIME PULLPOINT SUBSCRIPTION – PULLMESSAGES TIMEOUT
EVENT-3-1-33-v18.06 REALTIME PULLPOINT SUBSCRIPTION – CONJUNCTION IN
PULLMESSAGES FILTER (OR OPERATION)
EVENT-3-1-34-v18.06 REALTIME PULLPOINT SUBSCRIPTION – TOPIC SUB-TREE IN
PULLMESSAGES FILTER
EVENT-3-1-35-v18.06 REALTIME PULLPOINT SUBSCRIPTION – CONJUNCTION IN NOTIFY
FILTER (TOPIC SUB-TREE AND OR OPERATION)
EVENT-3-1-36-v17.12 REALTIME PULLPOINT SUBSCRIPTION - UNSUBSCRIBE
EVENT-3-1-37-v17.12 REALTIME PULLPOINT SUBSCRIPTION – MAXIMUM SUPPORTED
NUMBER OF NOTIFICATION PULL POINTS
EVENT-3-1-38-v18.06 REALTIME PULLPOINT SUBSCRIPTION - MESSAGE CONTENT FILTER
EVENT-4-1-6-v16.07 EVENT - NAMESPACES (DEFAULT NAMESPACES FOR EACH TAG)
EVENT-4-1-7-v16.07 EVENT - NAMESPACES (DEFAULT NAMESPACES FOR PARENT TAG)
EVENT-4-1-8-v16.07 EVENT - NAMESPACES (NOT STANDARD PREFIXES)

EVENT-4-1-9-v16.07 EVENT - NAMESPACES (DIFFERENT PREFIXES FOR THE SAME NAMESPACE)

EVENT-4-1-10-v16.07 EVENT - NAMESPACES (THE SAME PREFIX FOR DIFFERENT NAMESPACES)

EVENT-5-1-1-v15.06 EVENT SERVICE CAPABILITIES

EVENT-5-1-2-v15.06 GET SERVICES AND EVENT SERVICE CAPABILITIES CONSISTENCY

ONVIF TEST

Media Configuration

MEDIA-1-1-1-v14.12 MEDIA PROFILE CONFIGURATION

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting media profiles

STEP PASSED

STEP 4 - Validating media profiles

STEP PASSED

TEST PASSED

MEDIA-1-1-3-v14.12 PROFILES CONSISTENCY

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting media profiles

STEP PASSED

STEP 4 - Check if the DUT returned media profiles

STEP PASSED

STEP 5 - Getting media profile

STEP PASSED

STEP 6 - Check that profiles [token = 'profile1'] are the same

STEP PASSED

TEST PASSED

MEDIA-1-1-5-v19.12 DYNAMIC MEDIA PROFILE CONFIGURATION

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting media profiles

STEP PASSED

STEP 4 - Check the DUT returned at least one profile with video configuration

STEP PASSED

STEP 5 - Creating media profile [name = 'testMedia']

STEP PASSED

STEP 6 - Check the DUT returned an empty profile with no profile entities

STEP PASSED

STEP 7 - Check the DUT returned profile with @fixed = false

STEP PASSED

STEP 8 - Getting video source configurations

STEP PASSED

STEP 9 - Adding video source configuration [token = 'vsrc1'] to profile [token = 'profile2']

STEP PASSED

STEP 10 - Getting media profile

STEP PASSED

STEP 11 - Check the DUT returned profile with token = profile2

STEP PASSED

STEP 12 - Check the DUT returned profile with Video Source configuration token = vsrc1

STEP PASSED

STEP 13 - Getting video encoder configurations compatible with profile [token = 'profile2']

STEP PASSED

STEP 14 - Check that the DUT returned at least one Video Encoder configuration

STEP PASSED

STEP 15 - Adding video encoder configuration [token = 'venc1'] to profile [token = 'profile2']

STEP PASSED

STEP 16 - Getting media profile

STEP PASSED

STEP 17 - Check the DUT returned profile with token = profile2

STEP PASSED

STEP 18 - Check the DUT returned profile with Video Source configuration token = vsrc1

STEP PASSED

STEP 19 - Check the DUT returned profile with Video Encoder configuration token = venc1

STEP PASSED

STEP 20 - Removing video encoder configuration from profile [token = 'profile2']

STEP PASSED

STEP 21 - Getting media profile

STEP PASSED

STEP 22 - Check the DUT returned profile with token = profile2

STEP PASSED

STEP 23 - Check the DUT returned profile with Video Source configuration token = vsrc1

STEP PASSED

STEP 24 - Check the DUT returned profile without Video Encoder configuration

STEP PASSED

STEP 25 - Removing video source configuration from profile [token = 'profile2']

STEP PASSED

STEP 26 - Getting media profile

STEP PASSED

STEP 27 - Check the DUT returned profile with token = profile2

STEP PASSED

STEP 28 - Check the DUT returned profile without Video Source configuration

STEP PASSED

STEP 29 - Getting metadata configurations

STEP PASSED

STEP 30 - Getting audio source configurations

STEP PASSED

STEP 31 - Check that the DUT returned at least one Audio Source configuration

STEP PASSED

STEP 32 - Adding audio source configuration [token = 'asrc1'] to profile [token = 'profile2']

STEP PASSED

STEP 33 - Getting media profile

STEP PASSED

STEP 34 - Check the DUT returned profile with token = profile2

STEP PASSED

STEP 35 - Check the DUT returned profile with Audio Source configuration token = asrc1

STEP PASSED

STEP 36 - Getting audio encoder configurations compatible with profile [token = 'profile2']

STEP PASSED

STEP 37 - Check that the DUT returned at least one Audio Encoder configuration

STEP PASSED

STEP 38 - Adding audio encoder configuration [token = 'aenc1'] to profile [token = 'profile2']

STEP PASSED

STEP 39 - Getting media profile

STEP PASSED

STEP 40 - Check the DUT returned profile with token = profile2

STEP PASSED

STEP 41 - Check the DUT returned profile with Audio Source configuration token = asrc1

STEP PASSED

STEP 42 - Check the DUT returned profile with Audio Encoder configuration token = aenc1

STEP PASSED

STEP 43 - Removing audio encoder configuration from profile [token = 'profile2']

STEP PASSED

STEP 44 - Getting media profile

STEP PASSED

STEP 45 - Check the DUT returned profile with token = profile2

STEP PASSED

STEP 46 - Check the DUT returned profile with Audio Source configuration token = asrc1

STEP PASSED

STEP 47 - Check the DUT returned profile without Audio Encoder configuration

STEP PASSED

STEP 48 - Removing audio source configuration from profile [token = 'profile2']

STEP PASSED

STEP 49 - Getting media profile

STEP PASSED

STEP 50 - Check the DUT returned profile with token = profile2

STEP PASSED

STEP 51 - Check the DUT returned profile without Audio Source configuration

STEP PASSED

STEP 52 - Deleting media profile [token = 'profile2']

STEP PASSED

STEP 53 - Getting media profile

STEP PASSED

TEST PASSED

MEDIA-2-1-2-v14.12 VIDEO ENCODER CONFIGURATION

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting media profiles

STEP PASSED

STEP 4 - Validating media profiles

STEP PASSED

STEP 5 - Getting video encoder configurations compatible with profile [token = 'profile1']

STEP PASSED

STEP 6 - Validating video encoder configurations

STEP PASSED

STEP 7 - Getting video encoder configurations

STEP PASSED

STEP 8 - Validating video encoder configurations

STEP PASSED

TEST PASSED

MEDIA-2-1-6-v14.12 GUARANTEED NUMBER OF VIDEO ENCODER INSTANCES

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting video source configurations

STEP PASSED

STEP 4 - Validating video source configurations

STEP PASSED

STEP 5 - Getting guaranteed number of video encoder instances

STEP PASSED

STEP 6 - Validating guaranteed number of video encoder instances

STEP PASSED

TEST PASSED

MEDIA-2-1-7-v14.12 GET GUARANTEED NUMBER OF VIDEO ENCODER INSTANCES AND GET VIDEO ENCODER CONFIGURATION OPTIONS CONSISTENCY

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Get Media service capabilities from Device service

STEP PASSED

STEP 4 - Check that the DUT returned Media capabilities

STEP PASSED

STEP 5 - Get Media Service capabilities

STEP PASSED

STEP 6 - Check that the DUT returned Media service capabilities

STEP PASSED

STEP 7 - Getting video encoder configurations

STEP PASSED

STEP 8 - Validating video encoder configurations

STEP PASSED

STEP 9 - Getting video source configurations

STEP PASSED

STEP 10 - Validating video source configurations

STEP PASSED

STEP 11 - Getting guaranteed number of video encoder instances

STEP PASSED

STEP 12 - Compare guaranteed total number of video encoder instances and total number of video encoder configurations

STEP PASSED

STEP 13 - Compare guaranteed total number of video encoder instances and maximum number of profiles

STEP PASSED

STEP 14 - Get video encoder configuration options

STEP PASSED

STEP 15 - Check that JPEG options are present

STEP PASSED

STEP 16 - Check that H264 options are present

STEP PASSED

TEST PASSED

MEDIA-2-1-8-v14.12 VIDEO SOURCE CONFIGURATION

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting media profiles

STEP PASSED

STEP 4 - Validating media profiles

STEP PASSED

STEP 5 - Getting video sources

STEP PASSED

STEP 6 - Validating video sources

STEP PASSED

STEP 7 - Getting video source configurations compatible with profile [token = 'profile1']

STEP PASSED

STEP 8 - Validating video source configurations

STEP PASSED

STEP 9 - Getting video source configurations

STEP PASSED

STEP 10 - Validating video source configurations

STEP PASSED

STEP 11 - Getting video source configuration options for configuration [token = 'vsrc1']

STEP PASSED

STEP 12 - Setting video source configuration - negative test

STEP PASSED

STEP 13 - Setting video source configuration

STEP PASSED

STEP 14 - Getting video source configuration

STEP PASSED

STEP 15 - Comparing video source configurations

STEP PASSED

TEST PASSED

MEDIA-2-1-9-v14.12 JPEG VIDEO ENCODER CONFIGURATION

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting video encoder configurations

STEP PASSED

STEP 4 - Validating video encoder configurations

STEP PASSED

STEP 5 - Getting video encoder configuration options

STEP PASSED

STEP 6 - Setting video encoder configuration - negative test

STEP PASSED

STEP 7 - Find highest and lowest resolutions for further testing

STEP PASSED

STEP 8 - SetVideoEncoderConfiguration (use max values)

STEP PASSED

STEP 9 - Getting video encoder configuration

STEP PASSED

STEP 10 - Check that the DUT accepted values passed

STEP PASSED

STEP 11 - SetVideoEncoderConfiguration (use min values)

STEP PASSED

STEP 12 - Getting video encoder configuration

STEP PASSED

STEP 13 - Check that the DUT accepted values passed

STEP PASSED

STEP 14 - SetVideoEncoderConfiguration (use average values)

STEP PASSED

STEP 15 - Getting video encoder configuration

STEP PASSED

STEP 16 - Check that the DUT accepted values passed

STEP PASSED

STEP 17 - Setting video encoder configuration

STEP PASSED

TEST PASSED

MEDIA-2-1-11-v14.12 H.264 VIDEO ENCODER CONFIGURATION

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting video encoder configurations

STEP PASSED

STEP 4 - Validating video encoder configurations

STEP PASSED

STEP 5 - Getting video encoder configuration options

STEP PASSED

STEP 6 - Setting video encoder configuration - negative test

STEP PASSED

STEP 7 - Find highest and lowest resolutions for further testing

STEP PASSED

STEP 8 - SetVideoEncoderConfiguration (use max values)

STEP PASSED

STEP 9 - Getting video encoder configuration

STEP PASSED

STEP 10 - Check that the DUT accepted values passed

STEP PASSED

STEP 11 - SetVideoEncoderConfiguration (use min values)

STEP PASSED

STEP 12 - Getting video encoder configuration

STEP PASSED

STEP 13 - Check that the DUT accepted values passed

STEP PASSED

STEP 14 - SetVideoEncoderConfiguration (use average values)

STEP PASSED

STEP 15 - Getting video encoder configuration

STEP PASSED

STEP 16 - Check that the DUT accepted values passed

STEP PASSED

STEP 17 - Setting video encoder configuration

STEP PASSED

TEST PASSED

MEDIA-2-2-1-v14.12 VIDEO SOURCE CONFIGURATIONS AND PROFILES CONSISTENCY

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting media profiles

STEP PASSED

STEP 4 - Check if the DUT returned media profiles

STEP PASSED

STEP 5 - Getting video source configurations

STEP PASSED

STEP 6 - Check if the DUT returned configurations

STEP PASSED

STEP 7 - Check that video source configuration for profile with token 'profile1' exists

STEP PASSED

STEP 8 - Check that configurations [token = 'vsrc1'] are the same

STEP PASSED

TEST PASSED

MEDIA-2-2-2-v14.12 VIDEO SOURCE CONFIGURATIONS AND VIDEO SOURCE CONFIGURATION CONSISTENCY

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting video source configurations

STEP PASSED

STEP 4 - Check if the DUT returned configurations

STEP PASSED

STEP 5 - Getting video source configuration

STEP PASSED

STEP 6 - Check that configurations [token = 'vsrc1'] are the same

STEP PASSED

TEST PASSED

MEDIA-2-2-3-v14.12 VIDEO SOURCE CONFIGURATIONS AND VIDEO SOURCE CONFIGURATION OPTIONS CONSISTENCY

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting video source configurations

STEP PASSED

STEP 4 - Check if the DUT returned configurations

STEP PASSED

STEP 5 - Check if video source configuration is valid

STEP PASSED

STEP 6 - Getting video source configuration options for configuration [token = 'vsrc1']

STEP PASSED

STEP 7 - Check if the DUT returned video source configuration options

STEP PASSED

STEP 8 - Check if video source configuration options are valid

STEP PASSED

STEP 9 - Check if video source configuration [token='vsrc1'] and options are consistent

STEP PASSED

TEST PASSED

MEDIA-2-2-4-v14.12 PROFILES AND VIDEO SOURCE CONFIGURATION OPTIONS CONSISTENCY

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting media profiles

STEP PASSED

STEP 4 - Check if the DUT returned media profiles

STEP PASSED

STEP 5 - Getting video source configuration options for configuration [token = 'vsrc1']

STEP PASSED

STEP 6 - Check if the DUT returned video source configuration options

STEP PASSED

STEP 7 - Check if video source configuration [token='vsrc1'] and options are consistent

STEP PASSED

TEST PASSED

MEDIA-2-2-5-v14.12 VIDEO SOURCE CONFIGURATIONS AND VIDEO SOURCES CONSISTENCY

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting video source configurations

STEP PASSED

STEP 4 - Check if the DUT returned configurations

STEP PASSED

STEP 5 - Getting video sources

STEP PASSED

STEP 6 - Check if the DUT returned video sources

STEP PASSED

STEP 7 - Check if video source exists for configuration 'vsrc1'

STEP PASSED

TEST PASSED

MEDIA-2-2-6-v14.12 VIDEO SOURCE CONFIGURATION USE COUNT (CURRENT STATE)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting video source configurations

STEP PASSED

STEP 4 - Check if the DUT returned configurations

STEP PASSED

STEP 5 - Getting media profiles

STEP PASSED

STEP 6 - Check if the DUT returned media profiles

STEP PASSED

STEP 7 - Check condition

STEP PASSED

STEP 8 - Getting video source configuration

STEP PASSED

STEP 9 - Check UseCount value

STEP PASSED

TEST PASSED

MEDIA-2-2-12-v14.12 VIDEO SOURCE CONFIGURATION USE COUNT (ADD SAME VIDEO SOURCE CONFIGURATION TO PROFILE TWICE)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting video source configurations

STEP PASSED

STEP 4 - Check if the DUT returned configurations

STEP PASSED

STEP 5 - Getting media profiles

STEP PASSED

STEP 6 - Creating media profile [name = 'c']

STEP PASSED

STEP 7 - Adding video source configuration [token = 'vsrc1'] to profile [token = 'c']

STEP PASSED

STEP 8 - Getting video source configuration

STEP PASSED

STEP 9 - Check UseCount value after adding configuration to a profile

STEP PASSED

STEP 10 - Adding video source configuration [token = 'vsrc1'] to profile [token = 'c']

STEP PASSED

STEP 11 - Getting video source configuration

STEP PASSED

STEP 12 - Check UseCount value after adding the same configuration to a profile twice

STEP PASSED

STEP 13 - Deleting media profile [token = 'c']

STEP PASSED

TEST PASSED

MEDIA-2-2-13-v14.12 VIDEO SOURCE CONFIGURATION USE COUNT (ADD DIFFERENT VIDEO SOURCE CONFIGURATIONS IN PROFILE)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting video source configurations

STEP PASSED

STEP 4 - Check if the DUT returned video source configurations

STEP PASSED

TEST PASSED

MEDIA-2-2-14-v14.12 VIDEO SOURCE CONFIGURATION USE COUNT (REMOVE VIDEO SOURCE CONFIGURATION)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting video source configurations

STEP PASSED

STEP 4 - Check if the DUT returned configurations

STEP PASSED

STEP 5 - Getting media profiles

STEP PASSED

STEP 6 - Creating media profile [name = 'y']

STEP PASSED

STEP 7 - Adding video source configuration [token = 'vsrc1'] to profile [token = 'y']

STEP PASSED

STEP 8 - Removing video source configuration from profile [token = 'y']

STEP PASSED

STEP 9 - Getting video source configuration

STEP PASSED

STEP 10 - Check UseCount value after removing configuration from a profile

STEP PASSED

STEP 11 - Deleting media profile [token = 'y']

STEP PASSED

TEST PASSED

MEDIA-2-2-15-v17.06 VIDEO SOURCE CONFIGURATION USE COUNT (DELETION PROFILE WITH VIDEO SOURCE CONFIGURATION)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting video source configurations

STEP PASSED

STEP 4 - Check if the DUT returned configurations

STEP PASSED

STEP 5 - Getting media profiles

STEP PASSED

STEP 6 - Creating media profile [name = 'M']

STEP PASSED

STEP 7 - Adding video source configuration [token = 'vsrc1'] to profile [token = 'M']

STEP PASSED

STEP 8 - Deleting media profile [token = 'M']

STEP PASSED

STEP 9 - Getting video source configuration

STEP PASSED

STEP 10 - Check UseCount value after deleting profile with configuration

STEP PASSED

TEST PASSED

MEDIA-2-2-16-v14.12 VIDEO SOURCE CONFIGURATION USE COUNT (SET VIDEO SOURCE CONFIGURATION)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting video source configurations

STEP PASSED

STEP 4 - Check if the DUT returned configurations

STEP PASSED

STEP 5 - Setting video source configuration

STEP PASSED

STEP 6 - Getting video source configuration

STEP PASSED

STEP 7 - Check UseCount after setting new value via SetVideoSourceConfiguration

STEP PASSED

TEST PASSED

MEDIA-2-3-1-v14.12 VIDEO ENCODER CONFIGURATIONS AND PROFILES CONSISTENCY

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting media profiles

STEP PASSED

STEP 4 - Check if the DUT returned media profiles

STEP PASSED

STEP 5 - Getting video encoder configurations

STEP PASSED

STEP 6 - Check if the DUT returned configurations

STEP PASSED

STEP 7 - Check that video encoder configuration for profile with token 'profile1' exists

STEP PASSED

STEP 8 - Check that configurations [token = 'venc1'] are the same

STEP PASSED

TEST PASSED

MEDIA-2-3-2-v14.12 VIDEO ENCODER CONFIGURATIONS AND VIDEO ENCODER CONFIGURATION CONSISTENCY

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting video encoder configurations

STEP PASSED

STEP 4 - Check if the DUT returned configurations

STEP PASSED

STEP 5 - Getting video encoder configuration

STEP PASSED

STEP 6 - Check that configurations [token = 'venc1'] are the same

STEP PASSED

STEP 7 - Getting video encoder configuration

STEP PASSED

STEP 8 - Check that configurations [token = 'venc2'] are the same

STEP PASSED

STEP 9 - Getting video encoder configuration

STEP PASSED

STEP 10 - Check that configurations [token = 'venc3'] are the same

STEP PASSED

TEST PASSED

MEDIA-2-3-3-v14.12 VIDEO ENCODER CONFIGURATIONS AND VIDEO ENCODER CONFIGURATION OPTIONS CONSISTENCY

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting video encoder configurations

STEP PASSED

STEP 4 - Check if the DUT returned configurations

STEP PASSED

STEP 5 - Check if video encoder configuration is valid

STEP PASSED

STEP 6 - Get video encoder configuration options

STEP PASSED

STEP 7 - Check if the DUT returned video encoder configuration options

STEP PASSED

STEP 8 - Check if video encoder configuration [token='venc1'] and options are consistent

STEP PASSED

STEP 9 - Check if video encoder configuration is valid

STEP PASSED

STEP 10 - Get video encoder configuration options

STEP PASSED

STEP 11 - Check if the DUT returned video encoder configuration options

STEP PASSED

STEP 12 - Check if video encoder configuration [token='venc2'] and options are consistent

STEP PASSED

STEP 13 - Check if video encoder configuration is valid

STEP PASSED

STEP 14 - Get video encoder configuration options

STEP PASSED

STEP 15 - Check if the DUT returned video encoder configuration options

STEP PASSED

STEP 16 - Check if video encoder configuration [token='venc3'] and options are consistent

STEP PASSED

TEST PASSED

MEDIA-2-3-4-v14.12 PROFILES AND VIDEO ENCODER CONFIGURATION OPTIONS CONSISTENCY

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting media profiles

STEP PASSED

STEP 4 - Check if the DUT returned media profiles

STEP PASSED

STEP 5 - Get video encoder configuration options

STEP PASSED

STEP 6 - Check if the DUT returned video encoder configuration options

STEP PASSED

STEP 7 - Check if video encoder configuration [token='venc1'] and options are consistent

STEP PASSED

TEST PASSED

MEDIA-2-3-5-v14.12 VIDEO ENCODER CONFIGURATION USE COUNT (CURRENT STATE)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting video encoder configurations

STEP PASSED

STEP 4 - Check if the DUT returned configurations

STEP PASSED

STEP 5 - Getting media profiles

STEP PASSED

STEP 6 - Check if the DUT returned media profiles

STEP PASSED

STEP 7 - Check condition

STEP PASSED

STEP 8 - Getting video encoder configuration

STEP PASSED

STEP 9 - Check UseCount value

STEP PASSED

STEP 10 - Check condition

STEP PASSED

STEP 11 - Getting video encoder configuration

STEP PASSED

STEP 12 - Check UseCount value

STEP PASSED

STEP 13 - Check condition

STEP PASSED

STEP 14 - Getting video encoder configuration

STEP PASSED

STEP 15 - Check UseCount value

STEP PASSED

TEST PASSED

MEDIA-2-3-12-v14.12 VIDEO ENCODER CONFIGURATIONS – ALL SUPPORTED VIDEO ENCODINGS

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting video encoder configurations

STEP PASSED

STEP 4 - Check if the DUT returned configurations

STEP PASSED

STEP 5 - Get video encoder configuration options

STEP PASSED

STEP 6 - Setting video encoder configuration

STEP PASSED

STEP 7 - Getting video encoder configuration

STEP PASSED

STEP 8 - Check that the DUT accepted values passed

STEP PASSED

STEP 9 - Setting video encoder configuration

STEP PASSED

STEP 10 - Getting video encoder configuration

STEP PASSED

STEP 11 - Check that the DUT accepted values passed

STEP PASSED

STEP 12 - Get video encoder configuration options

STEP PASSED

STEP 13 - Setting video encoder configuration

STEP PASSED

STEP 14 - Getting video encoder configuration

STEP PASSED

STEP 15 - Check that the DUT accepted values passed

STEP PASSED

STEP 16 - Setting video encoder configuration

STEP PASSED

STEP 17 - Getting video encoder configuration

STEP PASSED

STEP 18 - Check that the DUT accepted values passed

STEP PASSED

STEP 19 - Get video encoder configuration options

STEP PASSED

STEP 20 - Setting video encoder configuration

STEP PASSED

STEP 21 - Getting video encoder configuration

STEP PASSED

STEP 22 - Check that the DUT accepted values passed

STEP PASSED

STEP 23 - Setting video encoder configuration

STEP PASSED

STEP 24 - Getting video encoder configuration

STEP PASSED

STEP 25 - Check that the DUT accepted values passed

STEP PASSED

STEP 26 - SetVideoEncoderConfiguration - rollback changes made in configuration 'venc1'

STEP PASSED

STEP 27 - SetVideoEncoderConfiguration - rollback changes made in configuration 'venc2'

STEP PASSED

STEP 28 - SetVideoEncoderConfiguration - rollback changes made in configuration 'venc3'

STEP PASSED

TEST PASSED

MEDIA-2-3-13-v14.12 VIDEO ENCODER CONFIGURATION USE COUNT (ADD SAME VIDEO ENCODER CONFIGURATION TO PROFILE TWICE)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting video encoder configurations

STEP PASSED

STEP 4 - Check if the DUT returned video encoder configurations

STEP PASSED

STEP 5 - Getting video source configurations

STEP PASSED

STEP 6 - Check if the DUT returned video source configurations

STEP PASSED

STEP 7 - Getting media profiles

STEP PASSED

STEP 8 - Creating media profile [name = '1']

STEP PASSED

STEP 9 - Getting video source configurations compatible with profile [token = '1']

STEP PASSED

STEP 10 - Adding video source configuration [token = 'vsrc1'] to profile [token = '1']

STEP PASSED

STEP 11 - Getting video encoder configurations compatible with profile [token = '1']

STEP PASSED

STEP 12 - Adding video encoder configuration [token = 'venc1'] to profile [token = '1']

STEP PASSED

STEP 13 - Getting video encoder configuration

STEP PASSED

STEP 14 - Check UseCount value after adding configuration to a profile

STEP PASSED

STEP 15 - Adding video encoder configuration [token = 'venc1'] to profile [token = '1']

STEP PASSED

STEP 16 - Getting video encoder configuration

STEP PASSED

STEP 17 - Check UseCount value after adding the same configuration to a profile twice

STEP PASSED

STEP 18 - Deleting media profile [token = '1']

STEP PASSED

TEST PASSED

MEDIA-2-3-14-v14.12 VIDEO ENCODER CONFIGURATION USE COUNT (ADD DIFFERENT VIDEO ENCODER CONFIGURATIONS IN PROFILE)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting video encoder configurations

STEP PASSED

STEP 4 - Check if the DUT returned video encoder configurations

STEP PASSED

STEP 5 - Getting video source configurations

STEP PASSED

STEP 6 - Check if the DUT returned video source configurations

STEP PASSED

STEP 7 - Getting media profiles

STEP PASSED

STEP 8 - Creating media profile [name = 'U']

STEP PASSED

STEP 9 - Getting video source configurations compatible with profile [token = 'U']

STEP PASSED

STEP 10 - Adding video source configuration [token = 'vsrc1'] to profile [token = 'U']

STEP PASSED

STEP 11 - Getting video encoder configurations compatible with profile [token = 'U']

STEP PASSED

STEP 12 - Adding video encoder configuration [token = 'venc1'] to profile [token = 'U']

STEP PASSED

STEP 13 - Getting video encoder configuration

STEP PASSED

STEP 14 - Check UseCount value after adding configuration to a profile

STEP PASSED

STEP 15 - Adding video encoder configuration [token = 'venc2'] to profile [token = 'U']

STEP PASSED

STEP 16 - Getting video encoder configuration

STEP PASSED

STEP 17 - Check UseCount value after replacing configuration in a profile (for replaced configuration)

STEP PASSED

STEP 18 - Getting video encoder configuration

STEP PASSED

STEP 19 - Check UseCount value after adding configuration to a profile (for added configuration)

STEP PASSED

STEP 20 - Deleting media profile [token = 'U']

STEP PASSED

TEST PASSED

MEDIA-2-3-15-v14.12 VIDEO ENCODER CONFIGURATION USE COUNT (REMOVE VIDEO ENCODER CONFIGURATION)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting video encoder configurations

STEP PASSED

STEP 4 - Check if the DUT returned video encoder configurations

STEP PASSED

STEP 5 - Getting video source configurations

STEP PASSED

STEP 6 - Check if the DUT returned video source configurations

STEP PASSED

STEP 7 - Getting media profiles

STEP PASSED

STEP 8 - Creating media profile [name = 'q']

STEP PASSED

STEP 9 - Getting video source configurations compatible with profile [token = 'q']

STEP PASSED

STEP 10 - Adding video source configuration [token = 'vsrc1'] to profile [token = 'q']

STEP PASSED

STEP 11 - Getting video encoder configurations compatible with profile [token = 'q']

STEP PASSED

STEP 12 - Adding video encoder configuration [token = 'venc1'] to profile [token = 'q']

STEP PASSED

STEP 13 - Removing video encoder configuration from profile [token = 'q']

STEP PASSED

STEP 14 - Getting video encoder configuration

STEP PASSED

STEP 15 - Check UseCount value after removing configuration from a profile

STEP PASSED

STEP 16 - Deleting media profile [token = 'q']

STEP PASSED

TEST PASSED

MEDIA-2-3-16-v17.06 VIDEO ENCODER CONFIGURATION USE COUNT (PROFILE DELETION WITH VIDEO ENCODER CONFIGURATION)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting video encoder configurations

STEP PASSED

STEP 4 - Check if the DUT returned video encoder configurations

STEP PASSED

STEP 5 - Getting video source configurations

STEP PASSED

STEP 6 - Check if the DUT returned video source configurations

STEP PASSED

STEP 7 - Getting media profiles

STEP PASSED

STEP 8 - Creating media profile [name = 'Q']

STEP PASSED

STEP 9 - Getting video source configurations compatible with profile [token = 'Q']

STEP PASSED

STEP 10 - Adding video source configuration [token = 'vsrc1'] to profile [token = 'Q']

STEP PASSED

STEP 11 - Getting video encoder configurations compatible with profile [token = 'Q']

STEP PASSED

STEP 12 - Adding video encoder configuration [token = 'venc1'] to profile [token = 'Q']

STEP PASSED

STEP 13 - Deleting media profile [token = 'Q']

STEP PASSED

STEP 14 - Getting video encoder configuration

STEP PASSED

STEP 15 - Check UseCount value after deleting profile with configuration

STEP PASSED

TEST PASSED

MEDIA-2-3-17-v14.12 VIDEO ENCODER CONFIGURATION USE COUNT (SET VIDEO ENCODER CONFIGURATION)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting video encoder configurations

STEP PASSED

STEP 4 - Check if the DUT returned configurations

STEP PASSED

STEP 5 - Setting video encoder configuration

STEP PASSED

STEP 6 - Getting video encoder configuration

STEP PASSED

STEP 7 - Check UseCount after setting new value via SetVideoEncoderConfiguration

STEP PASSED

TEST PASSED

MEDIA-3-1-7-v19.12 GET AUDIO SOURCE CONFIGURATION OPTIONS

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Get Audio source configuration options (empty message)

STEP PASSED

STEP 4 - Getting media profiles

STEP PASSED

STEP 5 - Check if the DUT returned media profiles

STEP PASSED

STEP 6 - Getting audio source configurations compatible with profile [token = 'profile1']

STEP PASSED

STEP 7 - Get Audio source configuration options for configuration [token='asrc1']

STEP PASSED

STEP 8 - Get Audio source configuration options for profile [token='profile1']

STEP PASSED

STEP 9 - Get Audio source configuration options for configuration [token='asrc1'] and profile [token = 'profile1']

STEP PASSED

TEST PASSED

MEDIA-3-1-14-v14.12 G.711 AUDIO ENCODER CONFIGURATION

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting audio encoder configurations

STEP PASSED

STEP 4 - Validating audio encoder configurations

STEP PASSED

STEP 5 - Getting audio encoder configuration options

STEP PASSED

STEP 6 - Setting audio encoder configuration - negative test

STEP PASSED

STEP 7 - Setting audio encoder configuration

STEP PASSED

STEP 8 - Getting audio encoder configuration

STEP PASSED

STEP 9 - Comparing audio encoder configurations

STEP PASSED

TEST PASSED

MEDIA-3-1-16-v14.12 AAC AUDIO ENCODER CONFIGURATION

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting audio encoder configurations

STEP PASSED

STEP 4 - Validating audio encoder configurations

STEP PASSED

STEP 5 - Getting audio encoder configuration options

STEP PASSED

STEP 6 - Setting audio encoder configuration - negative test

STEP PASSED

STEP 7 - Setting audio encoder configuration

STEP PASSED

STEP 8 - Getting audio encoder configuration

STEP PASSED

STEP 9 - Comparing audio encoder configurations

STEP PASSED

TEST PASSED

MEDIA-3-1-17-v14.12 GET AUDIO SOURCE CONFIGURATION – INVALID CONFIGURATIONTOKEN

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting audio source configurations

STEP PASSED

STEP 4 - Check if the DUT returned audio source configurations

STEP PASSED

STEP 5 - Get audio source configuration - negative test

STEP PASSED

TEST PASSED

MEDIA-3-1-18-v14.12 GET AUDIO SOURCE CONFIGURATION OPTIONS – INVALID PROFILETOKEN

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting media profiles

STEP PASSED

STEP 4 - Check if the DUT returned media profiles

STEP PASSED

STEP 5 - Get audio source configuration options - negative test

STEP PASSED

TEST PASSED

MEDIA-3-1-19-v14.12 GET AUDIO SOURCE CONFIGURATION OPTIONS – INVALID CONFIGURATION TOKEN

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting audio source configurations

STEP PASSED

STEP 4 - Check if the DUT returned configurations

STEP PASSED

STEP 5 - Get audio source configuration options - negative test

STEP PASSED

TEST PASSED

MEDIA-3-1-20-v14.12 SET AUDIO SOURCE CONFIGURATION – INVALID TOKEN

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting audio source configurations

STEP PASSED

STEP 4 - Check if the DUT returned configurations

STEP PASSED

STEP 5 - Set audio source configuration - negative test

STEP PASSED

TEST PASSED

MEDIA-3-1-21-v14.12 SET AUDIO ENCODER CONFIGURATION

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Create profile

STEP PASSED

STEP 4 - Validate new media profile

STEP PASSED

STEP 5 - Getting audio source configurations compatible with profile [token = 'profile2']

STEP PASSED

STEP 6 - Validating audio sources

STEP PASSED

STEP 7 - Adding audio source configuration [token = 'asrc1'] to profile [token = 'profile2']

STEP PASSED

STEP 8 - Getting audio encoder configurations compatible with profile [token = 'profile2']

STEP PASSED

STEP 9 - Validating audio encoder configurations

STEP PASSED

STEP 10 - Adding audio encoder configuration [token = 'aenc1'] to profile [token = 'profile2']

STEP PASSED

STEP 11 - Get audio encoder configuration options

STEP PASSED

STEP 12 - Validate response received

STEP PASSED

STEP 13 - Select AudioEncoderConfigurationOption to check configuration changing

STEP PASSED

STEP 14 - Setting audio encoder configuration

STEP PASSED

STEP 15 - Getting audio encoder configuration

STEP PASSED

STEP 16 - Comparing audio encoder configurations

STEP PASSED

STEP 17 - Setting audio encoder configuration

STEP PASSED

STEP 18 - Deleting media profile [token = 'profile2']

STEP PASSED

TEST PASSED

MEDIA-3-1-22-v14.12 AUDIO SOURCE CONFIGURATION

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Create profile

STEP PASSED

STEP 4 - Validate new media profile

STEP PASSED

STEP 5 - Validate new media profile

STEP PASSED

STEP 6 - Getting audio sources

STEP PASSED

STEP 7 - Validating audio sources

STEP PASSED

STEP 8 - Getting audio source configurations

STEP PASSED

STEP 9 - Validating audio sources

STEP PASSED

STEP 10 - Getting audio source configurations compatible with profile [token = 'profile2']

STEP PASSED

STEP 11 - Validating audio sources

STEP PASSED

STEP 12 - Adding audio source configuration [token = 'asrc1'] to profile [token = 'profile2']

STEP PASSED

STEP 13 - Getting audio source configuration options for configuration [token = 'asrc1']

STEP PASSED

STEP 14 - Setting audio source configuration - negative test

STEP PASSED

STEP 15 - Setting audio source configuration

STEP PASSED

STEP 16 - Getting audio source configuration

STEP PASSED

STEP 17 - Comparing audio source configurations

STEP PASSED

STEP 18 - Removing audio source configuration from profile [token = 'profile2']

STEP PASSED

STEP 19 - Deleting media profile [token = 'profile2']

STEP PASSED

TEST PASSED

MEDIA-3-1-23-v14.12 AUDIO ENCODER CONFIGURATION

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Create profile

STEP PASSED

STEP 4 - Validate new media profile

STEP PASSED

STEP 5 - Validate new media profile

STEP PASSED

STEP 6 - Getting audio source configurations

STEP PASSED

STEP 7 - Validating audio sources

STEP PASSED

STEP 8 - Adding audio source configuration [token = 'asrc1'] to profile [token = 'profile2']

STEP PASSED

STEP 9 - Getting audio encoder configurations

STEP PASSED

STEP 10 - Validating audio encoder configurations

STEP PASSED

STEP 11 - Getting audio encoder configurations compatible with profile [token = 'profile2']

STEP PASSED

STEP 12 - Validating audio encoder configurations

STEP PASSED

STEP 13 - Adding audio encoder configuration [token = 'aenc1'] to profile [token = 'profile2']

STEP PASSED

STEP 14 - Removing audio encoder configuration from profile [token = 'profile2']

STEP PASSED

STEP 15 - Removing audio source configuration from profile [token = 'profile2']

STEP PASSED

STEP 16 - Deleting media profile [token = 'profile2']

STEP PASSED

TEST PASSED

MEDIA-3-2-1-v14.12 AUDIO SOURCE CONFIGURATIONS AND PROFILES CONSISTENCY

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting media profiles

STEP PASSED

STEP 4 - Check if the DUT returned media profiles

STEP PASSED

STEP 5 - Getting audio source configurations

STEP PASSED

STEP 6 - Check if the DUT returned configurations

STEP PASSED

STEP 7 - Check that audio source configuration for profile with token 'profile1' exists

STEP PASSED

STEP 8 - Check that configurations [token = 'asrc1'] are the same

STEP PASSED

TEST PASSED

MEDIA-3-2-2-v14.12 AUDIO SOURCE CONFIGURATIONS AND AUDIO SOURCE CONFIGURATION CONSISTENCY

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting audio source configurations

STEP PASSED

STEP 4 - Check if the DUT returned configurations

STEP PASSED

STEP 5 - Getting audio source configuration

STEP PASSED

STEP 6 - Check that configurations [token = 'asrc1'] are the same

STEP PASSED

TEST PASSED

MEDIA-3-2-3-v14.12 AUDIO SOURCE CONFIGURATIONS AND AUDIO SOURCE CONFIGURATION OPTIONS CONSISTENCY

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting audio source configurations

STEP PASSED

STEP 4 - Check if the DUT returned configurations

STEP PASSED

STEP 5 - Getting audio source configuration options for configuration [token = 'asrc1']

STEP PASSED

STEP 6 - Check if the DUT returned audio source configuration options

STEP PASSED

STEP 7 - Check if the DUT returned available input tokens

STEP PASSED

STEP 8 - Check that input tokens listed are unique

STEP PASSED

STEP 9 - Check that InputTokensAvailable contains SourceToken

STEP PASSED

TEST PASSED

MEDIA-3-2-4-v14.12 PROFILES AND AUDIO SOURCE CONFIGURATION OPTIONS CONSISTENCY

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting media profiles

STEP PASSED

STEP 4 - Check if the DUT returned media profiles

STEP PASSED

STEP 5 - Getting audio source configuration options for configuration [token = 'asrc1']

STEP PASSED

STEP 6 - Check that the DUT sent audio source configuration options

STEP PASSED

STEP 7 - Check that input tokens list is not empty

STEP PASSED

STEP 8 - Check that input tokens listed are unique

STEP PASSED

STEP 9 - Check that source token is presented in the list of available input tokens

STEP PASSED

TEST PASSED

MEDIA-3-2-5-v14.12 AUDIO SOURCE CONFIGURATIONS AND AUDIO SOURCES CONSISTENCY

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting audio source configurations

STEP PASSED

STEP 4 - Check if the DUT returned configurations

STEP PASSED

STEP 5 - Getting audio sources

STEP PASSED

STEP 6 - Check if the DUT returned audio sources

STEP PASSED

STEP 7 - Check that SourceToken for configuration 'asrc1' exists

STEP PASSED

TEST PASSED

MEDIA-3-2-6-v14.12 AUDIO SOURCE CONFIGURATION USE COUNT (CURRENT STATE)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting audio source configurations

STEP PASSED

STEP 4 - Check if the DUT returned configurations

STEP PASSED

STEP 5 - Getting media profiles

STEP PASSED

STEP 6 - Check if the DUT returned media profiles

STEP PASSED

STEP 7 - Check condition

STEP PASSED

STEP 8 - Getting audio source configuration

STEP PASSED

STEP 9 - Check UseCount value

STEP PASSED

TEST PASSED

MEDIA-3-2-12-v14.12 AUDIO SOURCE CONFIGURATION USE COUNT (ADD SAME AUDIO SOURCE CONFIGURATION TO PROFILE TWICE)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting audio source configurations

STEP PASSED

STEP 4 - Check if the DUT returned configurations

STEP PASSED

STEP 5 - Getting media profiles

STEP PASSED

STEP 6 - Creating media profile [name = 'Y']

STEP PASSED

STEP 7 - Adding audio source configuration [token = 'asrc1'] to profile [token = 'Y']

STEP PASSED

STEP 8 - Getting audio source configuration

STEP PASSED

STEP 9 - Check UseCount value after adding configuration to a profile

STEP PASSED

STEP 10 - Adding audio source configuration [token = 'asrc1'] to profile [token = 'Y']

STEP PASSED

STEP 11 - Getting audio source configuration

STEP PASSED

STEP 12 - Check UseCount value after adding the same configuration to a profile twice

STEP PASSED

STEP 13 - Deleting media profile [token = 'Y']

STEP PASSED

TEST PASSED

MEDIA-3-2-13-v14.12 AUDIO SOURCE CONFIGURATION USE COUNT (ADD DIFFERENT AUDIO SOURCE CONFIGURATIONS IN PROFILE)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting audio source configurations

STEP PASSED

STEP 4 - Check if the DUT returned audio source configurations

STEP PASSED

TEST PASSED

MEDIA-3-2-14-v14.12 AUDIO SOURCE CONFIGURATION USE COUNT (REMOVE AUDIO SOURCE CONFIGURATION)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting audio source configurations

STEP PASSED

STEP 4 - Check if the DUT returned configurations

STEP PASSED

STEP 5 - Getting media profiles

STEP PASSED

STEP 6 - Creating media profile [name = 'J']

STEP PASSED

STEP 7 - Adding audio source configuration [token = 'asrc1'] to profile [token = 'J']

STEP PASSED

STEP 8 - Removing audio source configuration from profile [token = 'J']

STEP PASSED

STEP 9 - Getting audio source configuration

STEP PASSED

STEP 10 - Check UseCount value after removing configuration from a profile

STEP PASSED

STEP 11 - Deleting media profile [token = 'J']

STEP PASSED

TEST PASSED

MEDIA-3-2-15-v17.06 AUDIO SOURCE CONFIGURATION USE COUNT (PROFILE DELETION WITH AUDIO SOURCE CONFIGURATION)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting audio source configurations

STEP PASSED

STEP 4 - Check if the DUT returned configurations

STEP PASSED

STEP 5 - Getting media profiles

STEP PASSED

STEP 6 - Creating media profile [name = 'P']

STEP PASSED

STEP 7 - Adding audio source configuration [token = 'asrc1'] to profile [token = 'P']

STEP PASSED

STEP 8 - Deleting media profile [token = 'P']

STEP PASSED

STEP 9 - Getting audio source configuration

STEP PASSED

STEP 10 - Check UseCount value after deleting profile with configuration

STEP PASSED

TEST PASSED

MEDIA-3-2-16-v14.12 AUDIO SOURCE CONFIGURATION USE COUNT (SET AUDIO SOURCE CONFIGURATION)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting audio source configurations

STEP PASSED

STEP 4 - Check if the DUT returned configurations

STEP PASSED

STEP 5 - Setting audio source configuration

STEP PASSED

STEP 6 - Getting audio source configuration

STEP PASSED

STEP 7 - Check UseCount after setting new value via SetAudioSourceConfiguration

STEP PASSED

TEST PASSED

MEDIA-3-3-1-v14.12 AUDIO ENCODER CONFIGURATIONS AND PROFILES CONSISTENCY

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting media profiles

STEP PASSED

STEP 4 - Check if the DUT returned media profiles

STEP PASSED

STEP 5 - Getting audio encoder configurations

STEP PASSED

STEP 6 - Check if the DUT returned configurations

STEP PASSED

STEP 7 - Check that audio encoder configuration for profile with token 'profile1' exists

STEP PASSED

STEP 8 - Check that configurations [token = 'aenc1'] are the same

STEP PASSED

TEST PASSED

MEDIA-3-3-2-v14.12 AUDIO ENCODER CONFIGURATIONS AND AUDIO ENCODER CONFIGURATION CONSISTENCY

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting audio encoder configurations

STEP PASSED

STEP 4 - Check if the DUT returned configurations

STEP PASSED

STEP 5 - Getting audio encoder configuration

STEP PASSED

STEP 6 - Check that configurations [token = 'aenc1'] are the same

STEP PASSED

TEST PASSED

MEDIA-3-3-3-v14.12 AUDIO ENCODER CONFIGURATIONS AND AUDIO ENCODER CONFIGURATION OPTIONS CONSISTENCY

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting audio encoder configurations

STEP PASSED

STEP 4 - Check if the DUT returned configurations

STEP PASSED

STEP 5 - Get audio encoder configuration options

STEP PASSED

STEP 6 - Check if the DUT returned audio encoder configuration options

STEP PASSED

STEP 7 - Check if options list contain option for configuration with token 'aenc1'

STEP PASSED

TEST PASSED

MEDIA-3-3-4-v14.12 PROFILES AND AUDIO ENCODER CONFIGURATION OPTIONS CONSISTENCY

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting media profiles

STEP PASSED

STEP 4 - Check if the DUT returned media profiles

STEP PASSED

STEP 5 - Get audio encoder configuration options

STEP PASSED

STEP 6 - Check if options list contain option for configuration with token 'aenc1'

STEP PASSED

TEST PASSED

MEDIA-3-3-5-v14.12 AUDIO ENCODER CONFIGURATION USE COUNT (CURRENT STATE)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting audio encoder configurations

STEP PASSED

STEP 4 - Check if the DUT returned configurations

STEP PASSED

STEP 5 - Getting media profiles

STEP PASSED

STEP 6 - Check if the DUT returned media profiles

STEP PASSED

STEP 7 - Check condition

STEP PASSED

STEP 8 - Getting audio encoder configuration

STEP PASSED

STEP 9 - Check UseCount value

STEP PASSED

TEST PASSED

MEDIA-3-3-11-v14.12 AUDIO ENCODER CONFIGURATION OPTIONS AND AUDIO ENCODER CONFIGURATIONS CONSISTENCY (BITRATE AND SAMPLERATE)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Get audio encoder configuration options

STEP PASSED

STEP 4 - Check Bitrate and Samplerate for all options

STEP PASSED

STEP 5 - Getting audio encoder configurations

STEP PASSED

STEP 6 - Check if the DUT returned configurations

STEP PASSED

STEP 7 - Get audio encoder configuration options

STEP PASSED

STEP 8 - Check Bitrate and Samplerate for all options

STEP PASSED

STEP 9 - Check that options received for configuration with token 'aenc1' are valid

STEP PASSED

TEST PASSED

MEDIA-3-3-12-v14.12 AUDIO ENCODER CONFIGURATION USE COUNT (ADD SAME AUDIO ENCODER CONFIGURATION TO PROFILE TWICE)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting audio encoder configurations

STEP PASSED

STEP 4 - Check if the DUT returned audio encoder configurations

STEP PASSED

STEP 5 - Getting audio source configurations

STEP PASSED

STEP 6 - Check if the DUT returned audio source configurations

STEP PASSED

STEP 7 - Getting media profiles

STEP PASSED

STEP 8 - Creating media profile [name = 'T']

STEP PASSED

STEP 9 - Getting audio source configurations compatible with profile [token = 'T']

STEP PASSED

STEP 10 - Adding audio source configuration [token = 'asrc1'] to profile [token = 'T']

STEP PASSED

STEP 11 - Getting audio encoder configurations compatible with profile [token = 'T']

STEP PASSED

STEP 12 - Adding audio encoder configuration [token = 'aenc1'] to profile [token = 'T']

STEP PASSED

STEP 13 - Getting audio encoder configuration

STEP PASSED

STEP 14 - Check UseCount value after adding configuration to a profile

STEP PASSED

STEP 15 - Adding audio encoder configuration [token = 'aenc1'] to profile [token = 'T']

STEP PASSED

STEP 16 - Getting audio encoder configuration

STEP PASSED

STEP 17 - Check UseCount value after adding the same configuration to a profile twice

STEP PASSED

STEP 18 - Deleting media profile [token = 'T']

STEP PASSED

TEST PASSED

MEDIA-3-3-13-v14.12 AUDIO ENCODER CONFIGURATION USE COUNT (ADD DIFFERENT AUDIO ENCODER CONFIGURATIONS IN PROFILE)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting audio encoder configurations

STEP PASSED

STEP 4 - Check if the DUT returned audio encoder configurations

STEP PASSED

TEST PASSED

MEDIA-3-3-14-v14.12 AUDIO ENCODER CONFIGURATION USE COUNT (REMOVE AUDIO ENCODER CONFIGURATION)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting audio encoder configurations

STEP PASSED

STEP 4 - Check if the DUT returned audio encoder configurations

STEP PASSED

STEP 5 - Getting audio source configurations

STEP PASSED

STEP 6 - Check if the DUT returned audio source configurations

STEP PASSED

STEP 7 - Getting media profiles

STEP PASSED

STEP 8 - Creating media profile [name = 'k']

STEP PASSED

STEP 9 - Getting audio source configurations compatible with profile [token = 'k']

STEP PASSED

STEP 10 - Adding audio source configuration [token = 'asrc1'] to profile [token = 'k']

STEP PASSED

STEP 11 - Getting audio encoder configurations compatible with profile [token = 'k']

STEP PASSED

STEP 12 - Adding audio encoder configuration [token = 'aenc1'] to profile [token = 'k']

STEP PASSED

STEP 13 - Removing audio encoder configuration from profile [token = 'k']

STEP PASSED

STEP 14 - Getting audio encoder configuration

STEP PASSED

STEP 15 - Check UseCount value after removing configuration from a profile

STEP PASSED

STEP 16 - Deleting media profile [token = 'k']

STEP PASSED

TEST PASSED

MEDIA-3-3-15-v17.06 AUDIO ENCODER CONFIGURATION USE COUNT (DELETION PROFILE WITH AUDIO ENCODER CONFIGURATION)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting audio encoder configurations

STEP PASSED

STEP 4 - Check if the DUT returned audio encoder configurations

STEP PASSED

STEP 5 - Getting audio source configurations

STEP PASSED

STEP 6 - Check if the DUT returned audio source configurations

STEP PASSED

STEP 7 - Getting media profiles

STEP PASSED

STEP 8 - Creating media profile [name = '0']

STEP PASSED

STEP 9 - Getting audio source configurations compatible with profile [token = '0']

STEP PASSED

STEP 10 - Adding audio source configuration [token = 'asrc1'] to profile [token = '0']

STEP PASSED

STEP 11 - Getting audio encoder configurations compatible with profile [token = '0']

STEP PASSED

STEP 12 - Adding audio encoder configuration [token = 'aenc1'] to profile [token = '0']

STEP PASSED

STEP 13 - Deleting media profile [token = '0']

STEP PASSED

STEP 14 - Getting audio encoder configuration

STEP PASSED

STEP 15 - Check UseCount value after deleting profile with configuration

STEP PASSED

TEST PASSED

MEDIA-3-3-16-v14.12 AUDIO ENCODER CONFIGURATION USE COUNT (SET AUDIO ENCODER CONFIGURATION)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting audio encoder configurations

STEP PASSED

STEP 4 - Check if the DUT returned configurations

STEP PASSED

STEP 5 - Setting audio encoder configuration

STEP PASSED

STEP 6 - Getting audio encoder configuration

STEP PASSED

STEP 7 - Check UseCount after setting new value via SetAudioEncoderConfiguration

STEP PASSED

TEST PASSED

MEDIA-5-1-3-v14.12 METADATA CONFIGURATION

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Create profile

STEP PASSED

STEP 4 - Validate new media profile

STEP PASSED

STEP 5 - Validate new media profile

STEP PASSED

STEP 6 - Getting metadata configurations

STEP PASSED

STEP 7 - Deleting media profile [token = 'profile2']

STEP PASSED

TEST PASSED

MEDIA-6-1-1-v19.06 SNAPSHOT URI

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting media profiles

STEP PASSED

STEP 4 - Check if DUT returned at least one profile

STEP PASSED

STEP 5 - Check if media profile with video source and video encoder is present

STEP PASSED

STEP 6 - Get snapshot URI

STEP PASSED

STEP 7 - Check that response is not null

STEP PASSED

STEP 8 - Check that MediaUri field contains valid URL

STEP PASSED

STEP 9 - Invoke HTTP GET request on snapshot URI

STEP PASSED

STEP 10 - Check ContentType header

STEP PASSED

STEP 11 - Check HTTP status code

STEP PASSED

STEP 12 - Validate JPEG image

STEP PASSED

TEST PASSED

MEDIA-7-1-2-v18.06 SOAP FAULT MESSAGE

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting media profiles

STEP PASSED

STEP 4 - Check if DUT returned at least one profile

STEP PASSED

STEP 5 - Get Stream URI

STEP PASSED

TEST PASSED

MEDIA-7-1-4-v14.12 SOAP FAULT MESSAGE

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting media profiles

STEP PASSED

STEP 4 - Check if DUT returned profiles

STEP PASSED

STEP 5 - Get Stream URI - negative test

STEP PASSED

TEST PASSED

MEDIA-8-1-1-v14.12 MEDIA SERVICE CAPABILITIES

TestResult

STEP 1 - Get Media service address

STEP PASSED

STEP 2 - Check that the DUT returned Media service address

STEP PASSED

STEP 3 - Get Service Capabilities

STEP PASSED

TEST PASSED

MEDIA-8-1-2-v14.12 GET SERVICES AND GET MEDIA SERVICE CAPABILITIES CONSISTENCY

TestResult

STEP 1 - Get Services

STEP PASSED

STEP 2 - Check that the DUT returned Media service information

STEP PASSED

STEP 3 - Check that the DUT returned Capabilities element

STEP PASSED

STEP 4 - Get Media service address

STEP PASSED

STEP 5 - Check that the DUT returned Media service address

STEP PASSED

STEP 6 - Get Service Capabilities

STEP PASSED

STEP 7 - Parse Capabilities element in GetServices response

STEP PASSED

STEP 8 - Compare Capabilities

STEP PASSED

TEST PASSED

Real Time Streaming

RTSS-1-1-27-v19.12 MEDIA STREAMING – GUARANTEED NUMBER OF VIDEO ENCODER INSTANCES (RTP-Unicast/UDP)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting video source configurations

STEP PASSED

STEP 4 - Check if there are Video Source Configurations at the DUT

STEP PASSED

STEP 5 - Getting guaranteed number of video encoder instances

STEP PASSED

1 profiles with VideoSourceConfiguration 'vsrc1' are needed for test

STEP 6 - Getting media profiles

STEP PASSED

STEP 7 - Check if the DUT returned any profiles

STEP PASSED

Use existing profiles for test

STEP 8 - Check that required number of profiles has been achieved

STEP PASSED

STEP 9 - Get video encoder configuration options

STEP PASSED

STEP 10 - Setting video encoder configuration

STEP PASSED

STEP 11 - Get Stream URI

STEP PASSED

STEP 12 - Getting media service address

STEP PASSED

STEP 13 - Check if the stream uri has correct IP type

STEP PASSED

STEP 14 - Check if the stream uri has the scheme equal to 'rtsp'

STEP PASSED

STEP 15 - [Profile: profile1] Checking filters

STEP PASSED

STEP 16 - [Profile: profile1] Play As Filter

STEP PASSED

STEP 17 - [Profile: profile1] Enter CLiveCapsule::Prepare

STEP PASSED

STEP 18 - [Profile: profile1] Describe

STEP PASSED

STEP 19 - [Profile: profile1] Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 20 - [Profile: profile1] Create Media Session

STEP PASSED

STEP 21 - [Profile: profile1] Setup

STEP PASSED

STEP 22 - [Profile: profile1] Create Sinks

STEP PASSED

STEP 23 - [Profile: profile1] Play

STEP PASSED

STEP 24 - Closing streams

STEP 25 - [Profile: profile1] Pause

STEP 26 - [Profile: profile1] Teardown

STEP PASSED

STEP 27 - Check for test results

STEP PASSED

STEP 28 - Setting video encoder configuration

STEP PASSED

TEST PASSED

RTSS-1-1-28-v19.12 MEDIA STREAMING – GUARANTEED NUMBER OF VIDEO ENCODER INSTANCES (RTP-Unicast/RTSP/HTTP/TCP)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting video source configurations

STEP PASSED

STEP 4 - Check if there are Video Source Configurations at the DUT
STEP PASSED

STEP 5 - Getting guaranteed number of video encoder instances
STEP PASSED

1 profiles with VideoSourceConfiguration 'vsrc1' are needed for test

STEP 6 - Getting media profiles
STEP PASSED

STEP 7 - Check if the DUT returned any profiles
STEP PASSED

Use existing profiles for test

STEP 8 - Check that required number of profiles has been achieved
STEP PASSED

STEP 9 - Get video encoder configuration options
STEP PASSED

STEP 10 - Setting video encoder configuration
STEP PASSED

STEP 11 - Get Stream URI
STEP PASSED

STEP 12 - Getting media service address
STEP PASSED

STEP 13 - Check if the stream uri has correct IP type
STEP PASSED

STEP 14 - Check if the stream uri has the same scheme with the web service
STEP PASSED

STEP 15 - [Profile: profile1] Checking filters
STEP PASSED

STEP 16 - [Profile: profile1] Play As Filter

STEP PASSED

STEP 17 - [Profile: profile1] Enter CLiveCapsule::Prepare

STEP PASSED

STEP 18 - [Profile: profile1] Describe

STEP PASSED

STEP 19 - [Profile: profile1] Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 20 - [Profile: profile1] Create Media Session

STEP PASSED

STEP 21 - [Profile: profile1] Setup

STEP PASSED

STEP 22 - [Profile: profile1] Create Sinks

STEP PASSED

STEP 23 - [Profile: profile1] Play

STEP PASSED

STEP 24 - Closing streams

STEP 25 - [Profile: profile1] Pause

STEP 26 - [Profile: profile1] Teardown

STEP PASSED

STEP 27 - Check for test results

STEP PASSED

STEP 28 - Setting video encoder configuration

STEP PASSED

TEST PASSED

RTSS-1-1-29-v19.12 MEDIA STREAMING – GUARANTEED NUMBER OF VIDEO ENCODER INSTANCES (RTP/RTSP/TCP)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting video source configurations

STEP PASSED

STEP 4 - Check if there are Video Source Configurations at the DUT

STEP PASSED

STEP 5 - Getting guaranteed number of video encoder instances

STEP PASSED

1 profiles with VideoSourceConfiguration 'vsrc1' are needed for test

STEP 6 - Getting media profiles

STEP PASSED

STEP 7 - Check if the DUT returned any profiles

STEP PASSED

Use existing profiles for test

STEP 8 - Check that required number of profiles has been achieved

STEP PASSED

STEP 9 - Get video encoder configuration options

STEP PASSED

STEP 10 - Setting video encoder configuration

STEP PASSED

STEP 11 - Get Stream URI

STEP PASSED

STEP 12 - Getting media service address

STEP PASSED

STEP 13 - Check if the stream uri has correct IP type

STEP PASSED

STEP 14 - Check if the stream uri has the scheme equal to 'rtsp'

STEP PASSED

STEP 15 - [Profile: profile1] Checking filters

STEP PASSED

STEP 16 - [Profile: profile1] Play As Filter

STEP PASSED

STEP 17 - [Profile: profile1] Enter CLiveCapsule::Prepare

STEP PASSED

STEP 18 - [Profile: profile1] Describe

STEP PASSED

STEP 19 - [Profile: profile1] Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 20 - [Profile: profile1] Create Media Session

STEP PASSED

STEP 21 - [Profile: profile1] Setup

STEP PASSED

STEP 22 - [Profile: profile1] Create Sinks

STEP PASSED

STEP 23 - [Profile: profile1] Play

STEP PASSED

STEP 24 - Closing streams

STEP 25 - [Profile: profile1] Pause

STEP 26 - [Profile: profile1] Teardown

STEP PASSED

STEP 27 - Check for test results

STEP PASSED

STEP 28 - Setting video encoder configuration

STEP PASSED

TEST PASSED

RTSS-1-1-30-v19.12 MEDIA STREAMING – GUARANTEED NUMBER OF VIDEO ENCODER INSTANCES (MIX OF TRANSPORT TYPES)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting video source configurations

STEP PASSED

STEP 4 - Check if there are Video Source Configurations at the DUT

STEP PASSED

STEP 5 - Getting guaranteed number of video encoder instances

STEP PASSED

1 profiles with VideoSourceConfiguration 'vsrc1' are needed for test

STEP 6 - Getting media profiles

STEP PASSED

STEP 7 - Check if the DUT returned any profiles

STEP PASSED

Use existing profiles for test

STEP 8 - Removing audio encoder configuration from profile [token = 'profile1']

STEP PASSED

STEP 9 - Check that required number of profiles has been achieved

STEP PASSED

STEP 10 - Get video encoder configuration options

STEP PASSED

STEP 11 - Setting video encoder configuration

STEP PASSED

STEP 12 - Get Stream URI

STEP PASSED

STEP 13 - Getting media service address

STEP PASSED

STEP 14 - Check if the stream uri has correct IP type

STEP PASSED

STEP 15 - Check if the stream uri has the scheme equal to 'rtsp'

STEP PASSED

STEP 16 - [Profile: profile1] Checking filters

STEP PASSED

STEP 17 - [Profile: profile1] Play As Filter

STEP PASSED

STEP 18 - [Profile: profile1] Enter CLiveCapsule::Prepare

STEP PASSED

STEP 19 - [Profile: profile1] Describe

STEP PASSED

STEP 20 - [Profile: profile1] Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 21 - [Profile: profile1] Create Media Session

STEP PASSED

STEP 22 - [Profile: profile1] Setup

STEP PASSED

STEP 23 - [Profile: profile1] Create Sinks

STEP PASSED

STEP 24 - [Profile: profile1] Play

STEP PASSED

STEP 25 - Closing streams

STEP 26 - [Profile: profile1] Pause

STEP 27 - [Profile: profile1] Teardown

STEP PASSED

STEP 28 - Check for test results

STEP PASSED

Restore profile 'profile1' used for test

STEP 29 - Get actual profile

STEP PASSED

STEP 30 - Adding audio encoder configuration [token = 'aenc1'] to profile [token = 'profile1']

STEP PASSED

STEP 31 - Setting video encoder configuration

STEP PASSED

TEST PASSED

RTSS-1-1-31-v19.12 MEDIA CONTROL – RTSP/TCP

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting media profiles

STEP PASSED

STEP 4 - Select profile with JPEG Video encoder configuration

STEP PASSED

STEP 5 - Check if required profile found

STEP PASSED

STEP 6 - Check that options for JPEG encoder are received

STEP PASSED

STEP 7 - Setting video encoder configuration

STEP PASSED

STEP 8 - Get Stream URI

STEP PASSED

STEP 9 - Getting media service address

STEP PASSED

STEP 10 - Check if the stream uri has correct IP type

STEP PASSED

STEP 11 - Check if the stream uri has the scheme equal to 'rtsp'

STEP PASSED

STEP 12 - Checking filters

STEP PASSED

STEP 13 - Enter CLiveCapsule::Prepare

STEP PASSED

STEP 14 - Options

STEP PASSED

STEP 15 - Checking Options

STEP PASSED

STEP 16 - Describe

STEP PASSED

STEP 17 - Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 18 - Create Media Session

STEP PASSED

STEP 19 - Setup

STEP PASSED

STEP 20 - Create Sinks

STEP PASSED

STEP 21 - Play

STEP PASSED

STEP 22 - Waiting for 12 frames up to 1000 ms

STEP PASSED

STEP 23 - Teardown

STEP PASSED

STEP 24 - Setting video encoder configuration

STEP PASSED

TEST PASSED

RTSS-1-1-32-v19.12 MEDIA STREAMING – RTSP KEEPALIVE (SET_PARAMETER)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting media profiles

STEP PASSED

STEP 4 - Select profile with JPEG Video encoder configuration

STEP PASSED

STEP 5 - Check if required profile found

STEP PASSED

STEP 6 - Check that options for JPEG encoder are received

STEP PASSED

STEP 7 - Setting video encoder configuration

STEP PASSED

STEP 8 - Get Stream URI

STEP PASSED

STEP 9 - Getting media service address

STEP PASSED

STEP 10 - Check if the stream uri has correct IP type

STEP PASSED

STEP 11 - Check if the stream uri has the scheme equal to 'rtsp'

STEP PASSED

STEP 12 - Checking filters

STEP PASSED

STEP 13 - Enter CLiveCapsule::Prepare

STEP PASSED

STEP 14 - Options

STEP PASSED

STEP 15 - Checking Options

STEP PASSED

STEP 16 - Describe

STEP PASSED

STEP 17 - Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 18 - Create Media Session

STEP PASSED

STEP 19 - Setup

STEP PASSED

STEP 20 - Create Sinks

STEP PASSED

STEP 21 - Play

STEP PASSED

STEP 22 - Waiting for 12 frames up to 1000 ms

STEP PASSED

STEP 23 - Teardown

STEP PASSED

STEP 24 - Setting video encoder configuration

STEP PASSED

TEST PASSED

RTSS-1-1-33-v19.12 MEDIA STREAMING - RTSP KEEPALIVE (OPTIONS)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting media profiles

STEP PASSED

STEP 4 - Select profile with JPEG Video encoder configuration

STEP PASSED

STEP 5 - Check if required profile found

STEP PASSED

STEP 6 - Check that options for JPEG encoder are received

STEP PASSED

STEP 7 - Setting video encoder configuration

STEP PASSED

STEP 8 - Get Stream URI

STEP PASSED

STEP 9 - Getting media service address

STEP PASSED

STEP 10 - Check if the stream uri has correct IP type

STEP PASSED

STEP 11 - Check if the stream uri has the scheme equal to 'rtsp'

STEP PASSED

STEP 12 - Checking filters

STEP PASSED

STEP 13 - Enter CLiveCapsule::Prepare

STEP PASSED

STEP 14 - Options

STEP PASSED

STEP 15 - Checking Options

STEP PASSED

STEP 16 - Describe

STEP PASSED

STEP 17 - Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 18 - Create Media Session

STEP PASSED

STEP 19 - Setup

STEP PASSED

STEP 20 - Create Sinks

STEP PASSED

STEP 21 - Play

STEP PASSED

STEP 22 - Waiting for 12 frames up to 1000 ms

STEP PASSED

STEP 23 - Teardown

STEP PASSED

STEP 24 - Setting video encoder configuration

STEP PASSED

TEST PASSED

RTSS-1-1-34-v19.12 MEDIA STREAMING – JPEG (RTP-Unicast/UDP)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting media profiles

STEP PASSED

STEP 4 - Select profile with JPEG Video encoder configuration

STEP PASSED

STEP 5 - Check if required profile found

STEP PASSED

STEP 6 - Check that options for JPEG encoder are received

STEP PASSED

STEP 7 - Setting video encoder configuration

STEP PASSED

STEP 8 - Get Stream URI

STEP PASSED

STEP 9 - Getting media service address

STEP PASSED

STEP 10 - Check if the stream uri has correct IP type

STEP PASSED

STEP 11 - Check if the stream uri has the scheme equal to 'rtsp'

STEP PASSED

STEP 12 - Checking filters

STEP PASSED

STEP 13 - Enter CLiveCapsule::Prepare

STEP PASSED

STEP 14 - Describe

STEP PASSED

STEP 15 - Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 16 - Create Media Session

STEP PASSED

STEP 17 - Setup

STEP PASSED

STEP 18 - Create Sinks

STEP PASSED

STEP 19 - Play

STEP PASSED

STEP 20 - Waiting for 12 frames up to 1000 ms

STEP PASSED

STEP 21 - Teardown

STEP PASSED

STEP 22 - Setting video encoder configuration

STEP PASSED

TEST PASSED

RTSS-1-1-35-v19.12 MEDIA STREAMING - JPEG (RTP-Unicast/RTSP/HTTP/TCP)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting media profiles

STEP PASSED

STEP 4 - Select profile with JPEG Video encoder configuration

STEP PASSED

STEP 5 - Check if required profile found

STEP PASSED

STEP 6 - Check that options for JPEG encoder are received

STEP PASSED

STEP 7 - Setting video encoder configuration

STEP PASSED

STEP 8 - Get Stream URI

STEP PASSED

STEP 9 - Getting media service address

STEP PASSED

STEP 10 - Check if the stream uri has correct IP type

STEP PASSED

STEP 11 - Check if the stream uri has the same scheme with the web service

STEP PASSED

STEP 12 - Checking filters

STEP PASSED

STEP 13 - Enter CLiveCapsule::Prepare

STEP PASSED

STEP 14 - Describe

STEP PASSED

STEP 15 - Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 16 - Create Media Session

STEP PASSED

STEP 17 - Setup

STEP PASSED

STEP 18 - Create Sinks

STEP PASSED

STEP 19 - Play

STEP PASSED

STEP 20 - Waiting for 12 frames up to 1000 ms

STEP PASSED

STEP 21 - Teardown

STEP PASSED

STEP 22 - Setting video encoder configuration

STEP PASSED

TEST PASSED

RTSS-1-1-36-v19.12 MEDIA STREAMING - JPEG (RTP/RTSP/TCP)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting media profiles

STEP PASSED

STEP 4 - Select profile with JPEG Video encoder configuration

STEP PASSED

STEP 5 - Check if required profile found

STEP PASSED

STEP 6 - Check that options for JPEG encoder are received

STEP PASSED

STEP 7 - Setting video encoder configuration

STEP PASSED

STEP 8 - Get Stream URI

STEP PASSED

STEP 9 - Getting media service address

STEP PASSED

STEP 10 - Check if the stream uri has correct IP type

STEP PASSED

STEP 11 - Check if the stream uri has the scheme equal to 'rtsp'

STEP PASSED

STEP 12 - Checking filters

STEP PASSED

STEP 13 - Enter CLiveCapsule::Prepare

STEP PASSED

STEP 14 - Describe

STEP PASSED

STEP 15 - Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 16 - Create Media Session

STEP PASSED

STEP 17 - Setup

STEP PASSED

STEP 18 - Create Sinks

STEP PASSED

STEP 19 - Play

STEP PASSED

STEP 20 - Waiting for 12 frames up to 1000 ms

STEP PASSED

STEP 21 - Teardown

STEP PASSED

STEP 22 - Setting video encoder configuration

STEP PASSED

TEST PASSED

RTSS-1-1-41-v19.12 MEDIA STREAMING - H.264 (RTP-Unicast/UDP)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting media profiles

STEP PASSED

STEP 4 - Select profile with H.264 Video encoder configuration

STEP PASSED

STEP 5 - Check if required profile found

STEP PASSED

STEP 6 - Check that options for H264 encoder are received

STEP PASSED

STEP 7 - Setting video encoder configuration

STEP PASSED

STEP 8 - Get Stream URI

STEP PASSED

STEP 9 - Getting media service address

STEP PASSED

STEP 10 - Check if the stream uri has correct IP type

STEP PASSED

STEP 11 - Check if the stream uri has the scheme equal to 'rtsp'

STEP PASSED

STEP 12 - Checking filters

STEP PASSED

STEP 13 - Enter CLiveCapsule::Prepare

STEP PASSED

STEP 14 - Describe

STEP PASSED

STEP 15 - Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 16 - Create Media Session

STEP PASSED

STEP 17 - Setup

STEP PASSED

STEP 18 - Create Sinks

STEP PASSED

STEP 19 - Play

STEP PASSED

STEP 20 - Waiting for 12 frames up to 1000 ms

STEP PASSED

STEP 21 - Teardown

STEP PASSED

STEP 22 - Setting video encoder configuration

STEP PASSED

TEST PASSED

RTSS-1-1-42-v19.12 MEDIA STREAMING - H.264 (RTP-Unicast/RTSP/HTTP/TCP)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting media profiles

STEP PASSED

STEP 4 - Select profile with H.264 Video encoder configuration

STEP PASSED

STEP 5 - Check if required profile found

STEP PASSED

STEP 6 - Check that options for H264 encoder are received

STEP PASSED

STEP 7 - Setting video encoder configuration

STEP PASSED

STEP 8 - Get Stream URI

STEP PASSED

STEP 9 - Getting media service address

STEP PASSED

STEP 10 - Check if the stream uri has correct IP type

STEP PASSED

STEP 11 - Check if the stream uri has the same scheme with the web service

STEP PASSED

STEP 12 - Checking filters

STEP PASSED

STEP 13 - Enter CLiveCapsule::Prepare

STEP PASSED

STEP 14 - Describe

STEP PASSED

STEP 15 - Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 16 - Create Media Session

STEP PASSED

STEP 17 - Setup

STEP PASSED

STEP 18 - Create Sinks

STEP PASSED

STEP 19 - Play

STEP PASSED

STEP 20 - Waiting for 12 frames up to 1000 ms

STEP PASSED

STEP 21 - Teardown

STEP PASSED

STEP 22 - Setting video encoder configuration

STEP PASSED

TEST PASSED

RTSS-1-1-43-v19.12 MEDIA STREAMING - H.264 (RTP/RTSP/TCP)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting media profiles

STEP PASSED

STEP 4 - Select profile with H.264 Video encoder configuration

STEP PASSED

STEP 5 - Check if required profile found

STEP PASSED

STEP 6 - Check that options for H264 encoder are received

STEP PASSED

STEP 7 - Setting video encoder configuration

STEP PASSED

STEP 8 - Get Stream URI

STEP PASSED

STEP 9 - Getting media service address

STEP PASSED

STEP 10 - Check if the stream uri has correct IP type

STEP PASSED

STEP 11 - Check if the stream uri has the scheme equal to 'rtsp'

STEP PASSED

STEP 12 - Checking filters

STEP PASSED

STEP 13 - Enter CLiveCapsule::Prepare

STEP PASSED

STEP 14 - Describe

STEP PASSED

STEP 15 - Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 16 - Create Media Session

STEP PASSED

STEP 17 - Setup

STEP PASSED

STEP 18 - Create Sinks

STEP PASSED

STEP 19 - Play

STEP PASSED

STEP 20 - Waiting for 12 frames up to 1000 ms

STEP PASSED

STEP 21 - Teardown

STEP PASSED

STEP 22 - Setting video encoder configuration

STEP PASSED

TEST PASSED

RTSS-1-1-44-v19.12 SET SYNCHRONIZATION POINT - H.264

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting media profiles

STEP PASSED

STEP 4 - Select profile with H.264 Video encoder configuration

STEP PASSED

STEP 5 - Check if required profile found

STEP PASSED

STEP 6 - Check that options for H264 encoder are received

STEP PASSED

STEP 7 - Setting video encoder configuration

STEP PASSED

STEP 8 - Get Stream URI

STEP PASSED

STEP 9 - Getting media service address

STEP PASSED

STEP 10 - Check if the stream uri has correct IP type

STEP PASSED

STEP 11 - Check if the stream uri has the scheme equal to 'rtsp'

STEP PASSED

STEP 12 - Enter CLiveCapsule::Prepare

STEP PASSED

STEP 13 - Describe

STEP PASSED

STEP 14 - Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 15 - Create Media Session

STEP PASSED

STEP 16 - Setup

STEP PASSED

STEP 17 - Create Sinks

STEP PASSED

STEP 18 - Play

STEP PASSED

STEP 19 - SetSynchronizationPoint

STEP PASSED

STEP 20 - Waiting for 10 seconds

STEP PASSED

STEP 21 - Teardown

STEP PASSED

STEP 22 - Checking media frames count

STEP PASSED

STEP 23 - Setting video encoder configuration

STEP PASSED

TEST PASSED

RTSS-1-1-45-v19.12 MEDIA STREAMING – RTP-Unicast/RTSP/HTTP/TCP (LINE BREAKS IN BASE64 ENCODING)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting media profiles

STEP PASSED

STEP 4 - Select profile with JPEG Video encoder configuration

STEP PASSED

STEP 5 - Check if required profile found

STEP PASSED

STEP 6 - Check that options for JPEG encoder are received

STEP PASSED

STEP 7 - Setting video encoder configuration

STEP PASSED

STEP 8 - Get Stream URI

STEP PASSED

STEP 9 - Getting media service address

STEP PASSED

STEP 10 - Check if the stream uri has correct IP type

STEP PASSED

STEP 11 - Check if the stream uri has the same scheme with the web service

STEP PASSED

STEP 12 - Checking filters

STEP PASSED

STEP 13 - Enter CLiveCapsule::Prepare

STEP PASSED

STEP 14 - Describe

STEP PASSED

STEP 15 - Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 16 - Create Media Session

STEP PASSED

STEP 17 - Setup

STEP PASSED

STEP 18 - Create Sinks

STEP PASSED

STEP 19 - Play

STEP PASSED

STEP 20 - Waiting for 12 frames up to 1000 ms

STEP PASSED

STEP 21 - Teardown

STEP PASSED

STEP 22 - Setting video encoder configuration

STEP PASSED

TEST PASSED

RTSS-1-1-46-v19.12 VIDEO ENCODER CONFIGURATION – JPEG RESOLUTION

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting video encoder configurations

STEP PASSED

STEP 4 - Check if there are Video Encoder Configurations at the DUT

STEP PASSED

There are no VideoEncoderConfiguration ready for selected encoder type - will try to reconfigure (if this may fail - please pre-configure before making tests).

STEP 5 - Getting media profiles

STEP PASSED

STEP 6 - Check if the DUT returned any profiles

STEP PASSED

STEP 7 - Get video encoder configuration options

STEP PASSED

STEP 8 - Select profile for test

STEP PASSED

STEP 9 - Get video encoder configuration options

STEP PASSED

STEP 10 - Validate JPEG options

STEP PASSED

STEP 11 - Find highest and lowest resolutions for further testing

STEP PASSED

STEP 12 - Setting video encoder configuration

STEP PASSED

STEP 13 - Getting video encoder configuration

STEP PASSED

STEP 14 - Check that the DUT accepted values passed

STEP PASSED

STEP 15 - Get Stream URI

STEP PASSED

STEP 16 - Getting media service address

STEP PASSED

STEP 17 - Check if the stream uri has correct IP type

STEP PASSED

STEP 18 - Check if the stream uri has the scheme equal to 'rtsp'

STEP PASSED

STEP 19 - Checking filters

STEP PASSED

STEP 20 - Enter CLiveCapsule::Prepare

STEP PASSED

STEP 21 - Describe

STEP PASSED

STEP 22 - Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 23 - Create Media Session

STEP PASSED

STEP 24 - Setup

STEP PASSED

STEP 25 - Create Sinks

STEP PASSED

STEP 26 - Play

STEP PASSED

STEP 27 - Waiting for 12 frames up to 1000 ms

STEP PASSED

STEP 28 - Checking actual resolution

STEP PASSED

STEP 29 - Teardown

STEP PASSED

STEP 30 - Setting video encoder configuration

STEP PASSED

STEP 31 - Getting video encoder configuration

STEP PASSED

STEP 32 - Check that the DUT accepted values passed

STEP PASSED

STEP 33 - Get Stream URI

STEP PASSED

STEP 34 - Getting media service address

STEP PASSED

STEP 35 - Check if the stream uri has correct IP type

STEP PASSED

STEP 36 - Check if the stream uri has the scheme equal to 'rtsp'

STEP PASSED

STEP 37 - Checking filters

STEP PASSED

STEP 38 - Enter CLiveCapsule::Prepare

STEP PASSED

STEP 39 - Describe

STEP PASSED

STEP 40 - Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 41 - Create Media Session

STEP PASSED

STEP 42 - Setup

STEP PASSED

STEP 43 - Create Sinks

STEP PASSED

STEP 44 - Play

STEP PASSED

STEP 45 - Waiting for 12 frames up to 1000 ms

STEP PASSED

STEP 46 - Checking actual resolution

STEP PASSED

STEP 47 - Teardown

STEP PASSED

STEP 48 - Setting video encoder configuration

STEP PASSED

STEP 49 - Getting video encoder configuration

STEP PASSED

STEP 50 - Check that the DUT accepted values passed

STEP PASSED

STEP 51 - Get Stream URI

STEP PASSED

STEP 52 - Getting media service address

STEP PASSED

STEP 53 - Check if the stream uri has correct IP type

STEP PASSED

STEP 54 - Check if the stream uri has the scheme equal to 'rtsp'

STEP PASSED

STEP 55 - Checking filters

STEP PASSED

STEP 56 - Enter CLiveCapsule::Prepare

STEP PASSED

STEP 57 - Describe

STEP PASSED

STEP 58 - Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 59 - Create Media Session

STEP PASSED

STEP 60 - Setup

STEP PASSED

STEP 61 - Create Sinks

STEP PASSED

STEP 62 - Play

STEP PASSED

STEP 63 - Waiting for 12 frames up to 1000 ms

STEP PASSED

STEP 64 - Checking actual resolution

STEP PASSED

STEP 65 - Teardown

STEP PASSED

STEP 66 - Getting media profiles

STEP PASSED

STEP 67 - Check if the DUT returned any profiles

STEP PASSED

STEP 68 - Create profile for test

STEP PASSED

STEP 69 - Check that profile has been created properly

STEP PASSED

STEP 70 - Getting video source configurations compatible with profile [token = 'profile2']

STEP PASSED

STEP 71 - Check if there are compatible Video Source Configurationss at the DUT

STEP PASSED

STEP 72 - Adding video source configuration [token = 'vsrc1'] to profile [token = 'profile2']

STEP PASSED

STEP 73 - Getting video encoder configurations compatible with profile [token = 'profile2']

STEP PASSED

STEP 74 - Adding video encoder configuration [token = 'venc2'] to profile [token = 'profile2']

STEP PASSED

STEP 75 - Get video encoder configuration options

STEP PASSED

STEP 76 - Get video encoder configuration options

STEP PASSED

STEP 77 - Validate JPEG options

STEP PASSED

STEP 78 - Find highest and lowest resolutions for further testing

STEP PASSED

STEP 79 - Setting video encoder configuration

STEP PASSED

STEP 80 - Getting video encoder configuration

STEP PASSED

STEP 81 - Check that the DUT accepted values passed

STEP PASSED

STEP 82 - Get Stream URI

STEP PASSED

STEP 83 - Getting media service address

STEP PASSED

STEP 84 - Check if the stream uri has correct IP type

STEP PASSED

STEP 85 - Check if the stream uri has the scheme equal to 'rtsp'

STEP PASSED

STEP 86 - Checking filters

STEP PASSED

STEP 87 - Enter CLiveCapsule::Prepare

STEP PASSED

STEP 88 - Describe

STEP PASSED

STEP 89 - Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 90 - Create Media Session

STEP PASSED

STEP 91 - Setup

STEP PASSED

STEP 92 - Create Sinks

STEP PASSED

STEP 93 - Play

STEP PASSED

STEP 94 - Waiting for 12 frames up to 1000 ms

STEP PASSED

STEP 95 - Checking actual resolution

STEP PASSED

STEP 96 - Teardown

STEP PASSED

STEP 97 - Setting video encoder configuration

STEP PASSED

STEP 98 - Getting video encoder configuration

STEP PASSED

STEP 99 - Check that the DUT accepted values passed

STEP PASSED

STEP 100 - Get Stream URI

STEP PASSED

STEP 101 - Getting media service address

STEP PASSED

STEP 102 - Check if the stream uri has correct IP type

STEP PASSED

STEP 103 - Check if the stream uri has the scheme equal to 'rtsp'

STEP PASSED

STEP 104 - Checking filters

STEP PASSED

STEP 105 - Enter CLiveCapsule::Prepare

STEP PASSED

STEP 106 - Describe

STEP PASSED

STEP 107 - Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 108 - Create Media Session

STEP PASSED

STEP 109 - Setup

STEP PASSED

STEP 110 - Create Sinks

STEP PASSED

STEP 111 - Play

STEP PASSED

STEP 112 - Waiting for 12 frames up to 1000 ms

STEP PASSED

STEP 113 - Checking actual resolution

STEP PASSED

STEP 114 - Teardown

STEP PASSED

STEP 115 - Setting video encoder configuration

STEP PASSED

STEP 116 - Getting video encoder configuration

STEP PASSED

STEP 117 - Check that the DUT accepted values passed

STEP PASSED

STEP 118 - Get Stream URI

STEP PASSED

STEP 119 - Getting media service address

STEP PASSED

STEP 120 - Check if the stream uri has correct IP type

STEP PASSED

STEP 121 - Check if the stream uri has the scheme equal to 'rtsp'

STEP PASSED

STEP 122 - Checking filters

STEP PASSED

STEP 123 - Enter CLiveCapsule::Prepare

STEP PASSED

STEP 124 - Describe

STEP PASSED

STEP 125 - Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 126 - Create Media Session

STEP PASSED

STEP 127 - Setup

STEP PASSED

STEP 128 - Create Sinks

STEP PASSED

STEP 129 - Play

STEP PASSED

STEP 130 - Waiting for 12 frames up to 1000 ms

STEP PASSED

STEP 131 - Checking actual resolution

STEP PASSED

STEP 132 - Teardown

STEP PASSED

STEP 133 - Getting media profiles

STEP PASSED

STEP 134 - Check if the DUT returned any profiles

STEP PASSED

STEP 135 - Create profile for test

STEP PASSED

STEP 136 - Check that profile has been created properly

STEP PASSED

STEP 137 - Getting video source configurations compatible with profile [token = 'profile3']

STEP PASSED

STEP 138 - Check if there are compatible Video Source Configurationss at the DUT

STEP PASSED

STEP 139 - Adding video source configuration [token = 'vsrc1'] to profile [token = 'profile3']

STEP PASSED

STEP 140 - Getting video encoder configurations compatible with profile [token = 'profile3']

STEP PASSED

STEP 141 - Adding video encoder configuration [token = 'venc3'] to profile [token = 'profile3']

STEP PASSED

STEP 142 - Get video encoder configuration options

STEP PASSED

STEP 143 - Get video encoder configuration options

STEP PASSED

STEP 144 - Validate JPEG options

STEP PASSED

STEP 145 - Find highest and lowest resolutions for further testing

STEP PASSED

STEP 146 - Setting video encoder configuration

STEP PASSED

STEP 147 - Getting video encoder configuration

STEP PASSED

STEP 148 - Check that the DUT accepted values passed

STEP PASSED

STEP 149 - Get Stream URI

STEP PASSED

STEP 150 - Getting media service address

STEP PASSED

STEP 151 - Check if the stream uri has correct IP type

STEP PASSED

STEP 152 - Check if the stream uri has the scheme equal to 'rtsp'

STEP PASSED

STEP 153 - Checking filters

STEP PASSED

STEP 154 - Enter CLiveCapsule::Prepare

STEP PASSED

STEP 155 - Describe

STEP PASSED

STEP 156 - Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 157 - Create Media Session

STEP PASSED

STEP 158 - Setup

STEP PASSED

STEP 159 - Create Sinks

STEP PASSED

STEP 160 - Play

STEP PASSED

STEP 161 - Waiting for 12 frames up to 1000 ms

STEP PASSED

STEP 162 - Checking actual resolution

STEP PASSED

STEP 163 - Teardown

STEP PASSED

STEP 164 - Setting video encoder configuration

STEP PASSED

STEP 165 - Getting video encoder configuration

STEP PASSED

STEP 166 - Check that the DUT accepted values passed

STEP PASSED

STEP 167 - Get Stream URI

STEP PASSED

STEP 168 - Getting media service address

STEP PASSED

STEP 169 - Check if the stream uri has correct IP type

STEP PASSED

STEP 170 - Check if the stream uri has the scheme equal to 'rtsp'

STEP PASSED

STEP 171 - Checking filters

STEP PASSED

STEP 172 - Enter CLiveCapsule::Prepare

STEP PASSED

STEP 173 - Describe

STEP PASSED

STEP 174 - Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 175 - Create Media Session

STEP PASSED

STEP 176 - Setup

STEP PASSED

STEP 177 - Create Sinks

STEP PASSED

STEP 178 - Play

STEP PASSED

STEP 179 - Waiting for 12 frames up to 1000 ms

STEP PASSED

STEP 180 - Checking actual resolution

STEP PASSED

STEP 181 - Teardown

STEP PASSED

STEP 182 - Setting video encoder configuration

STEP PASSED

STEP 183 - Getting video encoder configuration

STEP PASSED

STEP 184 - Check that the DUT accepted values passed

STEP PASSED

STEP 185 - Get Stream URI

STEP PASSED

STEP 186 - Getting media service address

STEP PASSED

STEP 187 - Check if the stream uri has correct IP type

STEP PASSED

STEP 188 - Check if the stream uri has the scheme equal to 'rtsp'

STEP PASSED

STEP 189 - Checking filters

STEP PASSED

STEP 190 - Enter CLiveCapsule::Prepare

STEP PASSED

STEP 191 - Describe

STEP PASSED

STEP 192 - Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 193 - Create Media Session

STEP PASSED

STEP 194 - Setup

STEP PASSED

STEP 195 - Create Sinks

STEP PASSED

STEP 196 - Play

STEP PASSED

STEP 197 - Waiting for 12 frames up to 1000 ms

STEP PASSED

STEP 198 - Checking actual resolution

STEP PASSED

STEP 199 - Teardown

STEP PASSED

STEP 200 - Deleting media profile [token = 'profile2']

STEP PASSED

STEP 201 - Deleting media profile [token = 'profile3']

STEP PASSED

STEP 202 - Setting video encoder configuration

STEP PASSED

STEP 203 - Setting video encoder configuration

STEP PASSED

STEP 204 - Setting video encoder configuration

STEP PASSED

TEST PASSED

RTSS-1-1-48-v19.12 VIDEO ENCODER CONFIGURATION – H.264 RESOLUTION

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting video encoder configurations

STEP PASSED

STEP 4 - Check if there are Video Encoder Configurations at the DUT

STEP PASSED

STEP 5 - Getting media profiles

STEP PASSED

STEP 6 - Check if the DUT returned any profiles

STEP PASSED

STEP 7 - Get video encoder configuration options

STEP PASSED

STEP 8 - Select profile for test

STEP PASSED

STEP 9 - Get video encoder configuration options

STEP PASSED

STEP 10 - Validate H264 options

STEP PASSED

STEP 11 - Find highest and lowest resolutions for further testing

STEP PASSED

STEP 12 - Setting video encoder configuration

STEP PASSED

STEP 13 - Getting video encoder configuration

STEP PASSED

STEP 14 - Check that the DUT accepted values passed

STEP PASSED

STEP 15 - Get Stream URI

STEP PASSED

STEP 16 - Getting media service address

STEP PASSED

STEP 17 - Check if the stream uri has correct IP type

STEP PASSED

STEP 18 - Check if the stream uri has the scheme equal to 'rtsp'

STEP PASSED

STEP 19 - Checking filters

STEP PASSED

STEP 20 - Enter CLiveCapsule::Prepare

STEP PASSED

STEP 21 - Describe

STEP PASSED

STEP 22 - Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 23 - Create Media Session

STEP PASSED

STEP 24 - Setup

STEP PASSED

STEP 25 - Create Sinks

STEP PASSED

STEP 26 - Play

STEP PASSED

STEP 27 - Waiting for 12 frames up to 1000 ms

STEP PASSED

STEP 28 - Checking actual resolution

STEP PASSED

STEP 29 - Teardown

STEP PASSED

STEP 30 - Setting video encoder configuration

STEP PASSED

STEP 31 - Getting video encoder configuration

STEP PASSED

STEP 32 - Check that the DUT accepted values passed

STEP PASSED

STEP 33 - Get Stream URI

STEP PASSED

STEP 34 - Getting media service address

STEP PASSED

STEP 35 - Check if the stream uri has correct IP type

STEP PASSED

STEP 36 - Check if the stream uri has the scheme equal to 'rtsp'

STEP PASSED

STEP 37 - Checking filters

STEP PASSED

STEP 38 - Enter CLiveCapsule::Prepare

STEP PASSED

STEP 39 - Describe

STEP PASSED

STEP 40 - Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 41 - Create Media Session

STEP PASSED

STEP 42 - Setup

STEP PASSED

STEP 43 - Create Sinks

STEP PASSED

STEP 44 - Play

STEP PASSED

STEP 45 - Waiting for 12 frames up to 1000 ms

STEP PASSED

STEP 46 - Checking actual resolution

STEP PASSED

STEP 47 - Teardown

STEP PASSED

STEP 48 - Setting video encoder configuration

STEP PASSED

STEP 49 - Getting video encoder configuration

STEP PASSED

STEP 50 - Check that the DUT accepted values passed

STEP PASSED

STEP 51 - Get Stream URI

STEP PASSED

STEP 52 - Getting media service address

STEP PASSED

STEP 53 - Check if the stream uri has correct IP type

STEP PASSED

STEP 54 - Check if the stream uri has the scheme equal to 'rtsp'

STEP PASSED

STEP 55 - Checking filters

STEP PASSED

STEP 56 - Enter CLiveCapsule::Prepare

STEP PASSED

STEP 57 - Describe

STEP PASSED

STEP 58 - Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 59 - Create Media Session

STEP PASSED

STEP 60 - Setup

STEP PASSED

STEP 61 - Create Sinks

STEP PASSED

STEP 62 - Play

STEP PASSED

STEP 63 - Waiting for 12 frames up to 1000 ms

STEP PASSED

STEP 64 - Checking actual resolution

STEP PASSED

STEP 65 - Teardown

STEP PASSED

STEP 66 - Getting media profiles

STEP PASSED

STEP 67 - Check if the DUT returned any profiles

STEP PASSED

STEP 68 - Create profile for test

STEP PASSED

STEP 69 - Check that profile has been created properly

STEP PASSED

STEP 70 - Getting video source configurations compatible with profile [token = 'profile2']

STEP PASSED

STEP 71 - Check if there are compatible Video Source Configurationss at the DUT

STEP PASSED

STEP 72 - Adding video source configuration [token = 'vsrc1'] to profile [token = 'profile2']

STEP PASSED

STEP 73 - Getting video encoder configurations compatible with profile [token = 'profile2']

STEP PASSED

STEP 74 - Adding video encoder configuration [token = 'venc2'] to profile [token = 'profile2']

STEP PASSED

STEP 75 - Get video encoder configuration options

STEP PASSED

STEP 76 - Get video encoder configuration options

STEP PASSED

STEP 77 - Validate H264 options

STEP PASSED

STEP 78 - Find highest and lowest resolutions for further testing

STEP PASSED

STEP 79 - Setting video encoder configuration

STEP PASSED

STEP 80 - Getting video encoder configuration

STEP PASSED

STEP 81 - Check that the DUT accepted values passed

STEP PASSED

STEP 82 - Get Stream URI

STEP PASSED

STEP 83 - Getting media service address

STEP PASSED

STEP 84 - Check if the stream uri has correct IP type

STEP PASSED

STEP 85 - Check if the stream uri has the scheme equal to 'rtsp'

STEP PASSED

STEP 86 - Checking filters

STEP PASSED

STEP 87 - Enter CLiveCapsule::Prepare

STEP PASSED

STEP 88 - Describe

STEP PASSED

STEP 89 - Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 90 - Create Media Session

STEP PASSED

STEP 91 - Setup

STEP PASSED

STEP 92 - Create Sinks

STEP PASSED

STEP 93 - Play

STEP PASSED

STEP 94 - Waiting for 12 frames up to 1000 ms

STEP PASSED

STEP 95 - Checking actual resolution

STEP PASSED

STEP 96 - Teardown

STEP PASSED

STEP 97 - Setting video encoder configuration

STEP PASSED

STEP 98 - Getting video encoder configuration

STEP PASSED

STEP 99 - Check that the DUT accepted values passed

STEP PASSED

STEP 100 - Get Stream URI

STEP PASSED

STEP 101 - Getting media service address

STEP PASSED

STEP 102 - Check if the stream uri has correct IP type

STEP PASSED

STEP 103 - Check if the stream uri has the scheme equal to 'rtsp'

STEP PASSED

STEP 104 - Checking filters

STEP PASSED

STEP 105 - Enter CLiveCapsule::Prepare

STEP PASSED

STEP 106 - Describe

STEP PASSED

STEP 107 - Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 108 - Create Media Session

STEP PASSED

STEP 109 - Setup

STEP PASSED

STEP 110 - Create Sinks

STEP PASSED

STEP 111 - Play

STEP PASSED

STEP 112 - Waiting for 12 frames up to 1000 ms

STEP PASSED

STEP 113 - Checking actual resolution

STEP PASSED

STEP 114 - Teardown

STEP PASSED

STEP 115 - Setting video encoder configuration

STEP PASSED

STEP 116 - Getting video encoder configuration

STEP PASSED

STEP 117 - Check that the DUT accepted values passed

STEP PASSED

STEP 118 - Get Stream URI

STEP PASSED

STEP 119 - Getting media service address

STEP PASSED

STEP 120 - Check if the stream uri has correct IP type

STEP PASSED

STEP 121 - Check if the stream uri has the scheme equal to 'rtsp'

STEP PASSED

STEP 122 - Checking filters

STEP PASSED

STEP 123 - Enter CLiveCapsule::Prepare

STEP PASSED

STEP 124 - Describe

STEP PASSED

STEP 125 - Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 126 - Create Media Session

STEP PASSED

STEP 127 - Setup

STEP PASSED

STEP 128 - Create Sinks

STEP PASSED

STEP 129 - Play

STEP PASSED

STEP 130 - Waiting for 12 frames up to 1000 ms

STEP PASSED

STEP 131 - Checking actual resolution

STEP PASSED

STEP 132 - Teardown

STEP PASSED

STEP 133 - Getting media profiles

STEP PASSED

STEP 134 - Check if the DUT returned any profiles

STEP PASSED

STEP 135 - Create profile for test

STEP PASSED

STEP 136 - Check that profile has been created properly

STEP PASSED

STEP 137 - Getting video source configurations compatible with profile [token = 'profile3']

STEP PASSED

STEP 138 - Check if there are compatible Video Source Configurationss at the DUT

STEP PASSED

STEP 139 - Adding video source configuration [token = 'vsrc1'] to profile [token = 'profile3']

STEP PASSED

STEP 140 - Getting video encoder configurations compatible with profile [token = 'profile3']

STEP PASSED

STEP 141 - Adding video encoder configuration [token = 'venc3'] to profile [token = 'profile3']

STEP PASSED

STEP 142 - Get video encoder configuration options

STEP PASSED

STEP 143 - Get video encoder configuration options

STEP PASSED

STEP 144 - Validate H264 options

STEP PASSED

STEP 145 - Find highest and lowest resolutions for further testing

STEP PASSED

STEP 146 - Setting video encoder configuration

STEP PASSED

STEP 147 - Getting video encoder configuration

STEP PASSED

STEP 148 - Check that the DUT accepted values passed

STEP PASSED

STEP 149 - Get Stream URI

STEP PASSED

STEP 150 - Getting media service address

STEP PASSED

STEP 151 - Check if the stream uri has correct IP type

STEP PASSED

STEP 152 - Check if the stream uri has the scheme equal to 'rtsp'

STEP PASSED

STEP 153 - Checking filters

STEP PASSED

STEP 154 - Enter CLiveCapsule::Prepare

STEP PASSED

STEP 155 - Describe

STEP PASSED

STEP 156 - Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 157 - Create Media Session

STEP PASSED

STEP 158 - Setup

STEP PASSED

STEP 159 - Create Sinks

STEP PASSED

STEP 160 - Play

STEP PASSED

STEP 161 - Waiting for 12 frames up to 1000 ms

STEP PASSED

STEP 162 - Checking actual resolution

STEP PASSED

STEP 163 - Teardown

STEP PASSED

STEP 164 - Setting video encoder configuration

STEP PASSED

STEP 165 - Getting video encoder configuration

STEP PASSED

STEP 166 - Check that the DUT accepted values passed

STEP PASSED

STEP 167 - Get Stream URI

STEP PASSED

STEP 168 - Getting media service address

STEP PASSED

STEP 169 - Check if the stream uri has correct IP type

STEP PASSED

STEP 170 - Check if the stream uri has the scheme equal to 'rtsp'

STEP PASSED

STEP 171 - Checking filters

STEP PASSED

STEP 172 - Enter CLiveCapsule::Prepare

STEP PASSED

STEP 173 - Describe

STEP PASSED

STEP 174 - Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 175 - Create Media Session

STEP PASSED

STEP 176 - Setup

STEP PASSED

STEP 177 - Create Sinks

STEP PASSED

STEP 178 - Play

STEP PASSED

STEP 179 - Waiting for 12 frames up to 1000 ms

STEP PASSED

STEP 180 - Checking actual resolution

STEP PASSED

STEP 181 - Teardown

STEP PASSED

STEP 182 - Setting video encoder configuration

STEP PASSED

STEP 183 - Getting video encoder configuration

STEP PASSED

STEP 184 - Check that the DUT accepted values passed

STEP PASSED

STEP 185 - Get Stream URI

STEP PASSED

STEP 186 - Getting media service address

STEP PASSED

STEP 187 - Check if the stream uri has correct IP type

STEP PASSED

STEP 188 - Check if the stream uri has the scheme equal to 'rtsp'

STEP PASSED

STEP 189 - Checking filters

STEP PASSED

STEP 190 - Enter CLiveCapsule::Prepare

STEP PASSED

STEP 191 - Describe

STEP PASSED

STEP 192 - Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 193 - Create Media Session

STEP PASSED

STEP 194 - Setup

STEP PASSED

STEP 195 - Create Sinks

STEP PASSED

STEP 196 - Play

STEP PASSED

STEP 197 - Waiting for 12 frames up to 1000 ms

STEP PASSED

STEP 198 - Checking actual resolution

STEP PASSED

STEP 199 - Teardown

STEP PASSED

STEP 200 - Deleting media profile [token = 'profile2']

STEP PASSED

STEP 201 - Deleting media profile [token = 'profile3']

STEP PASSED

STEP 202 - Setting video encoder configuration

STEP PASSED

STEP 203 - Setting video encoder configuration

STEP PASSED

STEP 204 - Setting video encoder configuration

STEP PASSED

TEST PASSED

RTSS-1-1-53-v19.12 MEDIA STREAMING – JPEG (VALIDATING RTP HEADER EXTENSION)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting media profiles

STEP PASSED

STEP 4 - Check if the DUT returned any profiles

STEP PASSED

STEP 5 - Get video encoder configuration options

STEP PASSED

STEP 6 - Check if required profile found

STEP PASSED

STEP 7 - Select high resolution

STEP PASSED

STEP 8 - Setting video encoder configuration

STEP PASSED

STEP 9 - Get Stream URI

STEP PASSED

STEP 10 - Getting media service address

STEP PASSED

STEP 11 - Check if the stream uri has correct IP type

STEP PASSED

STEP 12 - Check if the stream uri has the scheme equal to 'rtsp'

STEP PASSED

STEP 13 - Checking filters

STEP PASSED

STEP 14 - Enter CLiveCapsule::Prepare

STEP PASSED

STEP 15 - Describe

STEP PASSED

STEP 16 - Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 17 - Create Media Session

STEP PASSED

STEP 18 - Setup

STEP PASSED

STEP 19 - Create Sinks

STEP PASSED

STEP 20 - Play

STEP PASSED

STEP 21 - Waiting for 12 frames up to 1000 ms

STEP PASSED

STEP 22 - Checking extension packets

STEP PASSED

STEP 23 - Checking actual resolution

STEP PASSED

STEP 24 - Teardown

STEP PASSED

STEP 25 - Setting video encoder configuration

STEP PASSED

TEST PASSED

RTSS-2-1-19-v19.12 MEDIA STREAMING – G.711 (RTP-Unicast/UDP)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting media profiles

STEP PASSED

STEP 4 - Creating media profile [name = 'TestProfileX']

STEP PASSED

STEP 5 - Getting audio source configurations compatible with profile [token = 'profile2']

STEP PASSED

STEP 6 - Check that the DUT returned Audio Source Configurations

STEP PASSED

STEP 7 - Adding audio source configuration [token = 'asrc1'] to profile [token = 'profile2']

STEP PASSED

STEP 8 - Getting audio encoder configurations compatible with profile [token = 'profile2']

STEP PASSED

STEP 9 - Get audio encoder configuration options

STEP PASSED

STEP 10 - Adding audio encoder configuration [token = 'aenc1'] to profile [token = 'profile2']

STEP PASSED

STEP 11 - Setting audio encoder configuration

STEP PASSED

STEP 12 - Getting video source configurations compatible with profile [token = 'profile2']

STEP PASSED

STEP 13 - Adding video source configuration [token = 'vsrc1'] to profile [token = 'profile2']

STEP PASSED

STEP 14 - Getting video encoder configurations compatible with profile [token = 'profile2']

STEP PASSED

STEP 15 - Adding video encoder configuration [token = 'venc1'] to profile [token = 'profile2']

STEP PASSED

STEP 16 - Check that profile with Audio Source Configuration, Audio Encoder Configuration with required encoder, Video Source Configuration and Video Encoder Configuration was configured

STEP PASSED

STEP 17 - Get audio encoder configuration options

STEP PASSED

STEP 18 - Setting audio encoder configuration

STEP PASSED

STEP 19 - Get Stream URI

STEP PASSED

STEP 20 - Getting media service address

STEP PASSED

STEP 21 - Check if the stream uri has correct IP type

STEP PASSED

STEP 22 - Check if the stream uri has the scheme equal to 'rtsp'

STEP PASSED

STEP 23 - Checking filters

STEP PASSED

STEP 24 - Enter CLiveCapsule::Prepare

STEP PASSED

STEP 25 - Describe

STEP PASSED

STEP 26 - Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 27 - Create Media Session

STEP PASSED

STEP 28 - Setup

STEP PASSED

STEP 29 - Create Sinks

STEP PASSED

STEP 30 - Play

STEP PASSED

STEP 31 - Waiting for 10 seconds

STEP PASSED

STEP 32 - Checking media frames count

STEP PASSED

STEP 33 - Teardown

STEP PASSED

STEP 34 - Deleting media profile [token = 'profile2']

STEP PASSED

STEP 35 - Setting audio encoder configuration

STEP PASSED

TEST PASSED

RTSS-2-1-20-v19.12 MEDIA STREAMING – G.711 (RTP-Unicast/RTSP/HTTP/TCP)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting media profiles

STEP PASSED

STEP 4 - Creating media profile [name = 'TestProfileX']

STEP PASSED

STEP 5 - Getting audio source configurations compatible with profile [token = 'profile2']

STEP PASSED

STEP 6 - Check that the DUT returned Audio Source Configurations

STEP PASSED

STEP 7 - Adding audio source configuration [token = 'asrc1'] to profile [token = 'profile2']

STEP PASSED

STEP 8 - Getting audio encoder configurations compatible with profile [token = 'profile2']

STEP PASSED

STEP 9 - Get audio encoder configuration options

STEP PASSED

STEP 10 - Adding audio encoder configuration [token = 'aenc1'] to profile [token = 'profile2']

STEP PASSED

STEP 11 - Setting audio encoder configuration

STEP PASSED

STEP 12 - Getting video source configurations compatible with profile [token = 'profile2']

STEP PASSED

STEP 13 - Adding video source configuration [token = 'vsrc1'] to profile [token = 'profile2']

STEP PASSED

STEP 14 - Getting video encoder configurations compatible with profile [token = 'profile2']

STEP PASSED

STEP 15 - Adding video encoder configuration [token = 'venc1'] to profile [token = 'profile2']

STEP PASSED

STEP 16 - Check that profile with Audio Source Configuration, Audio Encoder Configuration with required encoder, Video Source Configuration and Video Encoder Configuration was configured

STEP PASSED

STEP 17 - Get audio encoder configuration options

STEP PASSED

STEP 18 - Setting audio encoder configuration

STEP PASSED

STEP 19 - Get Stream URI

STEP PASSED

STEP 20 - Getting media service address

STEP PASSED

STEP 21 - Check if the stream uri has correct IP type

STEP PASSED

STEP 22 - Check if the stream uri has the same scheme with the web service

STEP PASSED

STEP 23 - Checking filters

STEP PASSED

STEP 24 - Enter CLiveCapsule::Prepare

STEP PASSED

STEP 25 - Describe

STEP PASSED

STEP 26 - Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 27 - Create Media Session

STEP PASSED

STEP 28 - Setup

STEP PASSED

STEP 29 - Create Sinks

STEP PASSED

STEP 30 - Play

STEP PASSED

STEP 31 - Waiting for 10 seconds

STEP PASSED

STEP 32 - Checking media frames count

STEP PASSED

STEP 33 - Teardown

STEP PASSED

STEP 34 - Deleting media profile [token = 'profile2']

STEP PASSED

STEP 35 - Setting audio encoder configuration

STEP PASSED

TEST PASSED

RTSS-2-1-21-v19.12 MEDIA STREAMING – G.711 (RTP/RTSP/TCP)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting media profiles

STEP PASSED

STEP 4 - Creating media profile [name = 'TestProfileX']

STEP PASSED

STEP 5 - Getting audio source configurations compatible with profile [token = 'profile2']

STEP PASSED

STEP 6 - Check that the DUT returned Audio Source Configurations

STEP PASSED

STEP 7 - Adding audio source configuration [token = 'asrc1'] to profile [token = 'profile2']

STEP PASSED

STEP 8 - Getting audio encoder configurations compatible with profile [token = 'profile2']

STEP PASSED

STEP 9 - Get audio encoder configuration options

STEP PASSED

STEP 10 - Adding audio encoder configuration [token = 'aenc1'] to profile [token = 'profile2']

STEP PASSED

STEP 11 - Setting audio encoder configuration

STEP PASSED

STEP 12 - Getting video source configurations compatible with profile [token = 'profile2']

STEP PASSED

STEP 13 - Adding video source configuration [token = 'vsrc1'] to profile [token = 'profile2']

STEP PASSED

STEP 14 - Getting video encoder configurations compatible with profile [token = 'profile2']

STEP PASSED

STEP 15 - Adding video encoder configuration [token = 'venc1'] to profile [token = 'profile2']

STEP PASSED

STEP 16 - Check that profile with Audio Source Configuration, Audio Encoder Configuration with required encoder, Video Source Configuration and Video Encoder Configuration was configured

STEP PASSED

STEP 17 - Get audio encoder configuration options

STEP PASSED

STEP 18 - Setting audio encoder configuration

STEP PASSED

STEP 19 - Get Stream URI

STEP PASSED

STEP 20 - Getting media service address

STEP PASSED

STEP 21 - Check if the stream uri has correct IP type

STEP PASSED

STEP 22 - Check if the stream uri has the scheme equal to 'rtsp'

STEP PASSED

STEP 23 - Checking filters

STEP PASSED

STEP 24 - Enter CLiveCapsule::Prepare

STEP PASSED

STEP 25 - Describe

STEP PASSED

STEP 26 - Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 27 - Create Media Session

STEP PASSED

STEP 28 - Setup

STEP PASSED

STEP 29 - Create Sinks

STEP PASSED

STEP 30 - Play

STEP PASSED

STEP 31 - Waiting for 10 seconds

STEP PASSED

STEP 32 - Checking media frames count

STEP PASSED

STEP 33 - Teardown

STEP PASSED

STEP 34 - Deleting media profile [token = 'profile2']

STEP PASSED

STEP 35 - Setting audio encoder configuration

STEP PASSED

TEST PASSED

RTSS-2-1-25-v19.12 MEDIA STREAMING – AAC (RTP-Unicast/UDP)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting media profiles

STEP PASSED

STEP 4 - Get audio encoder configuration options

STEP PASSED

STEP 5 - Setting audio encoder configuration

STEP PASSED

STEP 6 - Get Stream URI

STEP PASSED

STEP 7 - Getting media service address

STEP PASSED

STEP 8 - Check if the stream uri has correct IP type

STEP PASSED

STEP 9 - Check if the stream uri has the scheme equal to 'rtsp'

STEP PASSED

STEP 10 - Checking filters

STEP PASSED

STEP 11 - Enter CLiveCapsule::Prepare

STEP PASSED

STEP 12 - Describe

STEP PASSED

STEP 13 - Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 14 - Create Media Session

STEP PASSED

STEP 15 - Setup

STEP PASSED

STEP 16 - Create Sinks

STEP PASSED

STEP 17 - Play

STEP PASSED

STEP 18 - Waiting for 10 seconds

STEP PASSED

STEP 19 - Checking media frames count

STEP PASSED

STEP 20 - Teardown

STEP PASSED

STEP 21 - Setting audio encoder configuration

STEP PASSED

TEST PASSED

RTSS-2-1-26-v19.12 MEDIA STREAMING – AAC (RTP-Unicast/RTSP/HTTP/TCP)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting media profiles

STEP PASSED

STEP 4 - Get audio encoder configuration options

STEP PASSED

STEP 5 - Setting audio encoder configuration

STEP PASSED

STEP 6 - Get Stream URI

STEP PASSED

STEP 7 - Getting media service address

STEP PASSED

STEP 8 - Check if the stream uri has correct IP type

STEP PASSED

STEP 9 - Check if the stream uri has the same scheme with the web service

STEP PASSED

STEP 10 - Checking filters

STEP PASSED

STEP 11 - Enter CLiveCapsule::Prepare

STEP PASSED

STEP 12 - Describe

STEP PASSED

STEP 13 - Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 14 - Create Media Session

STEP PASSED

STEP 15 - Setup

STEP PASSED

STEP 16 - Create Sinks

STEP PASSED

STEP 17 - Play

STEP PASSED

STEP 18 - Waiting for 10 seconds

STEP PASSED

STEP 19 - Checking media frames count

STEP PASSED

STEP 20 - Teardown

STEP PASSED

STEP 21 - Setting audio encoder configuration

STEP PASSED

TEST PASSED

RTSS-2-1-27-v19.12 MEDIA STREAMING – AAC (RTP/RTSP/TCP)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting media profiles

STEP PASSED

STEP 4 - Get audio encoder configuration options

STEP PASSED

STEP 5 - Setting audio encoder configuration

STEP PASSED

STEP 6 - Get Stream URI

STEP PASSED

STEP 7 - Getting media service address

STEP PASSED

STEP 8 - Check if the stream uri has correct IP type

STEP PASSED

STEP 9 - Check if the stream uri has the scheme equal to 'rtsp'

STEP PASSED

STEP 10 - Checking filters

STEP PASSED

STEP 11 - Enter CLiveCapsule::Prepare

STEP PASSED

STEP 12 - Describe

STEP PASSED

STEP 13 - Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 14 - Create Media Session

STEP PASSED

STEP 15 - Setup

STEP PASSED

STEP 16 - Create Sinks

STEP PASSED

STEP 17 - Play

STEP PASSED

STEP 18 - Waiting for 10 seconds

STEP PASSED

STEP 19 - Checking media frames count

STEP PASSED

STEP 20 - Teardown

STEP PASSED

STEP 21 - Setting audio encoder configuration

STEP PASSED

TEST PASSED

RTSS-2-1-28-v19.12 AUDIO STREAMING – G.711 (RTP-Unicast/UDP)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Creating media profile [name = 'TestProfileX']

STEP PASSED

STEP 4 - Getting audio source configurations compatible with profile [token = 'profile2']

STEP PASSED

STEP 5 - Validating audio sources

STEP PASSED

STEP 6 - Adding audio source configuration [token = 'asrc1'] to profile [token = 'profile2']

STEP PASSED

STEP 7 - Getting audio encoder configurations compatible with profile [token = 'profile2']

STEP PASSED

STEP 8 - Validating audio encoder configurations

STEP PASSED

STEP 9 - Select audio encoder configuration with G.711 audio codec support

STEP PASSED

STEP 10 - Adding audio encoder configuration [token = 'aenc1'] to profile [token = 'profile2']

STEP PASSED

STEP 11 - Setting audio encoder configuration

STEP PASSED

STEP 12 - Get Stream URI

STEP PASSED

STEP 13 - Getting media service address

STEP PASSED

STEP 14 - Check if the stream uri has correct IP type

STEP PASSED

STEP 15 - Check if the stream uri has the scheme equal to 'rtsp'

STEP PASSED

STEP 16 - Validating of stream URI

STEP PASSED

STEP 17 - Checking filters

STEP PASSED

STEP 18 - Enter CLiveCapsule::Prepare

STEP PASSED

STEP 19 - Describe

STEP PASSED

STEP 20 - Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 21 - Create Media Session

STEP PASSED

STEP 22 - Setup

STEP PASSED

STEP 23 - Create Sinks

STEP PASSED

STEP 24 - Play

STEP PASSED

STEP 25 - Waiting for 10 seconds

STEP PASSED

STEP 26 - Checking media frames count

STEP PASSED

STEP 27 - Teardown

STEP PASSED

STEP 28 - Deleting media profile [token = 'profile2']

STEP PASSED

STEP 29 - Setting audio encoder configuration

STEP PASSED

TEST PASSED

RTSS-2-1-29-v19.12 AUDIO STREAMING – G.711 (RTP-Unicast/RTSP/HTTP/TCP)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Creating media profile [name = 'TestProfileX']

STEP PASSED

STEP 4 - Getting audio source configurations compatible with profile [token = 'profile2']

STEP PASSED

STEP 5 - Validating audio sources

STEP PASSED

STEP 6 - Adding audio source configuration [token = 'asrc1'] to profile [token = 'profile2']

STEP PASSED

STEP 7 - Getting audio encoder configurations compatible with profile [token = 'profile2']

STEP PASSED

STEP 8 - Validating audio encoder configurations

STEP PASSED

STEP 9 - Select audio encoder configuration with G.711 audio codec support

STEP PASSED

STEP 10 - Adding audio encoder configuration [token = 'aenc1'] to profile [token = 'profile2']

STEP PASSED

STEP 11 - Setting audio encoder configuration

STEP PASSED

STEP 12 - Get Stream URI

STEP PASSED

STEP 13 - Getting media service address

STEP PASSED

STEP 14 - Check if the stream uri has correct IP type

STEP PASSED

STEP 15 - Check if the stream uri has the same scheme with the web service

STEP PASSED

STEP 16 - Validating of stream URI

STEP PASSED

STEP 17 - Checking filters

STEP PASSED

STEP 18 - Enter CLiveCapsule::Prepare

STEP PASSED

STEP 19 - Describe

STEP PASSED

STEP 20 - Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 21 - Create Media Session

STEP PASSED

STEP 22 - Setup

STEP PASSED

STEP 23 - Create Sinks

STEP PASSED

STEP 24 - Play

STEP PASSED

STEP 25 - Waiting for 10 seconds

STEP PASSED

STEP 26 - Checking media frames count

STEP PASSED

STEP 27 - Teardown

STEP PASSED

STEP 28 - Deleting media profile [token = 'profile2']

STEP PASSED

STEP 29 - Setting audio encoder configuration

STEP PASSED

TEST PASSED

RTSS-2-1-30-v19.12 AUDIO STREAMING – G.711 (RTP/RTSP/TCP)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Creating media profile [name = 'TestProfileX']

STEP PASSED

STEP 4 - Getting audio source configurations compatible with profile [token = 'profile2']

STEP PASSED

STEP 5 - Validating audio sources

STEP PASSED

STEP 6 - Adding audio source configuration [token = 'asrc1'] to profile [token = 'profile2']

STEP PASSED

STEP 7 - Getting audio encoder configurations compatible with profile [token = 'profile2']

STEP PASSED

STEP 8 - Validating audio encoder configurations

STEP PASSED

STEP 9 - Select audio encoder configuration with G.711 audio codec support

STEP PASSED

STEP 10 - Adding audio encoder configuration [token = 'aenc1'] to profile [token = 'profile2']

STEP PASSED

STEP 11 - Setting audio encoder configuration

STEP PASSED

STEP 12 - Get Stream URI

STEP PASSED

STEP 13 - Getting media service address

STEP PASSED

STEP 14 - Check if the stream uri has correct IP type

STEP PASSED

STEP 15 - Check if the stream uri has the scheme equal to 'rtsp'

STEP PASSED

STEP 16 - Validating of stream URI

STEP PASSED

STEP 17 - Checking filters

STEP PASSED

STEP 18 - Enter CLiveCapsule::Prepare

STEP PASSED

STEP 19 - Describe

STEP PASSED

STEP 20 - Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 21 - Create Media Session

STEP PASSED

STEP 22 - Setup

STEP PASSED

STEP 23 - Create Sinks

STEP PASSED

STEP 24 - Play

STEP PASSED

STEP 25 - Waiting for 10 seconds

STEP PASSED

STEP 26 - Checking media frames count

STEP PASSED

STEP 27 - Teardown

STEP PASSED

STEP 28 - Deleting media profile [token = 'profile2']

STEP PASSED

STEP 29 - Setting audio encoder configuration

STEP PASSED

TEST PASSED

RTSS-2-1-34-v19.12 AUDIO STREAMING – AAC (RTP-Unicast/UDP)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Creating media profile [name = 'TestProfileX']

STEP PASSED

STEP 4 - Getting audio source configurations compatible with profile [token = 'profile2']

STEP PASSED

STEP 5 - Validating audio sources

STEP PASSED

STEP 6 - Adding audio source configuration [token = 'asrc1'] to profile [token = 'profile2']

STEP PASSED

STEP 7 - Getting audio encoder configurations compatible with profile [token = 'profile2']

STEP PASSED

STEP 8 - Validating audio encoder configurations

STEP PASSED

STEP 9 - Select audio encoder configuration with AAC audio codec support

STEP PASSED

STEP 10 - Adding audio encoder configuration [token = 'aenc1'] to profile [token = 'profile2']

STEP PASSED

STEP 11 - Setting audio encoder configuration

STEP PASSED

STEP 12 - Get Stream URI

STEP PASSED

STEP 13 - Getting media service address

STEP PASSED

STEP 14 - Check if the stream uri has correct IP type

STEP PASSED

STEP 15 - Check if the stream uri has the scheme equal to 'rtsp'

STEP PASSED

STEP 16 - Validating of stream URI

STEP PASSED

STEP 17 - Checking filters

STEP PASSED

STEP 18 - Enter CLiveCapsule::Prepare

STEP PASSED

STEP 19 - Describe

STEP PASSED

STEP 20 - Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 21 - Create Media Session

STEP PASSED

STEP 22 - Setup

STEP PASSED

STEP 23 - Create Sinks

STEP PASSED

STEP 24 - Play

STEP PASSED

STEP 25 - Waiting for 10 seconds

STEP PASSED

STEP 26 - Checking media frames count

STEP PASSED

STEP 27 - Teardown

STEP PASSED

STEP 28 - Deleting media profile [token = 'profile2']

STEP PASSED

STEP 29 - Setting audio encoder configuration

STEP PASSED

TEST PASSED

RTSS-2-1-35-v19.12 AUDIO STREAMING – AAC (RTP-Unicast/RTSP/HTTP/TCP)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Creating media profile [name = 'TestProfileX']

STEP PASSED

STEP 4 - Getting audio source configurations compatible with profile [token = 'profile2']

STEP PASSED

STEP 5 - Validating audio sources

STEP PASSED

STEP 6 - Adding audio source configuration [token = 'asrc1'] to profile [token = 'profile2']

STEP PASSED

STEP 7 - Getting audio encoder configurations compatible with profile [token = 'profile2']

STEP PASSED

STEP 8 - Validating audio encoder configurations

STEP PASSED

STEP 9 - Select audio encoder configuration with AAC audio codec support

STEP PASSED

STEP 10 - Adding audio encoder configuration [token = 'aenc1'] to profile [token = 'profile2']

STEP PASSED

STEP 11 - Setting audio encoder configuration

STEP PASSED

STEP 12 - Get Stream URI

STEP PASSED

STEP 13 - Getting media service address

STEP PASSED

STEP 14 - Check if the stream uri has correct IP type

STEP PASSED

STEP 15 - Check if the stream uri has the same scheme with the web service

STEP PASSED

STEP 16 - Validating of stream URI

STEP PASSED

STEP 17 - Checking filters

STEP PASSED

STEP 18 - Enter CLiveCapsule::Prepare

STEP PASSED

STEP 19 - Describe

STEP PASSED

STEP 20 - Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 21 - Create Media Session

STEP PASSED

STEP 22 - Setup

STEP PASSED

STEP 23 - Create Sinks

STEP PASSED

STEP 24 - Play

STEP PASSED

STEP 25 - Waiting for 10 seconds

STEP PASSED

STEP 26 - Checking media frames count

STEP PASSED

STEP 27 - Teardown

STEP PASSED

STEP 28 - Deleting media profile [token = 'profile2']

STEP PASSED

STEP 29 - Setting audio encoder configuration

STEP PASSED

TEST PASSED

RTSS-2-1-36-v19.12 AUDIO STREAMING – AAC (RTP/RTSP/TCP)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Creating media profile [name = 'TestProfileX']

STEP PASSED

STEP 4 - Getting audio source configurations compatible with profile [token = 'profile2']

STEP PASSED

STEP 5 - Validating audio sources

STEP PASSED

STEP 6 - Adding audio source configuration [token = 'asrc1'] to profile [token = 'profile2']

STEP PASSED

STEP 7 - Getting audio encoder configurations compatible with profile [token = 'profile2']

STEP PASSED

STEP 8 - Validating audio encoder configurations

STEP PASSED

STEP 9 - Select audio encoder configuration with AAC audio codec support

STEP PASSED

STEP 10 - Adding audio encoder configuration [token = 'aenc1'] to profile [token = 'profile2']

STEP PASSED

STEP 11 - Setting audio encoder configuration

STEP PASSED

STEP 12 - Get Stream URI

STEP PASSED

STEP 13 - Getting media service address

STEP PASSED

STEP 14 - Check if the stream uri has correct IP type

STEP PASSED

STEP 15 - Check if the stream uri has the scheme equal to 'rtsp'

STEP PASSED

STEP 16 - Validating of stream URI

STEP PASSED

STEP 17 - Checking filters

STEP PASSED

STEP 18 - Enter CLiveCapsule::Prepare

STEP PASSED

STEP 19 - Describe

STEP PASSED

STEP 20 - Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 21 - Create Media Session

STEP PASSED

STEP 22 - Setup

STEP PASSED

STEP 23 - Create Sinks

STEP PASSED

STEP 24 - Play

STEP PASSED

STEP 25 - Waiting for 10 seconds

STEP PASSED

STEP 26 - Checking media frames count

STEP PASSED

STEP 27 - Teardown

STEP PASSED

STEP 28 - Deleting media profile [token = 'profile2']

STEP PASSED

STEP 29 - Setting audio encoder configuration

STEP PASSED

TEST PASSED

RTSS-3-1-10-v19.12 MEDIA STREAMING – VIDEO AND G.711 AUDIO (RTP-Unicast/UDP)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting media profiles

STEP PASSED

STEP 4 - Creating media profile [name = 'TestProfileX']

STEP PASSED

STEP 5 - Getting audio source configurations compatible with profile [token = 'profile2']

STEP PASSED

STEP 6 - Check that the DUT returned Audio Source Configurations

STEP PASSED

STEP 7 - Adding audio source configuration [token = 'asrc1'] to profile [token = 'profile2']

STEP PASSED

STEP 8 - Getting audio encoder configurations compatible with profile [token = 'profile2']

STEP PASSED

STEP 9 - Get audio encoder configuration options

STEP PASSED

STEP 10 - Adding audio encoder configuration [token = 'aenc1'] to profile [token = 'profile2']

STEP PASSED

STEP 11 - Setting audio encoder configuration

STEP PASSED

STEP 12 - Getting video source configurations compatible with profile [token = 'profile2']

STEP PASSED

STEP 13 - Adding video source configuration [token = 'vsrc1'] to profile [token = 'profile2']

STEP PASSED

STEP 14 - Getting video encoder configurations compatible with profile [token = 'profile2']

STEP PASSED

STEP 15 - Adding video encoder configuration [token = 'venc1'] to profile [token = 'profile2']

STEP PASSED

STEP 16 - Check that profile with Audio Source Configuration, Audio Encoder Configuration with required encoder, Video Source Configuration and Video Encoder Configuration was configured

STEP PASSED

STEP 17 - Get video encoder configuration options

STEP PASSED

STEP 18 - Validate videoEncoderConfigurationOptions

STEP PASSED

STEP 19 - Setting video encoder configuration

STEP PASSED

STEP 20 - Setting audio encoder configuration

STEP PASSED

STEP 21 - Get Stream URI

STEP PASSED

STEP 22 - Getting media service address

STEP PASSED

STEP 23 - Check if the stream uri has correct IP type

STEP PASSED

STEP 24 - Check if the stream uri has the scheme equal to 'rtsp'

STEP PASSED

STEP 25 - Checking filters

STEP PASSED

STEP 26 - Enter CLiveCapsule::Prepare

STEP PASSED

STEP 27 - Describe

STEP PASSED

STEP 28 - Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 29 - Create Media Session

STEP PASSED

STEP 30 - Setup

STEP PASSED

STEP 31 - Setup

STEP PASSED

STEP 32 - Create Sinks

STEP PASSED

STEP 33 - Play

STEP PASSED

STEP 34 - Waiting for 12 frames up to 1000 ms

STEP PASSED

STEP 35 - Teardown

STEP PASSED

STEP 36 - Deleting media profile [token = 'profile2']

STEP PASSED

STEP 37 - Setting video encoder configuration

STEP PASSED

STEP 38 - Setting audio encoder configuration

STEP PASSED

TEST PASSED

RTSS-3-1-11-v19.12 MEDIA STREAMING – VIDEO AND G.711 AUDIO (RTP- Unicast/RTSP/HTTP/TCP)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting media profiles

STEP PASSED

STEP 4 - Creating media profile [name = 'TestProfileX']

STEP PASSED

STEP 5 - Getting audio source configurations compatible with profile [token = 'profile2']

STEP PASSED

STEP 6 - Check that the DUT returned Audio Source Configurations

STEP PASSED

STEP 7 - Adding audio source configuration [token = 'asrc1'] to profile [token = 'profile2']

STEP PASSED

STEP 8 - Getting audio encoder configurations compatible with profile [token = 'profile2']

STEP PASSED

STEP 9 - Get audio encoder configuration options

STEP PASSED

STEP 10 - Adding audio encoder configuration [token = 'aenc1'] to profile [token = 'profile2']

STEP PASSED

STEP 11 - Setting audio encoder configuration

STEP PASSED

STEP 12 - Getting video source configurations compatible with profile [token = 'profile2']

STEP PASSED

STEP 13 - Adding video source configuration [token = 'vsrc1'] to profile [token = 'profile2']

STEP PASSED

STEP 14 - Getting video encoder configurations compatible with profile [token = 'profile2']

STEP PASSED

STEP 15 - Adding video encoder configuration [token = 'venc1'] to profile [token = 'profile2']

STEP PASSED

STEP 16 - Check that profile with Audio Source Configuration, Audio Encoder Configuration with required encoder, Video Source Configuration and Video Encoder Configuration was configured

STEP PASSED

STEP 17 - Get video encoder configuration options

STEP PASSED

STEP 18 - Validate videoEncoderConfigurationOptions

STEP PASSED

STEP 19 - Setting video encoder configuration

STEP PASSED

STEP 20 - Setting audio encoder configuration

STEP PASSED

STEP 21 - Get Stream URI

STEP PASSED

STEP 22 - Getting media service address

STEP PASSED

STEP 23 - Check if the stream uri has correct IP type

STEP PASSED

STEP 24 - Check if the stream uri has the same scheme with the web service

STEP PASSED

STEP 25 - Checking filters

STEP PASSED

STEP 26 - Enter CLiveCapsule::Prepare

STEP PASSED

STEP 27 - Describe

STEP PASSED

STEP 28 - Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 29 - Create Media Session

STEP PASSED

STEP 30 - Setup

STEP PASSED

STEP 31 - Setup

STEP PASSED

STEP 32 - Create Sinks

STEP PASSED

STEP 33 - Play

STEP PASSED

STEP 34 - Waiting for 12 frames up to 1000 ms

STEP PASSED

STEP 35 - Teardown

STEP PASSED

STEP 36 - Deleting media profile [token = 'profile2']

STEP PASSED

STEP 37 - Setting video encoder configuration

STEP PASSED

STEP 38 - Setting audio encoder configuration

STEP PASSED

TEST PASSED

RTSS-3-1-12-v19.12 MEDIA STREAMING – VIDEO AND G.711 AUDIO (RTP/RTSP/TCP)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting media profiles

STEP PASSED

STEP 4 - Creating media profile [name = 'TestProfileX']

STEP PASSED

STEP 5 - Getting audio source configurations compatible with profile [token = 'profile2']

STEP PASSED

STEP 6 - Check that the DUT returned Audio Source Configurations

STEP PASSED

STEP 7 - Adding audio source configuration [token = 'asrc1'] to profile [token = 'profile2']

STEP PASSED

STEP 8 - Getting audio encoder configurations compatible with profile [token = 'profile2']

STEP PASSED

STEP 9 - Get audio encoder configuration options

STEP PASSED

STEP 10 - Adding audio encoder configuration [token = 'aenc1'] to profile [token = 'profile2']

STEP PASSED

STEP 11 - Setting audio encoder configuration

STEP PASSED

STEP 12 - Getting video source configurations compatible with profile [token = 'profile2']

STEP PASSED

STEP 13 - Adding video source configuration [token = 'vsrc1'] to profile [token = 'profile2']

STEP PASSED

STEP 14 - Getting video encoder configurations compatible with profile [token = 'profile2']

STEP PASSED

STEP 15 - Adding video encoder configuration [token = 'venc1'] to profile [token = 'profile2']

STEP PASSED

STEP 16 - Check that profile with Audio Source Configuration, Audio Encoder Configuration with required encoder, Video Source Configuration and Video Encoder Configuration was configured

STEP PASSED

STEP 17 - Get video encoder configuration options

STEP PASSED

STEP 18 - Validate videoEncoderConfigurationOptions

STEP PASSED

STEP 19 - Setting video encoder configuration

STEP PASSED

STEP 20 - Setting audio encoder configuration

STEP PASSED

STEP 21 - Get Stream URI

STEP PASSED

STEP 22 - Getting media service address

STEP PASSED

STEP 23 - Check if the stream uri has correct IP type

STEP PASSED

STEP 24 - Check if the stream uri has the scheme equal to 'rtsp'

STEP PASSED

STEP 25 - Checking filters

STEP PASSED

STEP 26 - Enter CLiveCapsule::Prepare

STEP PASSED

STEP 27 - Describe

STEP PASSED

STEP 28 - Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 29 - Create Media Session

STEP PASSED

STEP 30 - Setup

STEP PASSED

STEP 31 - Setup

STEP PASSED

STEP 32 - Create Sinks

STEP PASSED

STEP 33 - Play

STEP PASSED

STEP 34 - Waiting for 12 frames up to 1000 ms

STEP PASSED

STEP 35 - Teardown

STEP PASSED

STEP 36 - Deleting media profile [token = 'profile2']

STEP PASSED

STEP 37 - Setting video encoder configuration

STEP PASSED

STEP 38 - Setting audio encoder configuration

STEP PASSED

TEST PASSED

RTSS-3-1-16-v19.12 MEDIA STREAMING – VIDEO AND AAC AUDIO (RTP-Unicast/UDP)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting media profiles

STEP PASSED

STEP 4 - Get video encoder configuration options

STEP PASSED

STEP 5 - Validate videoEncoderConfigurationOptions

STEP PASSED

STEP 6 - Setting video encoder configuration

STEP PASSED

STEP 7 - Setting audio encoder configuration

STEP PASSED

STEP 8 - Get Stream URI

STEP PASSED

STEP 9 - Getting media service address

STEP PASSED

STEP 10 - Check if the stream uri has correct IP type

STEP PASSED

STEP 11 - Check if the stream uri has the scheme equal to 'rtsp'

STEP PASSED

STEP 12 - Checking filters

STEP PASSED

STEP 13 - Enter CLiveCapsule::Prepare

STEP PASSED

STEP 14 - Describe

STEP PASSED

STEP 15 - Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 16 - Create Media Session

STEP PASSED

STEP 17 - Setup

STEP PASSED

STEP 18 - Setup

STEP PASSED

STEP 19 - Create Sinks

STEP PASSED

STEP 20 - Play

STEP PASSED

STEP 21 - Waiting for 12 frames up to 1000 ms

STEP PASSED

STEP 22 - Teardown

STEP PASSED

STEP 23 - Setting video encoder configuration

STEP PASSED

STEP 24 - Setting audio encoder configuration

STEP PASSED

TEST PASSED

RTSS-3-1-17-v19.12 MEDIA STREAMING – VIDEO AND AAC AUDIO (RTP- Unicast/RTSP/HTTP/TCP)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting media profiles

STEP PASSED

STEP 4 - Get video encoder configuration options

STEP PASSED

STEP 5 - Validate videoEncoderConfigurationOptions

STEP PASSED

STEP 6 - Setting video encoder configuration

STEP PASSED

STEP 7 - Setting audio encoder configuration

STEP PASSED

STEP 8 - Get Stream URI

STEP PASSED

STEP 9 - Getting media service address

STEP PASSED

STEP 10 - Check if the stream uri has correct IP type

STEP PASSED

STEP 11 - Check if the stream uri has the same scheme with the web service

STEP PASSED

STEP 12 - Checking filters

STEP PASSED

STEP 13 - Enter CLiveCapsule::Prepare

STEP PASSED

STEP 14 - Describe

STEP PASSED

STEP 15 - Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 16 - Create Media Session

STEP PASSED

STEP 17 - Setup

STEP PASSED

STEP 18 - Setup

STEP PASSED

STEP 19 - Create Sinks

STEP PASSED

STEP 20 - Play

STEP PASSED

STEP 21 - Waiting for 12 frames up to 1000 ms

STEP PASSED

STEP 22 - Teardown

STEP PASSED

STEP 23 - Setting video encoder configuration

STEP PASSED

STEP 24 - Setting audio encoder configuration

STEP PASSED

TEST PASSED

RTSS-3-1-18-v19.12 MEDIA STREAMING – VIDEO AND AAC AUDIO (RTP/RTSP/TCP)

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Getting media profiles

STEP PASSED

STEP 4 - Get video encoder configuration options

STEP PASSED

STEP 5 - Validate videoEncoderConfigurationOptions

STEP PASSED

STEP 6 - Setting video encoder configuration

STEP PASSED

STEP 7 - Setting audio encoder configuration

STEP PASSED

STEP 8 - Get Stream URI

STEP PASSED

STEP 9 - Getting media service address

STEP PASSED

STEP 10 - Check if the stream uri has correct IP type

STEP PASSED

STEP 11 - Check if the stream uri has the scheme equal to 'rtsp'

STEP PASSED

STEP 12 - Checking filters

STEP PASSED

STEP 13 - Enter CLiveCapsule::Prepare

STEP PASSED

STEP 14 - Describe

STEP PASSED

STEP 15 - Check of IP address type in response to RTSP DESCRIBE

STEP PASSED

STEP 16 - Create Media Session

STEP PASSED

STEP 17 - Setup

STEP PASSED

STEP 18 - Setup

STEP PASSED

STEP 19 - Create Sinks

STEP PASSED

STEP 20 - Play

STEP PASSED

STEP 21 - Waiting for 12 frames up to 1000 ms

STEP PASSED

STEP 22 - Teardown

STEP PASSED

STEP 23 - Setting video encoder configuration

STEP PASSED

STEP 24 - Setting audio encoder configuration

STEP PASSED

TEST PASSED

RTSS-4-1-3-v19.12 NOTIFICATION STREAMING

TestResult

STEP 1 - Getting media service address

STEP PASSED

STEP 2 - Connect to Media service

STEP PASSED

STEP 3 - Create profile

STEP PASSED

STEP 4 - Validate new media profile

STEP PASSED

STEP 5 - Getting metadata configurations

STEP PASSED

STEP 6 - Deleting media profile [token = 'profile2']

STEP PASSED

TEST PASSED

Imaging

IMAGING-4-1-2-v18.06 REALTIME PULLPOINT SUBSCRIPTION – IMAGE TOO DARK

TestResult

STEP 1 - Get Device service address

STEP PASSED

STEP 2 - Check that the DUT returned Device service address

STEP PASSED

STEP 3 - Get Services

STEP PASSED

STEP 4 - Get Event Properties

STEP PASSED

STEP 5 - Check that the DUT returned at least one of the specified topics

STEP PASSED

STEP 6 - Checking description of event with topic tns1:VideoSource/ImageTooDark/ImagingService

STEP PASSED

STEP 7 - Create Pull Point Subscription

STEP PASSED

STEP 8 - Check that TerminationTime is specified

STEP PASSED

STEP 9 - Check that TerminationTime and CurrentTime has reasonable values

STEP PASSED

STEP 10 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 11 - Check if the DUT returned SubscriptionReference

STEP PASSED

STEP 12 - Check if SubscriptionReference contains address

STEP PASSED

STEP 13 - Check that URL specified is valid

STEP PASSED

STEP 14 - Send PullMessages request

STEP PASSED

STEP 15 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 16 - Check that a maximum number of 1 Notification Messages is included in PullMessagesResponse

STEP PASSED

STEP 17 - Response is not empty

STEP PASSED

STEP 18 - Waiting for notifications

STEP PASSED

STEP 19 - Send Unsubscribe request

STEP PASSED

TEST PASSED

IMAGING-4-1-5-v18.06 REALTIME PULLPOINT SUBSCRIPTION – MOTION ALARM

TestResult

STEP 1 - Get Device service address

STEP PASSED

STEP 2 - Check that the DUT returned Device service address

STEP PASSED

STEP 3 - Get Services

STEP PASSED

STEP 4 - Get Event Properties

STEP PASSED

STEP 5 - Check that the DUT returned at least one of the specified topics

STEP PASSED

STEP 6 - Checking description of event with topic tns1:VideoSource/MotionAlarm

STEP PASSED

STEP 7 - Create Pull Point Subscription

STEP PASSED

STEP 8 - Check that TerminationTime is specified

STEP PASSED

STEP 9 - Check that TerminationTime and CurrentTime has reasonable values

STEP PASSED

STEP 10 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 11 - Check if the DUT returned SubscriptionReference

STEP PASSED

STEP 12 - Check if SubscriptionReference contains address

STEP PASSED

STEP 13 - Check that URL specified is valid

STEP PASSED

STEP 14 - Send PullMessages request

STEP PASSED

STEP 15 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 16 - Check that a maximum number of 1 Notification Messages is included in PullMessagesResponse

STEP PASSED

STEP 17 - Response is not empty

STEP PASSED

STEP 18 - Waiting for notifications

STEP PASSED

STEP 19 - Send Unsubscribe request

STEP PASSED

TEST PASSED

Device I/O

DEVICEIO-2-1-1-v18.06 REALTIME PULLPOINT SUBSCRIPTION – DIGITAL INPUT EVENT

TestResult

STEP 1 - Get Event service address

STEP PASSED

STEP 2 - Get Event Properties

STEP PASSED

STEP 3 - Check that event with topic tns1:Device/Trigger/DigitalInput is present

STEP PASSED

STEP 4 - Checking description of event with topic tns1:Device/Trigger/DigitalInput

STEP PASSED

STEP 5 - Create Pull Point Subscription

STEP PASSED

STEP 6 - Check that TerminationTime is specified

STEP PASSED

STEP 7 - Check that TerminationTime and CurrentTime has reasonable values

STEP PASSED

STEP 8 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 9 - Check if the DUT returned SubscriptionReference

STEP PASSED

STEP 10 - Check if SubscriptionReference contains address

STEP PASSED

STEP 11 - Check that URL specified is valid

STEP PASSED

STEP 12 - Send PullMessages request

STEP PASSED

STEP 13 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 14 - Check that a maximum number of 1 Notification Messages is included in PullMessagesResponse

STEP PASSED

STEP 15 - Response is not empty

STEP PASSED

STEP 16 - Waiting for notifications [Topic = 'tns1:Device/Trigger/DigitalInput', PropertyOperation = 'Initialized']

STEP PASSED

STEP 17 - Send Unsubscribe request

STEP PASSED

TEST PASSED

DEVICEIO-3-1-1-v17.01 GETDIGITALINPUTS

TestResult

STEP 1 - Get Device IO service address

STEP PASSED

STEP 2 - Get Digital Inputs

STEP PASSED

STEP 3 - Check the DUT return at least one DigitalInput item

STEP PASSED

TEST PASSED

DEVICEIO-3-1-2-v17.01 GETDIGITALINPUTS – VERIFY QUANTITY

TestResult

STEP 1 - Get Device IO service address

STEP PASSED

STEP 2 - Get Service Capabilities(Device I/O)

STEP PASSED

STEP 3 - Get Digital Inputs

STEP PASSED

STEP 4 - Check the DUT return at least one DigitalInput item

STEP PASSED

STEP 5 - Check that the number of items returned in the 'GetDigitalInputsResponse' by the DUT is the same as specified in Device I/O ServiceCapabilities.DigitalInputs

STEP PASSED

TEST PASSED

DEVICEIO-3-1-3-v17.12 I/O GET DIGITAL INPUT CONFIGURATION OPTIONS

TestResult

STEP 1 - Get Device IO service address

STEP PASSED

STEP 2 - Get Digital Inputs

STEP PASSED

STEP 3 - Check the DUT return at least one DigitalInput item

STEP PASSED

STEP 4 - Get Digital Input Configuration Options

STEP PASSED

STEP 5 - Get Digital Input Configuration Options

STEP PASSED

TEST PASSED

DEVICEIO-3-1-4-v17.12 I/O DIGITAL INPUT CONFIGURATION

TestResult

STEP 1 - Get Device IO service address

STEP PASSED

STEP 2 - Get Digital Inputs

STEP PASSED

STEP 3 - Check the DUT return at least one DigitalInput item

STEP PASSED

STEP 4 - Get Digital Input Configuration Options

STEP PASSED

STEP 5 - Set Digital Input Configurations

STEP PASSED

STEP 6 - Get Digital Inputs

STEP PASSED

STEP 7 - Check the DUT return at least one DigitalInput item

STEP PASSED

STEP 8 - Check the DUT successfully changed value of 'IdleState' field

STEP PASSED

TEST PASSED

DEVICEIO-5-1-1-v17.12 GET VIDEOSOURCES (DeviceIO) AND GET VIDEOSOURCES (Media) CONSISTENCY

TestResult

STEP 1 - Get Device service address

STEP PASSED

STEP 2 - Check that the DUT returned Device service address

STEP PASSED

STEP 3 - Get Services

STEP PASSED

STEP 4 - Get Device I/O service address

STEP PASSED

STEP 5 - Check that the DUT returned Device I/O service address

STEP PASSED

STEP 6 - Get Video Sources

STEP PASSED

STEP 7 - Get Media service address

STEP PASSED

STEP 8 - Check that the DUT returned Media service address

STEP PASSED

STEP 9 - Get Video Sources

STEP PASSED

STEP 10 - Check if Media Service and DeviceIO Service returned the same Video Sources

STEP PASSED

TEST PASSED

Security Test Cases

SECURITY-1-1-1-v14.12 USER TOKEN PROFILE

TestResult

STEP 1 - Check if credentials were defined

STEP PASSED

STEP 2 - Sending request to the DUT with omitted Nonce

STEP PASSED

STEP 3 - Sending request to the DUT with omitted Created

STEP PASSED

STEP 4 - Sending request to the DUT with omitted Password/Type

STEP PASSED

STEP 5 - Sending valid request to the DUT

STEP PASSED

TEST PASSED

SECURITY-1-1-2-v14.12 DIGEST AUTHENTICATION

TestResult

STEP 1 - Check if credentials were defined

STEP PASSED

STEP 2 - Invoke GetDeviceInformation without credentials supplied

STEP PASSED

STEP 3 - Check response

STEP PASSED

STEP 4 - Sending valid request to the DUT

STEP PASSED

TEST PASSED

IP Configuration

IPCONFIG-1-1-3-v16.07 IPV4 DHCP

TestResult

STEP 1 - Get network interfaces

STEP PASSED

STEP 2 - Check that the DUT returned current interfaces

STEP PASSED

STEP 3 - Verifying IPv4 presence

STEP PASSED

STEP 4 - Waiting for Hello message...

STEP PASSED

STEP 5 - Set network interface

STEP PASSED

STEP 6 - Waiting for Hello message from the DUT

STEP PASSED

STEP 7 - 5 seconds timeout after Hello

STEP PASSED

STEP 8 - Waiting for Hello message...

STEP PASSED

STEP 9 - Waiting for Hello message from the DUT

STEP 10 - Verifying Hello message

STEP PASSED

STEP 11 - Identifying right address

STEP PASSED

STEP 12 - Get network interfaces

STEP PASSED

STEP 13 - Verifying appliance of IPv4 static settings

STEP PASSED

STEP 14 - Waiting for Hello message...

STEP PASSED

STEP 15 - Restore network settings

STEP PASSED

STEP 16 - Waiting for Hello message from the DUT

STEP PASSED

STEP 17 - 5 seconds timeout after Hello

STEP PASSED

STEP 18 - Waiting for Hello message...

STEP PASSED

STEP 19 - Waiting for Hello message from the DUT

STEP 20 - Verifying Hello message

STEP PASSED

STEP 21 - Identifying right address

STEP PASSED

TEST PASSED

Device Discovery

DISCOVERY-1-1-2-v16.01 HELLO MESSAGE VALIDATION

TestResult

STEP 1 - Send System Reboot message

STEP PASSED

STEP 2 - Waiting for Hello message...

STEP PASSED

STEP 3 - Waiting for Hello message from the DUT

STEP PASSED

STEP 4 - 5 seconds timeout after Hello

STEP PASSED

STEP 5 - Validating hello message

STEP PASSED

TEST PASSED

DISCOVERY-1-1-3-v14.12 SEARCH BASED ON DEVICE SCOPE TYPES

TestResult

STEP 1 - Get device scopes

STEP PASSED

STEP 2 - Validating device scopes

STEP PASSED

STEP 3 - Probe device

STEP PASSED

STEP 4 - Validate probe match

STEP PASSED

TEST PASSED

DISCOVERY-1-1-4-v14.12 SEARCH WITH OMITTED DEVICE AND SCOPE TYPES

TestResult

STEP 1 - Probe device

STEP PASSED

STEP 2 - Validate probe match

STEP PASSED

TEST PASSED

DISCOVERY-1-1-5-v14.12 RESPONSE TO INVALID SEARCH REQUEST

TestResult

STEP 1 - Probe device - negative test

STEP PASSED

TEST PASSED

DISCOVERY-1-1-6-v14.12 SEARCH USING UNICAST PROBE MESSAGE

TestResult

STEP 1 - Get device scopes

STEP PASSED

STEP 2 - Validating device scopes

STEP PASSED

STEP 3 - Probe device

STEP PASSED

STEP 4 - Validate probe match

STEP PASSED

STEP 5 - Probe device

STEP PASSED

STEP 6 - Validate probe match

STEP PASSED

STEP 7 - Probe device - negative test

STEP PASSED

TEST PASSED

DISCOVERY-1-1-8-v14.12 BYE MESSAGE

TestResult

STEP 1 - Waiting for Bye message...

STEP PASSED

STEP 2 - Reboot device

STEP PASSED

STEP 3 - Waiting for Bye message from the DUT

STEP PASSED

STEP 4 - Waiting for device to reboot

STEP PASSED

TEST PASSED

DISCOVERY-1-1-9-v14.12 DISCOVERY MODE CONFIGURATION

TestResult

STEP 1 - Get Discovery Mode

STEP PASSED

STEP 2 - Check current DiscoveryMode

STEP PASSED

STEP 3 - Set Discovery Mode

STEP PASSED

STEP 4 - Get Discovery Mode

STEP PASSED

STEP 5 - Check current DiscoveryMode

STEP PASSED

STEP 6 - Probe device - negative test

STEP PASSED

STEP 7 - Waiting for Bye or Hello message...

STEP PASSED

STEP 8 - Reboot device

STEP PASSED

STEP 9 - Waiting for Bye or Hello message from the DUT

STEP PASSED

STEP 10 - Set Discovery Mode

STEP PASSED

TEST PASSED

DISCOVERY-1-1-11-v14.12 DEVICE SCOPES CONFIGURATION

TestResult

STEP 1 - Get device scopes

STEP PASSED

STEP 2 - Set device scopes

STEP PASSED

STEP 3 - Waiting for Hello message...

STEP PASSED

STEP 4 - Add device scopes

STEP PASSED

STEP 5 - Waiting for Hello message from the DUT

STEP PASSED

STEP 6 - 5 seconds timeout after Hello

STEP PASSED

STEP 7 - Hello message validation

STEP PASSED

STEP 8 - Probe device

STEP PASSED

STEP 9 - Validate probe match

STEP PASSED

STEP 10 - Waiting for Hello message...

STEP PASSED

STEP 11 - Remove device scopes

STEP PASSED

STEP 12 - Waiting for Hello message from the DUT

STEP PASSED

STEP 13 - 5 seconds timeout after Hello

STEP PASSED

STEP 14 - Hello message validation

STEP PASSED

STEP 15 - Probe device - negative test

STEP PASSED

STEP 16 - Set device scopes

STEP PASSED

TEST PASSED

DISCOVERY-2-1-1-v14.12 DISCOVERY - NAMESPACES (DEFAULT NAMESPACES FOR EACH TAG)

TestResult

STEP 1 - Get device scopes

STEP PASSED

STEP 2 - Validating device scopes

STEP PASSED

STEP 3 - Probe device

STEP PASSED

STEP 4 - Validate probe match

STEP PASSED

TEST PASSED

DISCOVERY-2-1-2-v14.12 DISCOVERY - NAMESPACES (DEFAULT NAMESPACES FOR PARENT TAG)

TestResult

STEP 1 - Get device scopes

STEP PASSED

STEP 2 - Validating device scopes

STEP PASSED

STEP 3 - Probe device

STEP PASSED

STEP 4 - Validate probe match

STEP PASSED

TEST PASSED

DISCOVERY-2-1-3-v14.12 DISCOVERY - NAMESPACES (NOT STANDARD PREFIXES)

TestResult

STEP 1 - Get device scopes

STEP PASSED

STEP 2 - Validating device scopes

STEP PASSED

STEP 3 - Probe device

STEP PASSED

STEP 4 - Validate probe match

STEP PASSED

TEST PASSED

DISCOVERY-2-1-4-v14.12 DISCOVERY - NAMESPACES (DIFFERENT PREFIXES FOR THE SAME NAMESPACE)

TestResult

STEP 1 - Get device scopes

STEP PASSED

STEP 2 - Validating device scopes

STEP PASSED

STEP 3 - Probe device

STEP PASSED

STEP 4 - Validate probe match

STEP PASSED

TEST PASSED

DISCOVERY-2-1-5-v14.12 DISCOVERY - NAMESPACES (THE SAME PREFIX FOR DIFFERENT NAMESPACES)

TestResult

STEP 1 - Get device scopes

STEP PASSED

STEP 2 - Validating device scopes

STEP PASSED

STEP 3 - Probe device

STEP PASSED

STEP 4 - Validate probe match

STEP PASSED

TEST PASSED

Device Management

DEVICE-1-1-1-v14.12 GET WSDL URL

TestResult

STEP 1 - Get WSDL URL

STEP PASSED

STEP 2 - Validate URL returned (<http://www.onvif.org/onvif/ver10/device/wsdl/devicemgmt.wsdl>)

STEP PASSED

TEST PASSED

DEVICE-1-1-2-v14.12 ALL CAPABILITIES

TestResult

STEP 1 - Get capabilities

STEP PASSED

STEP 2 - Check capabilities

STEP PASSED

STEP 3 - Check that DUT returned Device capabilities

STEP PASSED

STEP 4 - Check that DUT returned Events capabilities

STEP PASSED

STEP 5 - Check that DUT returned Media capabilities

STEP PASSED

STEP 6 - Check that DUT returned DeviceIO capabilities

STEP PASSED

STEP 7 - Get capabilities

STEP PASSED

STEP 8 - Check capabilities

STEP PASSED

STEP 9 - Check that DUT returned Device capabilities

STEP PASSED

STEP 10 - Check that DUT returned Events capabilities

STEP PASSED

STEP 11 - Check that DUT returned Media capabilities

STEP PASSED

STEP 12 - Check that DUT returned DeviceIO capabilities

STEP PASSED

TEST PASSED

DEVICE-1-1-3-v14.12 DEVICE CAPABILITIES

TestResult

STEP 1 - Get capabilities

STEP PASSED

STEP 2 - Check that DUT returned capabilities

STEP PASSED

STEP 3 - Check that DUT returned device capabilities

STEP PASSED

STEP 4 - Validate device address (<http://192.168.1.5:8080/onvif/services>)

STEP PASSED

STEP 5 - Check that DUT returned network capabilities

STEP PASSED

STEP 6 - Check that DUT returned system capabilities

STEP PASSED

STEP 7 - Check that DUT did not return analytics capabilities

STEP PASSED

STEP 8 - Check that DUT did not return events capabilities

STEP PASSED

STEP 9 - Check that DUT did not return imaging capabilities

STEP PASSED

STEP 10 - Check that DUT did not return media capabilities

STEP PASSED

STEP 11 - Check that DUT did not return PTZ capabilities

STEP PASSED

STEP 12 - Check supported ONVIF versions

STEP PASSED

STEP 13 - Check that DUT returned IO capabilities

STEP PASSED

STEP 14 - Check that DUT returned security capabilities

STEP PASSED

TEST PASSED

DEVICE-1-1-4-v14.12 MEDIA CAPABILITIES

TestResult

STEP 1 - Get capabilities

STEP PASSED

STEP 2 - Check that DUT returned capabilities

STEP PASSED

STEP 3 - Check that DUT returned media capabilities

STEP PASSED

STEP 4 - Validate media address (<http://192.168.1.5:8080/onvif/services>)

STEP PASSED

STEP 5 - Check that DUT returned streaming capabilities

STEP PASSED

STEP 6 - Check that DUT did not return device capabilities

STEP PASSED

STEP 7 - Check that DUT did not return analytics capabilities

STEP PASSED

STEP 8 - Check that DUT did not return events capabilities

STEP PASSED

STEP 9 - Check that DUT did not return imaging capabilities

STEP PASSED

STEP 10 - Check that DUT did not return PTZ capabilities

STEP PASSED

TEST PASSED

DEVICE-1-1-5-v14.12 EVENT CAPABILITIES

TestResult

STEP 1 - Get capabilities

STEP PASSED

STEP 2 - Check that DUT returned capabilities

STEP PASSED

STEP 3 - Check that DUT returned events capabilities

STEP PASSED

STEP 4 - Validate events address (<http://192.168.1.5:8080/onvif/services>)

STEP PASSED

STEP 5 - Check that DUT did not return device capabilities

STEP PASSED

STEP 6 - Check that DUT did not return analytics capabilities

STEP PASSED

STEP 7 - Check that DUT did not return imaging capabilities

STEP PASSED

STEP 8 - Check that DUT did not return media capabilities

STEP PASSED

STEP 9 - Check that DUT did not return PTZ capabilities

STEP PASSED

TEST PASSED

DEVICE-1-1-6-v14.12 PTZ CAPABILITIES

TestResult

STEP 1 - Get PTZ Capabilities - negative test

STEP PASSED

TEST PASSED

DEVICE-1-1-9-v14.12 SOAP FAULT MESSAGE

TestResult

STEP 1 - Get capabilities

STEP PASSED

TEST PASSED

DEVICE-1-1-10-v14.12 IMAGING CAPABILITIES

TestResult

STEP 1 - Get Imaging Capabilities - negative test

STEP PASSED

TEST PASSED

DEVICE-1-1-11-v14.12 ANALYTICS CAPABILITIES

TestResult

STEP 1 - Get Analytics Capabilities - negative test

STEP PASSED

TEST PASSED

DEVICE-1-1-13-v14.12 GET SERVICES – DEVICE SERVICE

TestResult

STEP 1 - Get Services

STEP PASSED

STEP 2 - Check that DUT returned Device service address

STEP PASSED

STEP 3 - Check that no Capabilities returned

STEP PASSED

STEP 4 - Get Services

STEP PASSED

STEP 5 - Check that DUT returned Device service address

STEP PASSED

STEP 6 - Check that the DUT returned Capabilities element

STEP PASSED

STEP 7 - Check that Capabilities element is correct

STEP PASSED

TEST PASSED

DEVICE-1-1-14-v14.12 GET SERVICES – MEDIA SERVICE

TestResult

STEP 1 - Get Services

STEP PASSED

STEP 2 - Check that DUT returned Media service address

STEP PASSED

STEP 3 - Check that no Capabilities returned

STEP PASSED

STEP 4 - Get Services

STEP PASSED

STEP 5 - Check that DUT returned Media service address

STEP PASSED

STEP 6 - Check that the DUT returned Capabilities element

STEP PASSED

STEP 7 - Check that Capabilities element is correct

STEP PASSED

TEST PASSED

DEVICE-1-1-16-v14.12 GET SERVICES – EVENT SERVICE

TestResult

STEP 1 - Get Services

STEP PASSED

STEP 2 - Check that DUT returned Event service address

STEP PASSED

STEP 3 - Check that no Capabilities returned

STEP PASSED

STEP 4 - Get Services

STEP PASSED

STEP 5 - Check that DUT returned Event service address

STEP PASSED

STEP 6 - Check that the DUT returned Capabilities element

STEP PASSED

STEP 7 - Check that Capabilities element is correct

STEP PASSED

TEST PASSED

DEVICE-1-1-18-v14.12 DEVICE SERVICE CAPABILITIES

TestResult

STEP 1 - Get service capabilities

STEP PASSED

TEST PASSED

DEVICE-1-1-19-v14.12 GET SERVICES AND GET DEVICE SERVICE CAPABILITIES CONSISTENCY

TestResult

STEP 1 - Get Services

STEP PASSED

STEP 2 - Check that the DUT returned Device service information

STEP PASSED

STEP 3 - Check that the DUT returned Capabilities element

STEP PASSED

STEP 4 - Get service capabilities

STEP PASSED

STEP 5 - Parse Capabilities element in GetServices response

STEP PASSED

STEP 6 - Compare Capabilities

STEP PASSED

TEST PASSED

DEVICE-1-1-30-v17.06 GET SERVICES AND GET CAPABILITIES CONSISTENCY

TestResult

STEP 1 - Get Services

STEP PASSED

STEP 2 - Get capabilities

STEP PASSED

STEP 3 - Check that the DUT returned Device Management service information

STEP PASSED

STEP 4 - Check that the DUT returned Device Management service information

STEP PASSED

STEP 5 - Check that the DUT returned Capabilities element

STEP PASSED

STEP 6 - Parse Capabilities element in GetServices response

STEP PASSED

STEP 7 - Check that Network -> IPFilter capability has equal values in GetServices and in GetCapabilities response

STEP PASSED

STEP 8 - Check that Network -> ZeroConfiguration capability has equal values in GetServices and in GetCapabilities response

STEP PASSED

STEP 9 - Check that Network -> IPVersion6 capability has equal values in GetServices and in GetCapabilities response

STEP PASSED

STEP 10 - Check that Network -> DynDNS capability has equal values in GetServices and in GetCapabilities response

STEP PASSED

STEP 11 - Check that Network -> Dot11Configuration capability has equal values in GetServices and in GetCapabilities response

STEP PASSED

STEP 12 - Check that System -> DiscoveryResolve capability has equal values in GetServices and in GetCapabilities response

STEP PASSED

STEP 13 - Check that System -> DiscoveryBye capability has equal values in GetServices and in GetCapabilities response

STEP PASSED

STEP 14 - Check that System -> DiscoveryBye capability has equal values in GetServices and in GetCapabilities response

STEP PASSED

STEP 15 - Check that System -> RemoteDiscovery capability has equal values in GetServices and in GetCapabilities response

STEP PASSED

STEP 16 - Check that System -> SystemBackup capability has equal values in GetServices and in GetCapabilities response

STEP PASSED

STEP 17 - Check that System -> SystemLogging capability has equal values in GetServices and in GetCapabilities response

STEP PASSED

STEP 18 - Check that System -> FirmwareUpgrade capability has equal values in GetServices and in GetCapabilities response

STEP PASSED

STEP 19 - Check that System -> HttpFirmwareUpgrade capability has equal values in GetServices and in GetCapabilities response

STEP PASSED

STEP 20 - Check that System -> HttpSystemBackup capability has equal values in GetServices and in GetCapabilities response

STEP PASSED

STEP 21 - Check that System -> HttpSystemLogging capability has equal values in GetServices and in GetCapabilities response

STEP PASSED

STEP 22 - Check that System -> HttpSupportInformation capability has equal values in GetServices and in GetCapabilities response

STEP PASSED

STEP 23 - Check that Security -> TLS1.1 capability has equal values in GetServices and in GetCapabilities response

STEP PASSED

STEP 24 - Check that Security -> TLS1.2 capability has equal values in GetServices and in GetCapabilities response

STEP PASSED

STEP 25 - Check that Security -> OnboardKeyGeneration capability has equal values in GetServices and in GetCapabilities response

STEP PASSED

STEP 26 - Check that Security -> AccessPolicyConfig capability has equal values in GetServices and in GetCapabilities response

STEP PASSED

STEP 27 - Check that Security -> X.509Token capability has equal values in GetServices and in GetCapabilities response

STEP PASSED

STEP 28 - Check that Security -> SAMLToken capability has equal values in GetServices and in GetCapabilities response

STEP PASSED

STEP 29 - Check that Security -> KerberosToken capability has equal values in GetServices and in GetCapabilities response

STEP PASSED

STEP 30 - Check that Security -> RELToken capability has equal values in GetServices and in GetCapabilities response

STEP PASSED

STEP 31 - Check that Security -> TLS1.0 capability has equal values in GetServices and in GetCapabilities response

STEP PASSED

STEP 32 - Check that Security -> Dot1X capability has equal values in GetServices and in GetCapabilities response

STEP PASSED

STEP 33 - Check that Security -> SupportedEAPMethod capability has equal values in GetServices and in GetCapabilities response

STEP PASSED

STEP 34 - Check that Security -> RemoteUserHandling capability has equal values in GetServices and in GetCapabilities response

STEP PASSED

STEP 35 - Check that the DUT returned Events service information

STEP PASSED

STEP 36 - Check that the DUT returned Events service information

STEP PASSED

STEP 37 - Check that the DUT returned Capabilities element

STEP PASSED

STEP 38 - Parse Capabilities element in GetServices response

STEP PASSED

STEP 39 - Check that WSSubscriptionPolicySupport capability has equal values in GetServices and in GetCapabilities response

STEP PASSED

STEP 40 - Check that WSPullPointSupport capability has equal values in GetServices and in GetCapabilities response

STEP PASSED

STEP 41 - Check that WSPausableSubscriptionManagerInterfaceSupport capability has equal values in GetServices and in GetCapabilities response

STEP PASSED

STEP 42 - Check that the DUT returned Media service information

STEP PASSED

STEP 43 - Check that the DUT returned Capabilities element

STEP PASSED

STEP 44 - Parse Capabilities element in GetServices response

STEP PASSED

STEP 45 - Check that StreamingCapabilities -> RTPMulticast capability has equal values in GetServices and in GetCapabilities response

STEP PASSED

STEP 46 - Check that StreamingCapabilities -> RTP_TCP capability has equal values in GetServices and in GetCapabilities response

STEP PASSED

STEP 47 - Check that StreamingCapabilities -> RTP_RTSP_TCP capability has equal values in GetServices and in GetCapabilities response

STEP PASSED

STEP 48 - Check that ProfileCapabilities -> MaximumNumberOfProfiles capability has equal values in GetServices and in GetCapabilities response

STEP PASSED

STEP 49 - Check that the DUT returned DeviceIO service information

STEP PASSED

STEP 50 - Check that the DUT returned Capabilities element

STEP PASSED

STEP 51 - Parse Capabilities element in GetServices response

STEP PASSED

STEP 52 - Check that VideoSources capability has equal values in GetServices and in GetCapabilities response
STEP PASSED

STEP 53 - Check that VideoOutputs capability has equal values in GetServices and in GetCapabilities response
STEP PASSED

STEP 54 - Check that AudioSources capability has equal values in GetServices and in GetCapabilities response
STEP PASSED

STEP 55 - Check that AudioOutputs capability has equal values in GetServices and in GetCapabilities response
STEP PASSED

STEP 56 - Check that RelayOutputs capability has equal values in GetServices and in GetCapabilities response
STEP PASSED

TEST PASSED

DEVICE-1-1-31-v18.12 GET SERVICES - XADDR

TestResult

STEP 1 - Get Device service address
STEP PASSED

STEP 2 - Check that the DUT returned Device service address
STEP PASSED

STEP 3 - Get Services
STEP PASSED

STEP 4 - Check if the service with namespace "http://www.onvif.org/ver10/device/wsd" contains http address scheme
STEP PASSED

STEP 5 - Check if the service with namespace "http://www.onvif.org/ver10/device/wsd" contains authority component
STEP PASSED

STEP 6 - Check if the service with namespace "http://www.onvif.org/ver10/device/wsd" contains address 192.168.1.5
STEP PASSED

STEP 7 - Check if the service with namespace "http://www.onvif.org/ver10/device/wsd" contains address with port 8080
STEP PASSED

STEP 8 - Check if the service with namespace "http://www.onvif.org/ver10/media/wsd1" contains http address scheme
STEP PASSED

STEP 9 - Check if the service with namespace "http://www.onvif.org/ver10/media/wsd1" contains authority component
STEP PASSED

STEP 10 - Check if the service with namespace "http://www.onvif.org/ver10/media/wsd1" contains address 192.168.1.5
STEP PASSED

STEP 11 - Check if the service with namespace "http://www.onvif.org/ver10/media/wsd1" contains address with port 8080
STEP PASSED

STEP 12 - Check if the service with namespace "http://www.onvif.org/ver10/events/wsd1" contains http address scheme
STEP PASSED

STEP 13 - Check if the service with namespace "http://www.onvif.org/ver10/events/wsd1" contains authority component
STEP PASSED

STEP 14 - Check if the service with namespace "http://www.onvif.org/ver10/events/wsd1" contains address 192.168.1.5
STEP PASSED

STEP 15 - Check if the service with namespace "http://www.onvif.org/ver10/events/wsd1" contains address with port 8080
STEP PASSED

STEP 16 - Check if the service with namespace "http://www.onvif.org/ver10/deviceIO/wsd1" contains http address scheme
STEP PASSED

STEP 17 - Check if the service with namespace "http://www.onvif.org/ver10/deviceIO/wsd1" contains authority component
STEP PASSED

STEP 18 - Check if the service with namespace "http://www.onvif.org/ver10/deviceIO/wsd1" contains address 192.168.1.5
STEP PASSED

STEP 19 - Check if the service with namespace "http://www.onvif.org/ver10/deviceIO/wsd1" contains address with port 8080
STEP PASSED

TEST PASSED

DEVICE-2-1-1-v14.12 NETWORK COMMAND HOSTNAME CONFIGURATION

TestResult

STEP 1 - Get Hostname

STEP PASSED

STEP 2 - Check that hostname information returned from the DUT

STEP PASSED

STEP 3 - Validate hostname ('buildroot')

STEP PASSED

TEST PASSED

DEVICE-2-1-3-v14.12 NETWORK COMMAND SETHOSTNAME TEST ERROR CASE

TestResult

STEP 1 - Get Hostname

STEP PASSED

STEP 2 - Check that the DUT returned current hostname information

STEP PASSED

STEP 3 - Set Hostname - negative test

STEP PASSED

STEP 4 - Get Hostname

STEP PASSED

STEP 5 - Check that current hostname returned from the DUT

STEP PASSED

STEP 6 - Verify that hostname has not been changed

STEP PASSED

STEP 7 - Verify that FromDHCP has not been changed

STEP PASSED

TEST PASSED

DEVICE-2-1-4-v14.12 GET DNS CONFIGURATION

TestResult

STEP 1 - Get DNS configuration

STEP PASSED

STEP 2 - Check that DUT returned DNSInformation

STEP PASSED

STEP 3 - Validate DNS information

STEP PASSED

TEST PASSED

DEVICE-2-1-5-v14.12 SET DNS CONFIGURATION - SEARCHDOMAIN

TestResult

STEP 1 - Get DNS configuration

STEP PASSED

STEP 2 - Check that original DNS configuration returned from the DUT

STEP PASSED

STEP 3 - Set DNS configuration

STEP PASSED

STEP 4 - Wait 1.000 seconds to allow the DUT to apply settings

STEP PASSED

STEP 5 - Get DNS configuration

STEP PASSED

STEP 6 - Check that DNS configuration returned from the DUT

STEP PASSED

STEP 7 - Check that FromDHCP is false

STEP PASSED

STEP 8 - Check that the DUT returned Search Domains

STEP PASSED

STEP 9 - Validate SearchDomain value

STEP PASSED

STEP 10 - Restore DNS configuration

STEP PASSED

TEST PASSED

DEVICE-2-1-6-v14.12 SET DNS CONFIGURATION - DNSMANUAL IPV4

TestResult

STEP 1 - Get DNS configuration

STEP PASSED

STEP 2 - Check that original DNS configuration returned from the DUT

STEP PASSED

STEP 3 - Get network interfaces

STEP PASSED

STEP 4 - Check if DHCP must be turned off

STEP PASSED

STEP 5 - Set DNS configuration

STEP PASSED

STEP 6 - Wait 1.000 seconds to allow the DUT to apply settings

STEP PASSED

STEP 7 - Get DNS configuration

STEP PASSED

STEP 8 - Check that current DNS configuration returned from the DUT

STEP PASSED

STEP 9 - Check current DNS configuration

STEP PASSED

STEP 10 - Restore DNS configuration

STEP PASSED

TEST PASSED

DEVICE-2-1-8-v14.12 SET DNS CONFIGURATION - FROMDHCP

TestResult

STEP 1 - Get DNS configuration

STEP PASSED

STEP 2 - Check that valid DNS configuration returned from the DUT

STEP PASSED

STEP 3 - Get network interfaces

STEP PASSED

STEP 4 - Check if DHCP must be turned on

STEP PASSED

STEP 5 - Waiting for Hello message...

STEP PASSED

STEP 6 - Set network interface

STEP PASSED

STEP 7 - Waiting for Hello message from the DUT

STEP PASSED

STEP 8 - 5 seconds timeout after Hello

STEP PASSED

STEP 9 - Verifying Hello message

STEP PASSED

STEP 10 - Identifying right address

STEP PASSED

STEP 11 - Set DNS configuration

STEP PASSED

STEP 12 - Wait 1.000 seconds to allow the DUT to interact with DHCP server

STEP PASSED

STEP 13 - Get DNS configuration

STEP PASSED

STEP 14 - Check that original DNS configuration returned from the DUT

STEP PASSED

STEP 15 - Check that current DNS configuration returned from the DUT

STEP PASSED

STEP 16 - Check current DNS configuration

STEP PASSED

STEP 17 - Restore DNS configuration

STEP PASSED

STEP 18 - Waiting for Hello message...

STEP PASSED

STEP 19 - Restore network settings

STEP PASSED

STEP 20 - Waiting for Hello message from the DUT

STEP PASSED

STEP 21 - 5 seconds timeout after Hello

STEP PASSED

STEP 22 - Verifying Hello message

STEP PASSED

STEP 23 - Identifying right address

STEP PASSED

TEST PASSED

DEVICE-2-1-11-v14.12 GET NTP CONFIGURATION

TestResult

STEP 1 - Get NTP information

STEP PASSED

STEP 2 - Check that DUT returned NTP information

STEP PASSED

STEP 3 - Validate NTP information

STEP PASSED

TEST PASSED

DEVICE-2-1-12-v16.07 SET NTP CONFIGURATION - NTPMANUAL IPV4

TestResult

STEP 1 - Get NTP information

STEP PASSED

STEP 2 - Check that DUT returned NTP information

STEP PASSED

STEP 3 - Get network interfaces

STEP PASSED

STEP 4 - Check if DHCP must be turned off

STEP PASSED

STEP 5 - Set NTP configuration

STEP PASSED

STEP 6 - Get NTP information

STEP PASSED

STEP 7 - Check that DUT returned NTP information

STEP PASSED

STEP 8 - Validate current NTP configuration

STEP PASSED

STEP 9 - Restore NTP configuration

STEP PASSED

TEST PASSED

DEVICE-2-1-14-v14.12 SET NTP CONFIGURATION - FROMDHCP

TestResult

STEP 1 - Get NTP information

STEP PASSED

STEP 2 - Check that original NTP configuration returned from the DUT

STEP PASSED

STEP 3 - Get network interfaces

STEP PASSED

STEP 4 - Check if DHCP must be turned on

STEP PASSED

STEP 5 - Waiting for Hello message...

STEP PASSED

STEP 6 - Set network interface

STEP PASSED

STEP 7 - Waiting for Hello message from the DUT

STEP PASSED

STEP 8 - 5 seconds timeout after Hello

STEP PASSED

STEP 9 - Verifying Hello message

STEP PASSED

STEP 10 - Identifying right address

STEP PASSED

STEP 11 - Set NTP configuration

STEP PASSED

STEP 12 - Wait 1.000 seconds to allow the DUT to interact with DHCP server

STEP PASSED

STEP 13 - Get NTP information

STEP PASSED

STEP 14 - Check that current NTP configuration returned from the DUT

STEP PASSED

STEP 15 - Check current NTP configuration

STEP PASSED

STEP 16 - Waiting for Hello message...

STEP PASSED

STEP 17 - Restore network settings

STEP PASSED

STEP 18 - Waiting for Hello message from the DUT

STEP PASSED

STEP 19 - 5 seconds timeout after Hello

STEP PASSED

STEP 20 - Verifying Hello message

STEP PASSED

STEP 21 - Identifying right address

STEP PASSED

STEP 22 - Restore NTP configuration

STEP PASSED

TEST PASSED

DEVICE-2-1-17-v14.12 GET NETWORK INTERFACE CONFIGURATION

TestResult

STEP 1 - Get network interfaces

STEP PASSED

STEP 2 - Check if Network Interfaces returned from the DUT

STEP PASSED

TEST PASSED

DEVICE-2-1-18-v14.12 SET NETWORK INTERFACE CONFIGURATION - IPV4

TestResult

STEP 1 - Get network interfaces

STEP PASSED

STEP 2 - Check that the DUT returned current interfaces

STEP PASSED

STEP 3 - Verifying IPv4 presence

STEP PASSED

STEP 4 - Waiting for Hello message...

STEP PASSED

STEP 5 - Set network interface

STEP PASSED

STEP 6 - Waiting for Hello message from the DUT

STEP PASSED

STEP 7 - 5 seconds timeout after Hello

STEP PASSED

STEP 8 - Verifying Hello message

STEP PASSED

STEP 9 - Identifying right address

STEP PASSED

STEP 10 - Get network interfaces

STEP PASSED

STEP 11 - Verifying appliance of IPv4 static settings

STEP PASSED

STEP 12 - Waiting for Hello message...

STEP PASSED

STEP 13 - Restore network settings

STEP PASSED

STEP 14 - Waiting for Hello message from the DUT

STEP PASSED

STEP 15 - 5 seconds timeout after Hello

STEP PASSED

STEP 16 - Waiting for Hello message...

STEP PASSED

STEP 17 - Waiting for Hello message from the DUT

STEP 18 - Verifying Hello message

STEP PASSED

STEP 19 - Identifying right address

STEP PASSED

TEST PASSED

DEVICE-2-1-25-v14.12 GET NETWORK DEFAULT GATEWAY CONFIGURATION

TestResult

STEP 1 - Get Network Default Gateway

STEP PASSED

STEP 2 - Check if network default configuration returned

STEP PASSED

STEP 3 - Validate addresses

STEP PASSED

TEST PASSED

DEVICE-2-1-30-v14.12 SET NETWORK DEFAULT GATEWAY CONFIGURATION - IPV4

TestResult

STEP 1 - Get Network Default Gateway

STEP PASSED

STEP 2 - Check if original network default configuration returned

STEP PASSED

STEP 3 - Get network interfaces

STEP PASSED

STEP 4 - Check that the DUT returned current interfaces

STEP PASSED

STEP 5 - Set Network Default Gateway

STEP PASSED

STEP 6 - Get Network Default Gateway

STEP PASSED

STEP 7 - Check if IP address 192.168.1.1 is present in the list

STEP PASSED

STEP 8 - Set Network Default Gateway

STEP PASSED

TEST PASSED

DEVICE-2-1-32-v14.12 NETWORK COMMAND SETHOSTNAME TEST

TestResult

STEP 1 - Get Hostname

STEP PASSED

STEP 2 - Check that the DUT returned current hostname

STEP PASSED

STEP 3 - Set Hostname

STEP PASSED

STEP 4 - Get Hostname

STEP PASSED

STEP 5 - Check that the DUT returned current hostname

STEP PASSED

STEP 6 - Verify that hostname has been changed

STEP PASSED

STEP 7 - Verify that FromDHCP is false

STEP PASSED

STEP 8 - Restore hostname

STEP PASSED

TEST PASSED

DEVICE-2-1-33-v14.12 GET NETWORK PROTOCOLS CONFIGURATION

TestResult

STEP 1 - Get Network Protocols

STEP PASSED

STEP 2 - Check if network protocols returned from the DUT

STEP PASSED

STEP 3 - Check if RTSP is present in the list

STEP PASSED

STEP 4 - Check if HTTP is present in the list

STEP PASSED

TEST PASSED

DEVICE-2-1-34-v14.12 SET NETWORK PROTOCOLS CONFIGURATION

TestResult

STEP 1 - Get Network Protocols

STEP PASSED

STEP 2 - Check if network protocols returned from the DUT

STEP PASSED

STEP 3 - Set Network Protocols

STEP PASSED

STEP 4 - Get Network Protocols

STEP PASSED

STEP 5 - Check if network protocols returned from the DUT

STEP PASSED

STEP 6 - Validating protocols

STEP PASSED

STEP 7 - Set Network Protocols

STEP PASSED

STEP 8 - Get Network Protocols

STEP PASSED

STEP 9 - Check if network protocols returned from the DUT

STEP PASSED

STEP 10 - Validating protocols

STEP PASSED

STEP 11 - Set Network Protocols

STEP PASSED

TEST PASSED

DEVICE-2-1-35-v14.12 SET NETWORK PROTOCOLS CONFIGURATION - UNSUPPORTED
PROTOCOLS

TestResult

STEP 1 - Get Network Protocols

STEP PASSED

STEP 2 - Check if network protocols returned from the DUT

STEP PASSED

STEP 3 - Set Network Protocols - negative test

STEP PASSED

STEP 4 - Get Network Protocols

STEP PASSED

STEP 5 - Check if network protocols returned from the DUT

STEP PASSED

STEP 6 - Check network protocol's configurations

STEP PASSED

TEST PASSED

DEVICE-3-1-1-v14.12 SYSTEM COMMAND GETSYSTEMDATEANDTIME

TestResult

STEP 1 - Get system date and time

STEP PASSED

STEP 2 - Check that DUT returned date and time settings

STEP PASSED

STEP 3 - Validate TimeZone string

STEP PASSED

STEP 4 - Check if settings are self-consistent

STEP PASSED

STEP 5 - Validate LocalDateTime

STEP PASSED

STEP 6 - Validate UTCDateTime

STEP PASSED

TEST PASSED

DEVICE-3-1-4-v19.06 SYSTEM COMMAND SETSYSTEMDATEANDTIME TEST FOR INVALID TIMEZONE

TestResult

STEP 1 - Get system date and time

STEP PASSED

STEP 2 - Set system date and time - negative test

STEP PASSED

STEP 3 - Get system date and time

STEP PASSED

STEP 4 - Check that DUT returned date and time settings

STEP PASSED

STEP 5 - Check that DUT returned TimeZone settings

STEP PASSED

STEP 6 - Check if settings are self-consistent

STEP PASSED

STEP 7 - Validate LocalDateTime

STEP PASSED

STEP 8 - Validate UTCDateTime

STEP PASSED

STEP 9 - Synchronize time

STEP PASSED

TEST PASSED

DEVICE-3-1-5-v19.06 SYSTEM COMMAND SETSYSTEMDATEANDTIME TEST FOR INVALID DATE

TestResult

STEP 1 - Get system date and time

STEP PASSED

STEP 2 - Set system date and time - negative test

STEP PASSED

STEP 3 - Get system date and time

STEP PASSED

STEP 4 - Check that DUT returned date and time settings

STEP PASSED

STEP 5 - Validate TimeZone string

STEP PASSED

STEP 6 - Check if settings are self-consistent

STEP PASSED

STEP 7 - Validate LocalDateTime

STEP PASSED

STEP 8 - Validate UTCDateTime

STEP PASSED

STEP 9 - Synchronize time

STEP PASSED

TEST PASSED

DEVICE-3-1-7-v14.12 SYSTEM COMMAND FACTORY DEFAULT SOFT

TestResult

STEP 1 - Set System Factory Default

STEP PASSED

STEP 2 - Wait until Reboot Timeout expires (30.000 sec)

STEP PASSED

STEP 3 - Transmit multicast PROBE message

STEP PASSED

STEP 4 - Check that answer has been received

STEP PASSED

TEST PASSED

DEVICE-3-1-8-v16.01 SYSTEM COMMAND REBOOT

TestResult

STEP 1 - Send System Reboot message

STEP PASSED

STEP 2 - Waiting for Hello message...

STEP PASSED

STEP 3 - Waiting for Hello message from the DUT

STEP PASSED

STEP 4 - 5 seconds timeout after Hello

STEP PASSED

STEP 5 - Probe device

STEP PASSED

STEP 6 - Validate probe match

STEP PASSED

TEST PASSED

DEVICE-3-1-9-v14.12 SYSTEM COMMAND DEVICE INFORMATION

TestResult

STEP 1 - Get device information

STEP PASSED

STEP 2 - Check Manufacturer information

STEP PASSED

STEP 3 - Check Model information

STEP PASSED

STEP 4 - Check FirmwareVersion information

STEP PASSED

STEP 5 - Check SerialNumber information

STEP PASSED

STEP 6 - Check HardwareId information

STEP PASSED

TEST PASSED

DEVICE-3-1-11-v19.06 SYSTEM COMMAND SETSYSTEMDATEANDTIME

TestResult

STEP 1 - Get system date and time

STEP PASSED

STEP 2 - Set system date and time

STEP PASSED

STEP 3 - Get system date and time

STEP PASSED

STEP 4 - Check that DUT returned date and time settings

STEP PASSED

STEP 5 - Check that DateTimeType has been set.

STEP PASSED

STEP 6 - Check that DaylightSavings has been set.

STEP PASSED

STEP 7 - Check if settings are self-consistent

STEP PASSED

STEP 8 - Validate LocalDateTime

STEP PASSED

STEP 9 - Validate UTCDateTime

STEP PASSED

STEP 10 - Synchronize time

STEP PASSED

TEST PASSED

DEVICE-3-1-12-v19.06 SYSTEM COMMAND SETSYSTEMDATEANDTIME USING NTP

TestResult

STEP 1 - Get system date and time

STEP PASSED

STEP 2 - Get NTP information

STEP PASSED

STEP 3 - Set NTP configuration

STEP PASSED

STEP 4 - Set system date and time

STEP PASSED

STEP 5 - Get system date and time

STEP PASSED

STEP 6 - Check that DUT returned date and time settings

STEP PASSED

STEP 7 - Check that DateTimeType has been set.

STEP PASSED

STEP 8 - Check that DaylightSavings has been set.

STEP PASSED

STEP 9 - Check that DUT returned TimeZone settings

STEP PASSED

STEP 10 - Validate TimeZone

STEP PASSED

STEP 11 - Validate LocalDateTime

STEP PASSED

STEP 12 - Validate UTCDateTime

STEP PASSED

STEP 13 - Synchronize time

STEP PASSED

STEP 14 - Set NTP configuration

STEP PASSED

TEST PASSED

DEVICE-4-1-1-v14.12 SECURITY COMMAND GETUSERS

TestResult

STEP 1 - Get Users

STEP PASSED

STEP 2 - Validate response received

STEP PASSED

TEST PASSED

DEVICE-4-1-3-v14.12 SECURITY COMMAND CREATEUSERS ERROR CASE

TestResult

STEP 1 - Create users

STEP PASSED

STEP 2 - Get Users

STEP PASSED

STEP 3 - Check if the DUT returned users list

STEP PASSED

STEP 4 - Check if newly created user is present in the list

STEP PASSED

STEP 5 - Check if user has been created correctly

STEP PASSED

STEP 6 - Create User - Negative test

STEP PASSED

STEP 7 - Create User - Negative test

STEP PASSED

STEP 8 - Get Users

STEP PASSED

STEP 9 - Check if the DUT returned users list

STEP PASSED

STEP 10 - Check if no new users have been created

STEP PASSED

STEP 11 - Check if previously created user is present in the list

STEP PASSED

STEP 12 - Check if previously created user has correct level

STEP PASSED

STEP 13 - Delete users

STEP PASSED

TEST PASSED

DEVICE-4-1-4-v14.12 SECURITY COMMAND DELETEUSERS

TestResult

STEP 1 - Create users

STEP PASSED

STEP 2 - Get Users

STEP PASSED

STEP 3 - Check if the DUT returned users list

STEP PASSED

STEP 4 - Check condition

STEP PASSED

STEP 5 - Delete users

STEP PASSED

STEP 6 - Get Users

STEP PASSED

STEP 7 - Check if the DUT returned users list

STEP PASSED

STEP 8 - Check if the user has been deleted

STEP PASSED

STEP 9 - Delete users

STEP PASSED

STEP 10 - Get Users

STEP PASSED

STEP 11 - Check if the DUT returned users list

STEP PASSED

STEP 12 - Check if both users have been deleted

STEP PASSED

TEST PASSED

DEVICE-4-1-5-v14.12 SECURITY COMMAND DELETEUSERS ERROR CASE

TestResult

STEP 1 - Create users

STEP PASSED

STEP 2 - Delete Users - negative test

STEP PASSED

STEP 3 - Get Users

STEP PASSED

STEP 4 - Check if the DUT returned users list

STEP PASSED

STEP 5 - Check that the user OnvifTest1 has not been deleted

STEP PASSED

STEP 6 - Delete users

STEP PASSED

STEP 7 - Get Users

STEP PASSED

STEP 8 - Check if the DUT returned users list

STEP PASSED

STEP 9 - Check that the user OnvifTest1 has been deleted

STEP PASSED

TEST PASSED

DEVICE-4-1-7-v14.12 SECURITY COMMAND SETUSER

TestResult

STEP 1 - Create users

STEP PASSED

STEP 2 - Get Users

STEP PASSED

STEP 3 - Check if the DUT returned users list

STEP PASSED

STEP 4 - Set users

STEP PASSED

STEP 5 - Get Users

STEP PASSED

STEP 6 - Check if the DUT returned users list

STEP PASSED

STEP 7 - Check if the DUT returned modified users

STEP PASSED

STEP 8 - Set users

STEP PASSED

STEP 9 - Get Users

STEP PASSED

STEP 10 - Check if the DUT returned users list

STEP PASSED

STEP 11 - Check if the users have been modified correctly

STEP PASSED

STEP 12 - Delete users

STEP PASSED

TEST PASSED

DEVICE-4-1-8-v14.12 SECURITY COMMAND USER MANAGEMENT ERROR CASE

TestResult

STEP 1 - Create users

STEP PASSED

STEP 2 - Get Users

STEP PASSED

STEP 3 - Check if the DUT returned users list

STEP PASSED

STEP 4 - Set Users - negative test

STEP PASSED

STEP 5 - Get Users

STEP PASSED

STEP 6 - Check if the DUT returned users list

STEP PASSED

STEP 7 - Check if the user has not been modified

STEP PASSED

STEP 8 - Delete users

STEP PASSED

STEP 9 - Get Users

STEP PASSED

STEP 10 - Check if the DUT returned users list

STEP PASSED

TEST PASSED

DEVICE-4-1-9-v14.12 SECURITY COMMAND CREATEUSERS

TestResult

STEP 1 - Get Users

STEP PASSED

STEP 2 - Create users

STEP PASSED

STEP 3 - Get Users

STEP PASSED

STEP 4 - Check new user is created

STEP PASSED

STEP 5 - Create users

STEP PASSED

STEP 6 - Get Users

STEP PASSED

STEP 7 - Check new user is created

STEP PASSED

STEP 8 - Check new user is created

STEP PASSED

STEP 9 - Delete users

STEP PASSED

STEP 10 - Create users

STEP PASSED

STEP 11 - Get Users

STEP PASSED

STEP 12 - Check new user is created

STEP PASSED

STEP 13 - Delete users

STEP PASSED

STEP 14 - Check if a user with any parameters has been created

STEP PASSED

TEST PASSED

DEVICE-6-1-1-v14.12 DEVICE MANAGEMENT - NAMESPACES (DEFAULT NAMESPACES FOR EACH TAG)

TestResult

STEP 1 - Get DNS configuration

STEP PASSED

STEP 2 - Check that original DNS configuration returned from the DUT

STEP PASSED

STEP 3 - Set DNS configuration

STEP PASSED

STEP 4 - Wait 1.000 seconds to allow the DUT to apply settings

STEP PASSED

STEP 5 - Get DNS configuration

STEP PASSED

STEP 6 - Check that current DNS configuration returned from the DUT

STEP PASSED

STEP 7 - Check current DNS configuration

STEP PASSED

STEP 8 - Restore DNS configuration

STEP PASSED

TEST PASSED

DEVICE-6-1-2-v14.12 DEVICE MANAGEMENT - NAMESPACES (DEFAULT NAMESPACES FOR PARENT TAG)

TestResult

STEP 1 - Get DNS configuration

STEP PASSED

STEP 2 - Check that original DNS configuration returned from the DUT

STEP PASSED

STEP 3 - Set DNS configuration

STEP PASSED

STEP 4 - Wait 1.000 seconds to allow the DUT to apply settings

STEP PASSED

STEP 5 - Get DNS configuration

STEP PASSED

STEP 6 - Check that current DNS configuration returned from the DUT

STEP PASSED

STEP 7 - Check current DNS configuration

STEP PASSED

STEP 8 - Restore DNS configuration

STEP PASSED

TEST PASSED

DEVICE-6-1-3-v14.12 DEVICE MANAGEMENT - NAMESPACES (NOT STANDARD PREFIXES)

TestResult

STEP 1 - Get DNS configuration

STEP PASSED

STEP 2 - Check that original DNS configuration returned from the DUT

STEP PASSED

STEP 3 - Set DNS configuration

STEP PASSED

STEP 4 - Wait 1.000 seconds to allow the DUT to apply settings

STEP PASSED

STEP 5 - Get DNS configuration

STEP PASSED

STEP 6 - Check that current DNS configuration returned from the DUT

STEP PASSED

STEP 7 - Check current DNS configuration

STEP PASSED

STEP 8 - Restore DNS configuration

STEP PASSED

TEST PASSED

DEVICE-6-1-4-v14.12 DEVICE MANAGEMENT - NAMESPACES (DIFFERENT PREFIXES FOR THE SAME NAMESPACE)

TestResult

STEP 1 - Get DNS configuration

STEP PASSED

STEP 2 - Check that original DNS configuration returned from the DUT

STEP PASSED

STEP 3 - Set DNS configuration

STEP PASSED

STEP 4 - Wait 1.000 seconds to allow the DUT to apply settings

STEP PASSED

STEP 5 - Get DNS configuration

STEP PASSED

STEP 6 - Check that current DNS configuration returned from the DUT

STEP PASSED

STEP 7 - Check current DNS configuration

STEP PASSED

STEP 8 - Restore DNS configuration

STEP PASSED

TEST PASSED

DEVICE-6-1-5-v14.12 DEVICE MANAGEMENT - NAMESPACES (THE SAME PREFIX FOR DIFFERENT NAMESPACES)

TestResult

STEP 1 - Get DNS configuration

STEP PASSED

STEP 2 - Check that original DNS configuration returned from the DUT

STEP PASSED

STEP 3 - Set DNS configuration

STEP PASSED

STEP 4 - Wait 1.000 seconds to allow the DUT to apply settings

STEP PASSED

STEP 5 - Get DNS configuration

STEP PASSED

STEP 6 - Check that current DNS configuration returned from the DUT

STEP PASSED

STEP 7 - Check current DNS configuration

STEP PASSED

STEP 8 - Restore DNS configuration

STEP PASSED

TEST PASSED

DEVICE-8-1-1-v17.01 AUXILIARY COMMANDS

TestResult

STEP 1 - Get service capabilities

STEP PASSED

TEST PASSED

Event Handling

EVENT-1-1-2-v19.06 GET EVENT PROPERTIES

TestResult

STEP 1 - Get Event service address

STEP PASSED

STEP 2 - Get Event Properties

STEP PASSED

STEP 3 - Check that the DUT returned Topic Expression Dialects

STEP PASSED

STEP 4 - Check that Mandatory Topic Expression Dialect <http://docs.oasis-open.org/wsn/t-1/TopicExpression/Concrete> is supported

STEP PASSED

STEP 5 - Check that Mandatory Topic Expression Dialect <http://www.onvif.org/ver10/tev/topicExpression/ConcreteSet> is supported

STEP PASSED

STEP 6 - Check that the DUT returned Message Content Filter Dialects

STEP PASSED

STEP 7 - Check if the DUT supports mandatory Message Content Filter Dialect

<http://www.onvif.org/ver10/tev/messageContentFilter/ItemFilter>

STEP PASSED

STEP 8 - Check if response contains at least one topic namespace and that it is a valid string for an uri

STEP PASSED

STEP 9 - Check that the TopicSet returned is not null

STEP PASSED

STEP 10 - Check that the DUT returned not empty TopicSet

STEP PASSED

TEST PASSED

EVENT-2-1-9-v14.12 BASIC NOTIFICATION INTERFACE - SUBSCRIBE

TestResult

STEP 1 - Get Event service address

STEP PASSED

STEP 2 - Creating listening server

STEP PASSED

STEP 3 - Send Subscribe request

STEP PASSED

STEP 4 - Check that the DUT returned Subscribe response

STEP PASSED

STEP 5 - Check that CurrentTime is specified

STEP PASSED

STEP 6 - Check that TerminationTime is specified

STEP PASSED

STEP 7 - Check that TerminationTime and CurrentTime has reasonable values

STEP PASSED

STEP 8 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 9 - Check if the DUT returned SubscriptionReference

STEP PASSED

STEP 10 - Check if SubscriptionReference contains address

STEP PASSED

STEP 11 - Check that URL specified is valid

STEP PASSED

STEP 12 - Send Unsubscribe request

STEP PASSED

TEST PASSED

EVENT-2-1-12-v14.12 BASIC NOTIFICATION INTERFACE - RENEW

TestResult

STEP 1 - Get Event service address

STEP PASSED

STEP 2 - Creating listening server

STEP PASSED

STEP 3 - Send Subscribe request

STEP PASSED

STEP 4 - Check that the DUT returned Subscribe response

STEP PASSED

STEP 5 - Check that CurrentTime is specified

STEP PASSED

STEP 6 - Check that TerminationTime is specified

STEP PASSED

STEP 7 - Check that TerminationTime and CurrentTime has reasonable values

STEP PASSED

STEP 8 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 9 - Check if the DUT returned SubscriptionReference

STEP PASSED

STEP 10 - Check if SubscriptionReference contains address

STEP PASSED

STEP 11 - Check that URL specified is valid

STEP PASSED

STEP 12 - Renew subscription

STEP PASSED

STEP 13 - Renew subscription

STEP PASSED

STEP 14 - Send Unsubscribe request

STEP PASSED

TEST PASSED

EVENT-2-1-17-v14.12 BASIC NOTIFICATION INTERFACE - NOTIFY

TestResult

STEP 1 - Get Event service address

STEP PASSED

STEP 2 - Get Event Properties

STEP PASSED

Timeout of 60 seconds will be used

STEP 3 - Creating listening server

STEP PASSED

STEP 4 - Send Subscribe request

STEP PASSED

STEP 5 - Check that the DUT returned Subscribe response

STEP PASSED

STEP 6 - Check that CurrentTime is specified

STEP PASSED

STEP 7 - Check that TerminationTime is specified

STEP PASSED

STEP 8 - Check that TerminationTime and CurrentTime has reasonable values

STEP PASSED

STEP 9 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 10 - Check if the DUT returned SubscriptionReference

STEP PASSED

STEP 11 - Check if SubscriptionReference contains address

STEP PASSED

STEP 12 - Check that URL specified is valid

STEP PASSED

STEP 13 - Set Synchronization Point

STEP PASSED

STEP 14 - Wait for notification

STEP PASSED

STEP 15 - Receiving notification

STEP PASSED

STEP 16 - Receiving notification

STEP PASSED

STEP 17 - Receiving notification

STEP PASSED

STEP 18 - Receiving notification

STEP PASSED

STEP 19 - Receiving notification

STEP PASSED

STEP 20 - Receiving notification

STEP PASSED

STEP 21 - Validate notifications SOAP packet

STEP PASSED

STEP 22 - Validate Headers

STEP PASSED

STEP 23 - Validate notifications SOAP packet

STEP PASSED

STEP 24 - Validate Headers

STEP PASSED

STEP 25 - Validate notifications SOAP packet

STEP PASSED

STEP 26 - Validate Headers

STEP PASSED

STEP 27 - Validate notifications SOAP packet

STEP PASSED

STEP 28 - Validate Headers

STEP PASSED

STEP 29 - Validate notifications SOAP packet

STEP PASSED

STEP 30 - Validate Headers

STEP PASSED

STEP 31 - Validate notifications SOAP packet

STEP PASSED

STEP 32 - Validate Headers

STEP PASSED

STEP 33 - Check that DUT sent notification messages

STEP PASSED

STEP 34 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 35 - Validate messages

STEP PASSED

STEP 36 - Send Unsubscribe request

STEP PASSED

TEST PASSED

EVENT-2-1-18-v14.12 BASIC NOTIFICATION INTERFACE - NOTIFY FILTER

TestResult

STEP 1 - Get Event service address

STEP PASSED

STEP 2 - Get Event Properties

STEP PASSED

Timeout of 60 seconds will be used

STEP 3 - Parse topic

STEP PASSED

STEP 4 - Creating listening server

STEP PASSED

STEP 5 - Send Subscribe request

STEP PASSED

STEP 6 - Check that the DUT returned Subscribe response

STEP PASSED

STEP 7 - Check that CurrentTime is specified

STEP PASSED

STEP 8 - Check that TerminationTime is specified

STEP PASSED

STEP 9 - Check that TerminationTime and CurrentTime has reasonable values

STEP PASSED

STEP 10 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 11 - Check if the DUT returned SubscriptionReference

STEP PASSED

STEP 12 - Check if SubscriptionReference contains address

STEP PASSED

STEP 13 - Check that URL specified is valid

STEP PASSED

STEP 14 - Set Synchronization Point

STEP PASSED

STEP 15 - Wait for notification

STEP PASSED

STEP 16 - Receiving notification

STEP PASSED

STEP 17 - Receiving notification

STEP PASSED

STEP 18 - Validate notifications SOAP packet

STEP PASSED

STEP 19 - Validate Headers

STEP PASSED

STEP 20 - Validate notifications SOAP packet

STEP PASSED

STEP 21 - Validate Headers

STEP PASSED

STEP 22 - Check that DUT sent notification messages

STEP PASSED

STEP 23 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 24 - Validate messages

STEP PASSED

STEP 25 - Send Unsubscribe request

STEP PASSED

TEST PASSED

EVENT-2-1-24-v17.06 BASIC NOTIFICATION INTERFACE - SET SYNCHRONIZATION POINT

TestResult

STEP 1 - Get Device service address

STEP PASSED

STEP 2 - Check that the DUT returned Device service address

STEP PASSED

STEP 3 - Get Services

STEP PASSED

STEP 4 - Get Event service address

STEP PASSED

STEP 5 - Check that the DUT returned Event service address

STEP PASSED

STEP 6 - Get Event Properties

STEP PASSED

STEP 7 - Creating listening server

STEP PASSED

STEP 8 - Send Subscribe request

STEP PASSED

STEP 9 - Check that the DUT returned Subscribe response

STEP PASSED

STEP 10 - Check that CurrentTime is specified

STEP PASSED

STEP 11 - Check that TerminationTime is specified

STEP PASSED

STEP 12 - Check that TerminationTime and CurrentTime has reasonable values

STEP PASSED

STEP 13 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 14 - Check if the DUT returned SubscriptionReference

STEP PASSED

STEP 15 - Check if SubscriptionReference contains address

STEP PASSED

STEP 16 - Check that URL specified is valid

STEP PASSED

STEP 17 - Wait for notification

STEP PASSED

STEP 18 - Receiving notification

STEP PASSED

STEP 19 - Validate notifications SOAP packet

STEP PASSED

STEP 20 - Validate Headers

STEP PASSED

STEP 21 - Check that DUT sent notification messages

STEP PASSED

STEP 22 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 23 - Checking received notification matches to the topic specified on Management tab

STEP PASSED

STEP 24 - Set Synchronization Point

STEP PASSED

STEP 25 - Wait for notification

STEP PASSED

STEP 26 - Receiving notification

STEP PASSED

STEP 27 - Validate notifications SOAP packet

STEP PASSED

STEP 28 - Validate Headers

STEP PASSED

STEP 29 - Check that DUT sent notification messages

STEP PASSED

STEP 30 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 31 - Send Unsubscribe request

STEP PASSED

TEST PASSED

EVENT-2-1-25-v17.06 BASIC NOTIFICATION INTERFACE – CONJUNCTION IN NOTIFY FILTER (OR OPERATION)

TestResult

STEP 1 - Get Device service address

STEP PASSED

STEP 2 - Check that the DUT returned Device service address

STEP PASSED

STEP 3 - Get Services

STEP PASSED

STEP 4 - Get Event service address

STEP PASSED

STEP 5 - Check that the DUT returned Event service address

STEP PASSED

STEP 6 - Get Event Properties

STEP PASSED

STEP 7 - Parse topic

STEP PASSED

STEP 8 - Creating listening server

STEP PASSED

STEP 9 - Send Subscribe request

STEP PASSED

STEP 10 - Check that the DUT returned Subscribe response

STEP PASSED

STEP 11 - Check that CurrentTime is specified

STEP PASSED

STEP 12 - Check that TerminationTime is specified

STEP PASSED

STEP 13 - Check that TerminationTime and CurrentTime has reasonable values

STEP PASSED

STEP 14 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 15 - Check if the DUT returned SubscriptionReference

STEP PASSED

STEP 16 - Check if SubscriptionReference contains address

STEP PASSED

STEP 17 - Check that URL specified is valid

STEP PASSED

STEP 18 - Wait for notification

STEP PASSED

STEP 19 - Receiving notification

STEP PASSED

STEP 20 - Receiving notification

STEP PASSED

STEP 21 - Validate notifications SOAP packet

STEP PASSED

STEP 22 - Validate Headers

STEP PASSED

STEP 23 - Validate notifications SOAP packet

STEP PASSED

STEP 24 - Validate Headers

STEP PASSED

STEP 25 - Check that DUT sent notification messages

STEP PASSED

STEP 26 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 27 - Check if the DUT returned only required notifications

STEP PASSED

STEP 28 - Check that DUT sent notification messages

STEP PASSED

STEP 29 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 30 - Check if the DUT returned only required notifications

STEP PASSED

STEP 31 - Check if the DUT returned all required notifications

STEP PASSED

STEP 32 - Send Unsubscribe request

STEP PASSED

TEST PASSED

EVENT-2-1-26-v17.06 BASIC NOTIFICATION INTERFACE – TOPIC SUB-TREE IN PULLMESSAGES FILTER

TestResult

STEP 1 - Get Device service address

STEP PASSED

STEP 2 - Check that the DUT returned Device service address

STEP PASSED

STEP 3 - Get Services

STEP PASSED

STEP 4 - Get Event service address

STEP PASSED

STEP 5 - Check that the DUT returned Event service address

STEP PASSED

STEP 6 - Get Event Properties

STEP PASSED

STEP 7 - Parse topic

STEP PASSED

STEP 8 - Creating listening server

STEP PASSED

STEP 9 - Send Subscribe request

STEP PASSED

STEP 10 - Check that the DUT returned Subscribe response

STEP PASSED

STEP 11 - Check that CurrentTime is specified

STEP PASSED

STEP 12 - Check that TerminationTime is specified

STEP PASSED

STEP 13 - Check that TerminationTime and CurrentTime has reasonable values

STEP PASSED

STEP 14 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 15 - Check if the DUT returned SubscriptionReference

STEP PASSED

STEP 16 - Check if SubscriptionReference contains address

STEP PASSED

STEP 17 - Check that URL specified is valid

STEP PASSED

STEP 18 - Wait for notification

STEP PASSED

STEP 19 - Receiving notification

STEP PASSED

STEP 20 - Validate notifications SOAP packet

STEP PASSED

STEP 21 - Validate Headers

STEP PASSED

STEP 22 - Check that DUT sent notification messages

STEP PASSED

STEP 23 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 24 - Check if the DUT returned notifications with the root element is equal to "tns1:Device//."

STEP PASSED

STEP 25 - Check if the DUT returned all required notifications

STEP PASSED

STEP 26 - Send Unsubscribe request

STEP PASSED

TEST PASSED

EVENT-2-1-27-v17.06 BASIC NOTIFICATION INTERFACE – CONJUNCTION IN NOTIFY FILTER (TOPIC SUB-TREE AND OR OPERATION)

TestResult

STEP 1 - Get Device service address

STEP PASSED

STEP 2 - Check that the DUT returned Device service address

STEP PASSED

STEP 3 - Get Services

STEP PASSED

STEP 4 - Get Event service address

STEP PASSED

STEP 5 - Check that the DUT returned Event service address

STEP PASSED

STEP 6 - Get Event Properties

STEP PASSED

STEP 7 - Parse topic

STEP PASSED

STEP 8 - Creating listening server

STEP PASSED

STEP 9 - Send Subscribe request

STEP PASSED

STEP 10 - Check that the DUT returned Subscribe response

STEP PASSED

STEP 11 - Check that CurrentTime is specified

STEP PASSED

STEP 12 - Check that TerminationTime is specified

STEP PASSED

STEP 13 - Check that TerminationTime and CurrentTime has reasonable values

STEP PASSED

STEP 14 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 15 - Check if the DUT returned SubscriptionReference

STEP PASSED

STEP 16 - Check if SubscriptionReference contains address

STEP PASSED

STEP 17 - Check that URL specified is valid

STEP PASSED

STEP 18 - Wait for notification

STEP PASSED

STEP 19 - Receiving notification

STEP PASSED

STEP 20 - Receiving notification

STEP PASSED

STEP 21 - Validate notifications SOAP packet

STEP PASSED

STEP 22 - Validate Headers

STEP PASSED

STEP 23 - Validate notifications SOAP packet

STEP PASSED

STEP 24 - Validate Headers

STEP PASSED

STEP 25 - Check that DUT sent notification messages

STEP PASSED

STEP 26 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 27 - Check if the DUT returned notifications with the root element is equal to "tns1:Device//." or with the topic is equal to "tns1:VideoSource/ImageTooDark/ImagingService"

STEP PASSED

STEP 28 - Check that DUT sent notification messages

STEP PASSED

STEP 29 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 30 - Check if the DUT returned notifications with the root element is equal to "tns1:Device//." or with the topic is equal to "tns1:VideoSource/ImageTooDark/ImagingService"

STEP PASSED

STEP 31 - Check if the DUT returned all required notifications

STEP PASSED

STEP 32 - Send Unsubscribe request

STEP PASSED

TEST PASSED

EVENT-2-1-28-v17.12 BASIC NOTIFICATION INTERFACE - UNSUBSCRIBE

TestResult

STEP 1 - Get Device service address

STEP PASSED

STEP 2 - Check that the DUT returned Device service address

STEP PASSED

STEP 3 - Get Services

STEP PASSED

STEP 4 - Creating listening server

STEP PASSED

STEP 5 - Send Subscribe request

STEP PASSED

STEP 6 - Check that the DUT returned Subscribe response

STEP PASSED

STEP 7 - Check that CurrentTime is specified

STEP PASSED

STEP 8 - Check that TerminationTime is specified

STEP PASSED

STEP 9 - Check that TerminationTime and CurrentTime has reasonable values

STEP PASSED

STEP 10 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 11 - Check if the DUT returned SubscriptionReference

STEP PASSED

STEP 12 - Check if SubscriptionReference contains address

STEP PASSED

STEP 13 - Check that URL specified is valid

STEP PASSED

STEP 14 - Waiting one second

STEP PASSED

STEP 15 - Send Unsubscribe request

STEP PASSED

TEST PASSED

EVENT-2-1-29-v18.06 BASIC NOTIFICATION INTERFACE - MESSAGE CONTENT FILTER

TestResult

STEP 1 - Get Device service address

STEP PASSED

STEP 2 - Check that the DUT returned Device service address

STEP PASSED

STEP 3 - Get Services

STEP PASSED

STEP 4 - Get Event service address

STEP PASSED

STEP 5 - Check that the DUT returned Event service address

STEP PASSED

STEP 6 - Get Event Properties

STEP PASSED

STEP 7 - Check the DUT returned at least one MessageContentFilterDialect item

STEP PASSED

STEP 8 - Parse topic

STEP PASSED

STEP 9 - Creating listening server

STEP PASSED

STEP 10 - Send Subscribe request

STEP PASSED

STEP 11 - Check that the DUT returned Subscribe response

STEP PASSED

STEP 12 - Check that CurrentTime is specified

STEP PASSED

STEP 13 - Check that TerminationTime is specified

STEP PASSED

STEP 14 - Check that TerminationTime and CurrentTime has reasonable values

STEP PASSED

STEP 15 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 16 - Check if the DUT returned SubscriptionReference

STEP PASSED

STEP 17 - Check if SubscriptionReference contains address

STEP PASSED

STEP 18 - Check that URL specified is valid

STEP PASSED

STEP 19 - Wait for notification

STEP PASSED

STEP 20 - Receiving notification

STEP PASSED

STEP 21 - Validate notifications SOAP packet

STEP PASSED

STEP 22 - Validate Headers

STEP PASSED

STEP 23 - Check that DUT sent notification messages

STEP PASSED

STEP 24 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 25 - Check if the DUT returned required notification

STEP PASSED

STEP 26 - Send Unsubscribe request

STEP PASSED

STEP 27 - Wait for 1 second(s) to complete the operation

STEP PASSED

STEP 28 - Check if the DUT returned notification message with 'Source.SimpleItem' element and 'Name', 'Value' attributes

STEP PASSED

STEP 29 - Creating listening server

STEP PASSED

STEP 30 - Send Subscribe request

STEP PASSED

STEP 31 - Check that the DUT returned Subscribe response

STEP PASSED

STEP 32 - Check that CurrentTime is specified

STEP PASSED

STEP 33 - Check that TerminationTime is specified

STEP PASSED

STEP 34 - Check that TerminationTime and CurrentTime has reasonable values

STEP PASSED

STEP 35 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 36 - Check if the DUT returned SubscriptionReference

STEP PASSED

STEP 37 - Check if SubscriptionReference contains address

STEP PASSED

STEP 38 - Check that URL specified is valid

STEP PASSED

Waiting for notification [Topic = 'tns1:Device/Trigger/DigitalInput', PropertyOperation = 'Initialized']

STEP 39 - Wait for notification

STEP PASSED

STEP 40 - Receiving notification

STEP PASSED

STEP 41 - Validate notifications SOAP packet

STEP PASSED

STEP 42 - Validate Headers

STEP PASSED

STEP 43 - Check that DUT sent notification messages

STEP PASSED

STEP 44 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 45 - Check that each returned notification message contains SimpleItem element with Name = 'InputToken' and with Value = '1'

STEP PASSED

STEP 46 - Check if the DUT returned required notification

STEP PASSED

STEP 47 - Send Unsubscribe request

STEP PASSED

TEST PASSED

EVENT-3-1-9-v14.12 REALTIME PULLPOINT SUBSCRIPTION - CREATE PULL POINT SUBSCRIPTION

TestResult

STEP 1 - Get Event service address

STEP PASSED

STEP 2 - Create Pull Point Subscription

STEP PASSED

STEP 3 - Check if the DUT returned SubscriptionReference

STEP PASSED

STEP 4 - Check if SubscriptionReference contains address

STEP PASSED

STEP 5 - Check that URL specified is valid

STEP PASSED

STEP 6 - Check that TerminationTime is specified

STEP PASSED

STEP 7 - Validate times

STEP PASSED

STEP 8 - Delete Subscription Manager

STEP PASSED

TEST PASSED

EVENT-3-1-12-v17.12 REALTIME PULLPOINT SUBSCRIPTION - RENEW

TestResult

STEP 1 - Get Event service address

STEP PASSED

STEP 2 - Create Pull Point Subscription

STEP PASSED

STEP 3 - Check that TerminationTime is specified

STEP PASSED

STEP 4 - Validate times

STEP PASSED

STEP 5 - Check if the DUT returned SubscriptionReference

STEP PASSED

STEP 6 - Check if SubscriptionReference contains address

STEP PASSED

STEP 7 - Check that URL specified is valid

STEP PASSED

STEP 8 - Renew subscription

STEP PASSED

STEP 9 - Check that the DUT returned Renew response

STEP PASSED

STEP 10 - Check that CurrentTime is specified

STEP PASSED

STEP 11 - Check that TerminationTime is specified

STEP PASSED

STEP 12 - Validate times

STEP PASSED

STEP 13 - Delete Subscription Manager

STEP PASSED

TEST PASSED

EVENT-3-1-15-v14.12 REALTIME PULLPOINT SUBSCRIPTION - PULLMESSAGES

TestResult

STEP 1 - Get Event service address

STEP PASSED

STEP 2 - Get Event Properties

STEP PASSED

Timeout of 60 seconds will be used

STEP 3 - Create Pull Point Subscription

STEP PASSED

STEP 4 - Check that TerminationTime is specified

STEP PASSED

STEP 5 - Check that TerminationTime and CurrentTime has reasonable values

STEP PASSED

STEP 6 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 7 - Check if the DUT returned SubscriptionReference

STEP PASSED

STEP 8 - Check if SubscriptionReference contains address

STEP PASSED

STEP 9 - Check that URL specified is valid

STEP PASSED

STEP 10 - Send PullMessages request

STEP PASSED

STEP 11 - Set Synchronization Point

STEP PASSED

STEP 12 - Get PullMessages response

STEP PASSED

STEP 13 - Check that DUT sent notification messages

STEP PASSED

STEP 14 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 15 - Check that a maximum number of 2 Notification Messages is included in PullMessagesResponse

STEP PASSED

STEP 16 - Response is not empty

STEP PASSED

STEP 17 - Validate messages

STEP PASSED

STEP 18 - Delete Subscription Manager

STEP PASSED

TEST PASSED

EVENT-3-1-16-v14.12 REALTIME PULLPOINT SUBSCRIPTION - PULLMESSAGES FILTER

TestResult

STEP 1 - Get Event service address

STEP PASSED

STEP 2 - Get Event Properties

STEP PASSED

STEP 3 - Parse topic

STEP PASSED

Timeout of 60 seconds will be used

STEP 4 - Create Pull Point Subscription

STEP PASSED

STEP 5 - Check that TerminationTime is specified

STEP PASSED

STEP 6 - Check that TerminationTime and CurrentTime has reasonable values

STEP PASSED

STEP 7 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 8 - Check if the DUT returned SubscriptionReference

STEP PASSED

STEP 9 - Check if SubscriptionReference contains address

STEP PASSED

STEP 10 - Check that URL specified is valid

STEP PASSED

STEP 11 - Send PullMessages request

STEP PASSED

STEP 12 - Set Synchronization Point

STEP PASSED

STEP 13 - Get PullMessages response

STEP PASSED

STEP 14 - Check that DUT sent notification messages

STEP PASSED

STEP 15 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 16 - Check that a maximum number of 2 Notification Messages is included in PullMessagesResponse

STEP PASSED

STEP 17 - Response is not empty

STEP PASSED

STEP 18 - Validate messages

STEP PASSED

STEP 19 - Delete Subscription Manager

STEP PASSED

TEST PASSED

EVENT-3-1-24-v14.12 REALTIME PULLPOINT SUBSCRIPTION – PULLMESSAGES AS KEEP-ALIVE

TestResult

STEP 1 - Get Event service address

STEP PASSED

STEP 2 - Get Event Properties

STEP PASSED

STEP 3 - Create Pull Point Subscription

STEP PASSED

STEP 4 - Check that TerminationTime is specified

STEP PASSED

STEP 5 - Check that TerminationTime and CurrentTime has reasonable values

STEP PASSED

STEP 6 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 7 - Check if the DUT returned SubscriptionReference

STEP PASSED

STEP 8 - Check if SubscriptionReference contains address

STEP PASSED

STEP 9 - Check that URL specified is valid

STEP PASSED

STEP 10 - 1 second after CreatePullPointSubscription

STEP PASSED

STEP 11 - Validating Current Time and Termination Time in CreatePullPointSubscription response

STEP PASSED

STEP 12 - Send PullMessages request

STEP PASSED

STEP 13 - Get PullMessages response

STEP PASSED

STEP 14 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 15 - Check that a maximum number of 1 Notification Messages is included in PullMessagesResponse

STEP PASSED

STEP 16 - Response is not empty

STEP PASSED

STEP 17 - Validating Current Time and Termination Time in PullMessages response

STEP PASSED

STEP 18 - Send Unsubscribe request

STEP PASSED

TEST PASSED

EVENT-3-1-25-v17.06 REALTIME PULLPOINT SUBSCRIPTION – SET SYNCHRONIZATION POINT

TestResult

STEP 1 - Get Device service address

STEP PASSED

STEP 2 - Check that the DUT returned Device service address

STEP PASSED

STEP 3 - Get Services

STEP PASSED

STEP 4 - Get Event service address

STEP PASSED

STEP 5 - Check that the DUT returned Event service address

STEP PASSED

STEP 6 - Get Event Properties

STEP PASSED

STEP 7 - Parse topic

STEP PASSED

STEP 8 - Create Pull Point Subscription

STEP PASSED

STEP 9 - Check that TerminationTime is specified

STEP PASSED

STEP 10 - Check that TerminationTime and CurrentTime has reasonable values

STEP PASSED

STEP 11 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 12 - Check if the DUT returned SubscriptionReference

STEP PASSED

STEP 13 - Check if SubscriptionReference contains address

STEP PASSED

STEP 14 - Check that URL specified is valid

STEP PASSED

STEP 15 - 1 second after CreatePullPointSubscription

STEP PASSED

STEP 16 - Send PullMessages request

STEP PASSED

STEP 17 - Check that DUT sent notification messages

STEP PASSED

STEP 18 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 19 - Check that a maximum number of 1 Notification Messages is included in PullMessagesResponse

STEP PASSED

STEP 20 - Response is not empty

STEP PASSED

STEP 21 - Checking received notification matches to the topic specified on Management tab

STEP PASSED

STEP 22 - Set Synchronization Point

STEP PASSED

STEP 23 - 1 second timeout

STEP PASSED

STEP 24 - Send PullMessages request

STEP PASSED

STEP 25 - Check that DUT sent notification messages

STEP PASSED

STEP 26 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 27 - Check that a maximum number of 1 Notification Messages is included in PullMessagesResponse

STEP PASSED

STEP 28 - Response is not empty

STEP PASSED

STEP 29 - Send Unsubscribe request

STEP PASSED

TEST PASSED

EVENT-3-1-32-v17.06 REALTIME PULLPOINT SUBSCRIPTION – PULLMESSAGES TIMEOUT

TestResult

STEP 1 - Get Device service address

STEP PASSED

STEP 2 - Check that the DUT returned Device service address

STEP PASSED

STEP 3 - Get Services

STEP PASSED

STEP 4 - Create Pull Point Subscription

STEP PASSED

STEP 5 - Check that TerminationTime is specified

STEP PASSED

STEP 6 - Check that TerminationTime and CurrentTime has reasonable values

STEP PASSED

STEP 7 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 8 - Check if the DUT returned SubscriptionReference

STEP PASSED

STEP 9 - Check if SubscriptionReference contains address

STEP PASSED

STEP 10 - Check that URL specified is valid

STEP PASSED

STEP 11 - Send PullMessages request

STEP PASSED

STEP 12 - Check that the termination time is greater than the current time

STEP PASSED

STEP 13 - Send Unsubscribe request

STEP PASSED

TEST PASSED

EVENT-3-1-33-v18.06 REALTIME PULLPOINT SUBSCRIPTION – CONJUNCTION IN PULLMESSAGES FILTER (OR OPERATION)

TestResult

STEP 1 - Get Device service address

STEP PASSED

STEP 2 - Check that the DUT returned Device service address

STEP PASSED

STEP 3 - Get Services

STEP PASSED

STEP 4 - Get Event service address

STEP PASSED

STEP 5 - Check that the DUT returned Event service address

STEP PASSED

STEP 6 - Get Event Properties

STEP PASSED

STEP 7 - Parse topic

STEP PASSED

STEP 8 - Create Pull Point Subscription

STEP PASSED

STEP 9 - Check that TerminationTime is specified

STEP PASSED

STEP 10 - Check that TerminationTime and CurrentTime has reasonable values

STEP PASSED

STEP 11 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 12 - Check if the DUT returned SubscriptionReference

STEP PASSED

STEP 13 - Check if SubscriptionReference contains address

STEP PASSED

STEP 14 - Check that URL specified is valid

STEP PASSED

STEP 15 - Send PullMessages request

STEP PASSED

STEP 16 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 17 - Check that a maximum number of 1 Notification Messages is included in PullMessagesResponse

STEP PASSED

STEP 18 - Response is not empty

STEP PASSED

STEP 19 - Send PullMessages request

STEP PASSED

STEP 20 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 21 - Check that a maximum number of 1 Notification Messages is included in PullMessagesResponse

STEP PASSED

STEP 22 - Response is not empty

STEP PASSED

STEP 23 - Waiting for notifications

STEP PASSED

STEP 24 - Send Unsubscribe request

STEP PASSED

TEST PASSED

EVENT-3-1-34-v18.06 REALTIME PULLPOINT SUBSCRIPTION – TOPIC SUB-TREE IN PULLMESSAGES FILTER

TestResult

STEP 1 - Get Device service address

STEP PASSED

STEP 2 - Check that the DUT returned Device service address

STEP PASSED

STEP 3 - Get Services

STEP PASSED

STEP 4 - Get Event service address

STEP PASSED

STEP 5 - Check that the DUT returned Event service address

STEP PASSED

STEP 6 - Get Event Properties

STEP PASSED

STEP 7 - Parse topic

STEP PASSED

STEP 8 - Create Pull Point Subscription

STEP PASSED

STEP 9 - Check that TerminationTime is specified

STEP PASSED

STEP 10 - Check that TerminationTime and CurrentTime has reasonable values

STEP PASSED

STEP 11 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 12 - Check if the DUT returned SubscriptionReference

STEP PASSED

STEP 13 - Check if SubscriptionReference contains address

STEP PASSED

STEP 14 - Check that URL specified is valid

STEP PASSED

STEP 15 - Send PullMessages request

STEP PASSED

STEP 16 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 17 - Check that a maximum number of 1 Notification Messages is included in PullMessagesResponse

STEP PASSED

STEP 18 - Response is not empty

STEP PASSED

STEP 19 - Waiting for notifications

STEP PASSED

STEP 20 - Send Unsubscribe request

STEP PASSED

TEST PASSED

EVENT-3-1-35-v18.06 REALTIME PULLPOINT SUBSCRIPTION – CONJUNCTION IN NOTIFY FILTER (TOPIC SUB-TREE AND OR OPERATION)

TestResult

STEP 1 - Get Device service address

STEP PASSED

STEP 2 - Check that the DUT returned Device service address

STEP PASSED

STEP 3 - Get Services

STEP PASSED

STEP 4 - Get Event service address

STEP PASSED

STEP 5 - Check that the DUT returned Event service address

STEP PASSED

STEP 6 - Get Event Properties

STEP PASSED

STEP 7 - Parse topic

STEP PASSED

STEP 8 - Create Pull Point Subscription

STEP PASSED

STEP 9 - Check that TerminationTime is specified

STEP PASSED

STEP 10 - Check that TerminationTime and CurrentTime has reasonable values

STEP PASSED

STEP 11 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 12 - Check if the DUT returned SubscriptionReference

STEP PASSED

STEP 13 - Check if SubscriptionReference contains address

STEP PASSED

STEP 14 - Check that URL specified is valid

STEP PASSED

STEP 15 - Send PullMessages request

STEP PASSED

STEP 16 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 17 - Check that a maximum number of 1 Notification Messages is included in PullMessagesResponse

STEP PASSED

STEP 18 - Response is not empty

STEP PASSED

STEP 19 - Send PullMessages request

STEP PASSED

STEP 20 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 21 - Check that a maximum number of 1 Notification Messages is included in PullMessagesResponse

STEP PASSED

STEP 22 - Response is not empty

STEP PASSED

STEP 23 - Waiting for notifications

STEP PASSED

STEP 24 - Send Unsubscribe request

STEP PASSED

TEST PASSED

EVENT-3-1-36-v17.12 REALTIME PULLPOINT SUBSCRIPTION - UNSUBSCRIBE

TestResult

STEP 1 - Get Device service address

STEP PASSED

STEP 2 - Check that the DUT returned Device service address

STEP PASSED

STEP 3 - Get Services

STEP PASSED

STEP 4 - Create Pull Point Subscription

STEP PASSED

STEP 5 - Check that TerminationTime is specified

STEP PASSED

STEP 6 - Check that TerminationTime and CurrentTime has reasonable values

STEP PASSED

STEP 7 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 8 - Check if the DUT returned SubscriptionReference

STEP PASSED

STEP 9 - Check if SubscriptionReference contains address

STEP PASSED

STEP 10 - Check that URL specified is valid

STEP PASSED

STEP 11 - Waiting one second

STEP PASSED

STEP 12 - Send Unsubscribe request

STEP PASSED

TEST PASSED

EVENT-3-1-37-v17.12 REALTIME PULLPOINT SUBSCRIPTION – MAXIMUM SUPPORTED NUMBER OF NOTIFICATION PULL POINTS

TestResult

STEP 1 - Get Device service address

STEP PASSED

STEP 2 - Check that the DUT returned Device service address

STEP PASSED

STEP 3 - Get Services

STEP PASSED

STEP 4 - Get Event service address

STEP PASSED

STEP 5 - Check that the DUT returned Event service address

STEP PASSED

STEP 6 - Get Service Capabilities(Event)

STEP PASSED

STEP 7 - Check if EventServiceCapabilities item contains MaxPullPoints

STEP PASSED

STEP 8 - Get Event Properties

STEP PASSED

STEP 9 - Create Pull Point Subscription

STEP PASSED

STEP 10 - Check that TerminationTime is specified

STEP PASSED

STEP 11 - Check that TerminationTime and CurrentTime has reasonable values

STEP PASSED

STEP 12 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 13 - Check if the DUT returned SubscriptionReference

STEP PASSED

STEP 14 - Check if SubscriptionReference contains address

STEP PASSED

STEP 15 - Check that URL specified is valid

STEP PASSED

STEP 16 - Create Pull Point Subscription

STEP PASSED

STEP 17 - Check that TerminationTime is specified

STEP PASSED

STEP 18 - Check that TerminationTime and CurrentTime has reasonable values

STEP PASSED

STEP 19 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 20 - Check if the DUT returned SubscriptionReference

STEP PASSED

STEP 21 - Check if SubscriptionReference contains address

STEP PASSED

STEP 22 - Check that URL specified is valid

STEP PASSED

STEP 23 - Check that the DUT did not create the subscriptions with the same id

STEP PASSED

STEP 24 - Create Pull Point Subscription

STEP PASSED

STEP 25 - Check that TerminationTime is specified

STEP PASSED

STEP 26 - Check that TerminationTime and CurrentTime has reasonable values

STEP PASSED

STEP 27 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 28 - Check if the DUT returned SubscriptionReference

STEP PASSED

STEP 29 - Check if SubscriptionReference contains address

STEP PASSED

STEP 30 - Check that URL specified is valid

STEP PASSED

STEP 31 - Check that the DUT did not create the subscriptions with the same id

STEP PASSED

STEP 32 - Create Pull Point Subscription

STEP PASSED

STEP 33 - Check that TerminationTime is specified

STEP PASSED

STEP 34 - Check that TerminationTime and CurrentTime has reasonable values

STEP PASSED

STEP 35 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 36 - Check if the DUT returned SubscriptionReference

STEP PASSED

STEP 37 - Check if SubscriptionReference contains address

STEP PASSED

STEP 38 - Check that URL specified is valid

STEP PASSED

STEP 39 - Check that the DUT did not create the subscriptions with the same id

STEP PASSED

STEP 40 - Create Pull Point Subscription

STEP PASSED

STEP 41 - Check that TerminationTime is specified

STEP PASSED

STEP 42 - Check that TerminationTime and CurrentTime has reasonable values

STEP PASSED

STEP 43 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 44 - Check if the DUT returned SubscriptionReference

STEP PASSED

STEP 45 - Check if SubscriptionReference contains address

STEP PASSED

STEP 46 - Check that URL specified is valid

STEP PASSED

STEP 47 - Check that the DUT did not create the subscriptions with the same id

STEP PASSED

STEP 48 - Create Pull Point Subscription

STEP PASSED

STEP 49 - Check that TerminationTime is specified

STEP PASSED

STEP 50 - Check that TerminationTime and CurrentTime has reasonable values

STEP PASSED

STEP 51 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 52 - Check if the DUT returned SubscriptionReference

STEP PASSED

STEP 53 - Check if SubscriptionReference contains address

STEP PASSED

STEP 54 - Check that URL specified is valid

STEP PASSED

STEP 55 - Check that the DUT did not create the subscriptions with the same id

STEP PASSED

STEP 56 - Create Pull Point Subscription

STEP PASSED

STEP 57 - Check that TerminationTime is specified

STEP PASSED

STEP 58 - Check that TerminationTime and CurrentTime has reasonable values

STEP PASSED

STEP 59 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 60 - Check if the DUT returned SubscriptionReference

STEP PASSED

STEP 61 - Check if SubscriptionReference contains address

STEP PASSED

STEP 62 - Check that URL specified is valid

STEP PASSED

STEP 63 - Check that the DUT did not create the subscriptions with the same id

STEP PASSED

STEP 64 - Create Pull Point Subscription

STEP PASSED

STEP 65 - Check that TerminationTime is specified

STEP PASSED

STEP 66 - Check that TerminationTime and CurrentTime has reasonable values

STEP PASSED

STEP 67 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 68 - Check if the DUT returned SubscriptionReference

STEP PASSED

STEP 69 - Check if SubscriptionReference contains address

STEP PASSED

STEP 70 - Check that URL specified is valid

STEP PASSED

STEP 71 - Check that the DUT did not create the subscriptions with the same id

STEP PASSED

STEP 72 - Create Pull Point Subscription

STEP PASSED

STEP 73 - Check that TerminationTime is specified

STEP PASSED

STEP 74 - Check that TerminationTime and CurrentTime has reasonable values

STEP PASSED

STEP 75 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 76 - Check if the DUT returned SubscriptionReference

STEP PASSED

STEP 77 - Check if SubscriptionReference contains address

STEP PASSED

STEP 78 - Check that URL specified is valid

STEP PASSED

STEP 79 - Check that the DUT did not create the subscriptions with the same id

STEP PASSED

STEP 80 - Create Pull Point Subscription

STEP PASSED

STEP 81 - Check that TerminationTime is specified

STEP PASSED

STEP 82 - Check that TerminationTime and CurrentTime has reasonable values

STEP PASSED

STEP 83 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 84 - Check if the DUT returned SubscriptionReference

STEP PASSED

STEP 85 - Check if SubscriptionReference contains address

STEP PASSED

STEP 86 - Check that URL specified is valid

STEP PASSED

STEP 87 - Check that the DUT did not create the subscriptions with the same id

STEP PASSED

STEP 88 - Send PullMessages request

STEP PASSED

STEP 89 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 90 - Check that a maximum number of 1 Notification Messages is included in PullMessagesResponse

STEP PASSED

STEP 91 - Response is not empty

STEP PASSED

STEP 92 - Waiting for notification

STEP PASSED

STEP 93 - Send PullMessages request

STEP PASSED

STEP 94 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 95 - Check that a maximum number of 1 Notification Messages is included in PullMessagesResponse

STEP PASSED

STEP 96 - Response is not empty

STEP PASSED

STEP 97 - Waiting for notification

STEP PASSED

STEP 98 - Send PullMessages request

STEP PASSED

STEP 99 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 100 - Check that a maximum number of 1 Notification Messages is included in PullMessagesResponse

STEP PASSED

STEP 101 - Response is not empty

STEP PASSED

STEP 102 - Waiting for notification

STEP PASSED

STEP 103 - Send PullMessages request

STEP PASSED

STEP 104 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 105 - Check that a maximum number of 1 Notification Messages is included in PullMessagesResponse

STEP PASSED

STEP 106 - Response is not empty

STEP PASSED

STEP 107 - Waiting for notification

STEP PASSED

STEP 108 - Send PullMessages request

STEP PASSED

STEP 109 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 110 - Check that a maximum number of 1 Notification Messages is included in PullMessagesResponse

STEP PASSED

STEP 111 - Response is not empty

STEP PASSED

STEP 112 - Waiting for notification

STEP PASSED

STEP 113 - Send PullMessages request

STEP PASSED

STEP 114 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 115 - Check that a maximum number of 1 Notification Messages is included in PullMessagesResponse

STEP PASSED

STEP 116 - Response is not empty

STEP PASSED

STEP 117 - Waiting for notification

STEP PASSED

STEP 118 - Send PullMessages request

STEP PASSED

STEP 119 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 120 - Check that a maximum number of 1 Notification Messages is included in PullMessagesResponse

STEP PASSED

STEP 121 - Response is not empty

STEP PASSED

STEP 122 - Waiting for notification

STEP PASSED

STEP 123 - Send PullMessages request

STEP PASSED

STEP 124 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 125 - Check that a maximum number of 1 Notification Messages is included in PullMessagesResponse

STEP PASSED

STEP 126 - Response is not empty

STEP PASSED

STEP 127 - Waiting for notification

STEP PASSED

STEP 128 - Send PullMessages request

STEP PASSED

STEP 129 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 130 - Check that a maximum number of 1 Notification Messages is included in PullMessagesResponse

STEP PASSED

STEP 131 - Response is not empty

STEP PASSED

STEP 132 - Waiting for notification

STEP PASSED

STEP 133 - Send PullMessages request

STEP PASSED

STEP 134 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 135 - Check that a maximum number of 1 Notification Messages is included in PullMessagesResponse

STEP PASSED

STEP 136 - Response is not empty

STEP PASSED

STEP 137 - Waiting for notification

STEP PASSED

STEP 138 - Send Unsubscribe request

STEP PASSED

STEP 139 - Send Unsubscribe request

STEP PASSED

STEP 140 - Send Unsubscribe request

STEP PASSED

STEP 141 - Send Unsubscribe request

STEP PASSED

STEP 142 - Send Unsubscribe request

STEP PASSED

STEP 143 - Send Unsubscribe request

STEP PASSED

STEP 144 - Send Unsubscribe request

STEP PASSED

STEP 145 - Send Unsubscribe request

STEP PASSED

STEP 146 - Send Unsubscribe request

STEP PASSED

STEP 147 - Send Unsubscribe request

STEP PASSED

TEST PASSED

EVENT-3-1-38-v18.06 REALTIME PULLPOINT SUBSCRIPTION - MESSAGE CONTENT FILTER

TestResult

STEP 1 - Get Device service address

STEP PASSED

STEP 2 - Check that the DUT returned Device service address

STEP PASSED

STEP 3 - Get Services

STEP PASSED

STEP 4 - Get Event service address

STEP PASSED

STEP 5 - Check that the DUT returned Event service address

STEP PASSED

STEP 6 - Get Event Properties

STEP PASSED

STEP 7 - Check the DUT returned at least one MessageContentFilterDialect item

STEP PASSED

STEP 8 - Parse topic

STEP PASSED

STEP 9 - Create Pull Point Subscription

STEP PASSED

STEP 10 - Check that TerminationTime is specified

STEP PASSED

STEP 11 - Check that TerminationTime and CurrentTime has reasonable values

STEP PASSED

STEP 12 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 13 - Check if the DUT returned SubscriptionReference

STEP PASSED

STEP 14 - Check if SubscriptionReference contains address

STEP PASSED

STEP 15 - Check that URL specified is valid

STEP PASSED

STEP 16 - Send PullMessages request

STEP PASSED

STEP 17 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 18 - Check that a maximum number of 1 Notification Messages is included in PullMessagesResponse

STEP PASSED

STEP 19 - Response is not empty

STEP PASSED

STEP 20 - Waiting for notifications [Topic = 'tns1:Device/Trigger/DigitalInput', PropertyOperation = 'Initialized']

STEP PASSED

STEP 21 - Send Unsubscribe request

STEP PASSED

STEP 22 - Wait for 1 second(s) to complete the operation

STEP PASSED

STEP 23 - Check if the DUT returned notification message with 'Source.SimpleItem' element and 'Name', 'Value' attributes

STEP PASSED

STEP 24 - Create Pull Point Subscription

STEP PASSED

STEP 25 - Check that TerminationTime is specified

STEP PASSED

STEP 26 - Check that TerminationTime and CurrentTime has reasonable values

STEP PASSED

STEP 27 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 28 - Check if the DUT returned SubscriptionReference

STEP PASSED

STEP 29 - Check if SubscriptionReference contains address

STEP PASSED

STEP 30 - Check that URL specified is valid

STEP PASSED

STEP 31 - Send PullMessages request

STEP PASSED

STEP 32 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 33 - Check that a maximum number of 1 Notification Messages is included in PullMessagesResponse

STEP PASSED

STEP 34 - Response is not empty

STEP PASSED

STEP 35 - Waiting for notifications [Topic = 'tns1:Device/Trigger/DigitalInput', PropertyOperation = 'Initialized']

STEP PASSED

STEP 36 - Send Unsubscribe request

STEP PASSED

TEST PASSED

EVENT-4-1-6-v16.07 EVENT - NAMESPACES (DEFAULT NAMESPACES FOR EACH TAG)

TestResult

STEP 1 - Get Event service address

STEP PASSED

STEP 2 - Send Subscribe request

STEP PASSED

STEP 3 - Check that the DUT returned Subscribe response

STEP PASSED

STEP 4 - Check that CurrentTime is specified

STEP PASSED

STEP 5 - Check that TerminationTime is specified

STEP PASSED

STEP 6 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 7 - Check if the DUT returned SubscriptionReference

STEP PASSED

STEP 8 - Check if SubscriptionReference contains address

STEP PASSED

STEP 9 - Check that URL specified is valid

STEP PASSED

STEP 10 - Send Subscribe request

STEP PASSED

STEP 11 - Check that the DUT returned Subscribe response

STEP PASSED

STEP 12 - Check that CurrentTime is specified

STEP PASSED

STEP 13 - Check that TerminationTime is specified

STEP PASSED

STEP 14 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 15 - Check if the DUT returned SubscriptionReference

STEP PASSED

STEP 16 - Check if SubscriptionReference contains address

STEP PASSED

STEP 17 - Check that URL specified is valid

STEP PASSED

STEP 18 - Check if reaction to request was the same

STEP PASSED

STEP 19 - Delete Subscription Manager

STEP PASSED

STEP 20 - Delete Subscription Manager

STEP PASSED

TEST PASSED

EVENT-4-1-7-v16.07 EVENT - NAMESPACES (DEFAULT NAMESPACES FOR PARENT TAG)

TestResult

STEP 1 - Get Event service address

STEP PASSED

STEP 2 - Send Subscribe request

STEP PASSED

STEP 3 - Check that the DUT returned Subscribe response

STEP PASSED

STEP 4 - Check that CurrentTime is specified

STEP PASSED

STEP 5 - Check that TerminationTime is specified

STEP PASSED

STEP 6 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 7 - Check if the DUT returned SubscriptionReference

STEP PASSED

STEP 8 - Check if SubscriptionReference contains address

STEP PASSED

STEP 9 - Check that URL specified is valid

STEP PASSED

STEP 10 - Send Subscribe request

STEP PASSED

STEP 11 - Check that the DUT returned Subscribe response

STEP PASSED

STEP 12 - Check that CurrentTime is specified

STEP PASSED

STEP 13 - Check that TerminationTime is specified

STEP PASSED

STEP 14 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 15 - Check if the DUT returned SubscriptionReference

STEP PASSED

STEP 16 - Check if SubscriptionReference contains address

STEP PASSED

STEP 17 - Check that URL specified is valid

STEP PASSED

STEP 18 - Check if reaction to request was the same

STEP PASSED

STEP 19 - Delete Subscription Manager

STEP PASSED

STEP 20 - Delete Subscription Manager

STEP PASSED

TEST PASSED

EVENT-4-1-8-v16.07 EVENT - NAMESPACES (NOT STANDARD PREFIXES)

TestResult

STEP 1 - Get Event service address

STEP PASSED

STEP 2 - Send Subscribe request

STEP PASSED

STEP 3 - Check that the DUT returned Subscribe response

STEP PASSED

STEP 4 - Check that CurrentTime is specified

STEP PASSED

STEP 5 - Check that TerminationTime is specified

STEP PASSED

STEP 6 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 7 - Check if the DUT returned SubscriptionReference

STEP PASSED

STEP 8 - Check if SubscriptionReference contains address

STEP PASSED

STEP 9 - Check that URL specified is valid

STEP PASSED

STEP 10 - Send Subscribe request

STEP PASSED

STEP 11 - Check that the DUT returned Subscribe response

STEP PASSED

STEP 12 - Check that CurrentTime is specified

STEP PASSED

STEP 13 - Check that TerminationTime is specified

STEP PASSED

STEP 14 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 15 - Check if the DUT returned SubscriptionReference

STEP PASSED

STEP 16 - Check if SubscriptionReference contains address

STEP PASSED

STEP 17 - Check that URL specified is valid

STEP PASSED

STEP 18 - Check if reaction to request was the same

STEP PASSED

STEP 19 - Delete Subscription Manager

STEP PASSED

STEP 20 - Delete Subscription Manager

STEP PASSED

TEST PASSED

EVENT-4-1-9-v16.07 EVENT - NAMESPACES (DIFFERENT PREFIXES FOR THE SAME NAMESPACE)

TestResult

STEP 1 - Get Event service address

STEP PASSED

STEP 2 - Send Subscribe request

STEP PASSED

STEP 3 - Check that the DUT returned Subscribe response

STEP PASSED

STEP 4 - Check that CurrentTime is specified

STEP PASSED

STEP 5 - Check that TerminationTime is specified

STEP PASSED

STEP 6 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 7 - Check if the DUT returned SubscriptionReference

STEP PASSED

STEP 8 - Check if SubscriptionReference contains address

STEP PASSED

STEP 9 - Check that URL specified is valid

STEP PASSED

STEP 10 - Send Subscribe request

STEP PASSED

STEP 11 - Check that the DUT returned Subscribe response

STEP PASSED

STEP 12 - Check that CurrentTime is specified

STEP PASSED

STEP 13 - Check that TerminationTime is specified

STEP PASSED

STEP 14 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 15 - Check if the DUT returned SubscriptionReference

STEP PASSED

STEP 16 - Check if SubscriptionReference contains address

STEP PASSED

STEP 17 - Check that URL specified is valid

STEP PASSED

STEP 18 - Check if reaction to request was the same

STEP PASSED

STEP 19 - Delete Subscription Manager

STEP PASSED

STEP 20 - Delete Subscription Manager

STEP PASSED

TEST PASSED

EVENT-4-1-10-v16.07 EVENT - NAMESPACES (THE SAME PREFIX FOR DIFFERENT NAMESPACES)

TestResult

STEP 1 - Get Event service address

STEP PASSED

STEP 2 - Send Subscribe request

STEP PASSED

STEP 3 - Check that the DUT returned Subscribe response

STEP PASSED

STEP 4 - Check that CurrentTime is specified

STEP PASSED

STEP 5 - Check that TerminationTime is specified

STEP PASSED

STEP 6 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 7 - Check if the DUT returned SubscriptionReference

STEP PASSED

STEP 8 - Check if SubscriptionReference contains address

STEP PASSED

STEP 9 - Check that URL specified is valid

STEP PASSED

STEP 10 - Send Subscribe request

STEP PASSED

STEP 11 - Check that the DUT returned Subscribe response

STEP PASSED

STEP 12 - Check that CurrentTime is specified

STEP PASSED

STEP 13 - Check that TerminationTime is specified

STEP PASSED

STEP 14 - Validate CurrentTime and TerminationTime

STEP PASSED

STEP 15 - Check if the DUT returned SubscriptionReference

STEP PASSED

STEP 16 - Check if SubscriptionReference contains address

STEP PASSED

STEP 17 - Check that URL specified is valid

STEP PASSED

STEP 18 - Check if reaction to request was the same

STEP PASSED

STEP 19 - Delete Subscription Manager

STEP PASSED

STEP 20 - Delete Subscription Manager

STEP PASSED

TEST PASSED

EVENT-5-1-1-v15.06 EVENT SERVICE CAPABILITIES

TestResult

STEP 1 - Get Event service address

STEP PASSED

STEP 2 - Check that the DUT returned Event service address

STEP PASSED

STEP 3 - Get Event Service Capabilities

STEP PASSED

TEST PASSED

EVENT-5-1-2-v15.06 GET SERVICES AND EVENT SERVICE CAPABILITIES CONSISTENCY

TestResult

STEP 1 - Get Services

STEP PASSED

STEP 2 - Check that the DUT returned events service information

STEP PASSED

STEP 3 - Check that the DUT returned Capabilities element

STEP PASSED

STEP 4 - Get Event service address

STEP PASSED

STEP 5 - Check that the DUT returned Event service address

STEP PASSED

STEP 6 - Get Event Service Capabilities

STEP PASSED

STEP 7 - Parse Capabilities element in GetServices response

STEP PASSED

STEP 8 - Compare Capabilities

STEP PASSED

TEST PASSED